Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEG OSK5O88ES

User Manual for AEG ÖKO SANTO OSK5O88ES Refrigerator

Model: OSK5O88ES | Brand: AEG

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your AEG ÖKO SANTO OSK5O88ES refrigerator. Please read these instructions carefully before use and keep them for future reference.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the appliance is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

Setup and Installation

Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage. Report any damage to your retailer immediately.

Placement

The refrigerator is designed for built-in integration. Ensure adequate ventilation around the appliance. Refer to the installation diagram for precise dimensions and clearances.




Figure 1: Installation dimensions for the AEG OSK5O88ES refrigerator. The appliance measures 873x548x549 mm (HxWxD) and requires an installation niche of 880x560x550 mm (HxWxD). Minimum ventilation areas of 200 cm² are required at the top and bottom.

Electrical Connection

Connect the appliance to a properly grounded electrical outlet. The refrigerator operates on 230-240 Volts with a connection value of 100 Watts. The power cord length is 2.4 meters.

Door Reversal

The door hinge is factory-set to the right but is reversible. Consult a qualified technician or the full service manual for detailed instructions on changing the door swing direction.

Operating Instructions

Temperature Control

The AEG OSK5O88ES features mechanical temperature control. Adjust the thermostat dial inside the refrigerator to set the desired cooling level. Higher numbers typically indicate colder temperatures.

Internal Features

The refrigerator is equipped with LED interior lighting for clear visibility. It includes 3 glass shelves, 1 fruit and vegetable drawer, and an egg tray for 6 eggs.



Figure 2: Interior view of the AEG OSK5O88ES refrigerator, showing the arrangement of glass shelves, door bins, and the fruit/vegetable drawer.



Figure 3: Close-up of the transparent fruit and vegetable drawer, designed to keep produce fresh.

Maintenance and Cleaning

Cleaning the Interior

Before cleaning, always unplug the appliance. Clean the interior regularly with a soft cloth and a mild, non-abrasive detergent. Rinse with clean water and dry thoroughly. Avoid using harsh chemicals or abrasive cleaners.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. For stubborn marks, use a mild detergent. Ensure no water enters the electrical components.

Troubleshooting

Before contacting service, review the following common issues and solutions:

- **Appliance does not operate:** Check if the power cord is properly plugged in and if there is power to the outlet. Ensure the temperature control is not set to 'off'.
- **Temperature is not cold enough:** Verify the temperature setting. Avoid frequent door openings. Ensure the door seal is intact and the appliance is not overloaded.
- **Unusual noise:** The refrigerator operates at a noise level of 36 dB. Some operational sounds (e.g., refrigerant circulation, compressor) are normal. Ensure the appliance is level and not touching walls or other objects.

If the problem persists after checking these points, please contact customer support.

Specifications

Feature	Specification
Model	OSK5O88ES
Type	Built-in Refrigerator (without freezer compartment)
Total Net Capacity	142 Liters
Dimensions (HxWxD)	873 x 548 x 549 mm
Niche Dimensions (HxWxD)	880 x 560 x 550 mm
Energy Efficiency Class	E
Annual Energy Consumption	93 kWh/annum
Airborne Acoustical Noise Emission	36 dB(A) re 1 pW
Noise Emission Class	C
Climate Class	SN-N-ST-T
Control Type	Mechanical
Power Connection	100 Watts
Voltage	230-240 Volts
Cable Length	2.4 meters
Door Hinge	Right, reversible
Lighting	LED

For detailed energy information, please refer to the energy label and the EPREL database:




Figure 4: Energy label for the AEG OSK5O88ES, showing an energy efficiency class of E, annual energy consumption of 93 kWh, and a noise level of 36 dB.

EPREL Database Link: https://eprel.ec.europa.eu/qr/1629773

Warranty and Support

Warranty Information

Your AEG ÖKO SANTO OSK5O88ES refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official AEG website for specific terms and conditions applicable in your region.

Customer Support

For technical assistance, spare parts, or service requests, please contact AEG customer support. Have your model number (OSK5O88ES) and serial number ready when contacting support.

Contact details can typically be found on the AEG official website or in your purchase documentation.

© 2024 AEG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7CQ5RQB

More documents and user manuals: **https://manuals.plus/**