



[Manuals.plus](#) /

› [NANU SHOP](#) /

› Digital Voice Recorder MT-556 User Manual

NANU SHOP MT-556

Digital Voice Recorder MT-556 User Manual

Brand: NANU SHOP | Model: MT-556

INTRODUCTION

The NANU SHOP MT-556 Digital Voice Recorder is a versatile and portable audio recording device designed for capturing high-quality audio in various settings such as conferences, lectures, meetings, and classes. With 8GB of internal memory, it offers extensive recording time and features an LCD screen for easy navigation. It also functions as an MP3 player and a portable storage device (pen drive).

PACKAGE CONTENTS

Please check the package carefully to ensure all items are present:

- 1 Digital Voice Recorder (MT-556)
- 1 Earphone
- 1 RJ-11 Phone Kit (for telephone recording)
- 1 User Manual
- 1 Lapel Microphone
- 1 USB Cable
- 2 AAA Batteries (may be included or required separately)



Image: All components included in the MT-556 Digital Voice Recorder package.

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your MT-556 Digital Voice Recorder.



Image: Front view of the recorder, highlighting the LCD screen and control buttons.






Image: Side view displaying the VOL+, VOL-, MODE, PLAY/PAUSE, and HOLD buttons.



Image: Top view showing the MIC and Headphone jacks.



Image: Detailed view of the audio input (MIC) and output (Headphone) ports.




Image: Close-up of the LCD screen, showing recording status and time.



Image: The recorder held in a hand, illustrating its compact and portable design.

SETUP

1. Battery Installation

The MT-556 recorder requires two AAA batteries for operation. Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the device.
2. Slide the cover open.
3. Insert two AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Close the battery compartment cover securely.




Image: Rear view of the recorder with the battery compartment open, showing where to insert AAA batteries.

2. Initial Power On

After installing batteries, slide the power switch (often combined with the HOLD switch) to the 'ON' position. The LCD screen should light up.

3. Connecting to a Computer (USB)

The MT-556 can be connected to a computer via its USB interface to transfer recorded files or use it as a portable storage device.

1. Ensure the recorder is powered on.
2. Connect one end of the provided USB cable to the recorder's USB port.
3. Connect the other end of the USB cable to an available USB port on your computer.
4. The recorder should be recognized as a removable disk (similar to a pen drive). You can then access your recorded files (WMA, MP3) or store other data.

5. **Note for Windows 10 users:** Some users have reported difficulty connecting to Windows 10. If you encounter issues, try connecting to a different USB port, restarting the computer, or ensuring the device is not in 'HOLD' mode. It may be recognized more easily on older Windows versions like Windows 7.

OPERATING INSTRUCTIONS

1. Basic Recording

1. Ensure the recorder is powered on and not in 'HOLD' mode.
2. Press the **REC** button (usually red or marked with a red dot) to start recording. The recording indicator on the LCD screen will activate.
3. To pause recording, press the **PLAY/PAUSE** button. Press it again to resume.
4. To stop recording, press the **STOP** button. The recorded file will be saved automatically.

2. Playback

1. In stop mode, use the **UP** and **DOWN** buttons to navigate through your recorded files.
2. Press the **PLAY/PAUSE** button to start playback of the selected file.
3. Press **PLAY/PAUSE** again to pause playback.
4. Press the **STOP** button to stop playback.

3. Volume Control

During playback, use the **VOL+** button to increase volume and the **VOL-** button to decrease volume.

4. Mode Selection (MP3 Player Function)

The MT-556 can also function as an MP3 player. Press the **MODE** button to switch between recording mode and MP3 playback mode. In MP3 mode, you can play music files stored on the device.

5. Voice Operated Recording (VOR)

The VOR function allows the recorder to automatically start recording when sound is detected and pause when there is silence, saving memory and battery life. Refer to the detailed user manual (included in the package) for specific instructions on enabling and adjusting VOR sensitivity.

6. Using the Lapel Microphone

For enhanced audio capture, especially in interviews or presentations, connect the included lapel microphone to the MIC input jack on the recorder. Ensure the microphone is securely plugged in before starting a recording.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or solvents.
- **Storage:** Store the recorder in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.
- **Battery Care:** Replace batteries when the low battery indicator appears on the LCD. Always use fresh AAA batteries.
- **Data Backup:** Regularly back up important recordings to your computer to prevent data loss.

TROUBLESHOOTING

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Device does not power on.	<p>Check if batteries are inserted correctly with correct polarity.</p> <p>Replace old or depleted batteries with new AAA batteries.</p> <p>Ensure the power switch is in the 'ON' position and not 'HOLD'.</p>
Cannot connect to computer (Windows 10).	<p>Ensure the device is not in 'HOLD' mode.</p> <p>Try connecting to a different USB port on your computer.</p> <p>Restart your computer.</p> <p>Ensure the USB cable is not damaged.</p>
Poor recording quality / High background noise.	<p>Ensure the microphone is not obstructed.</p> <p>Record in a quieter environment.</p> <p>If using the built-in microphone, consider using the external lapel microphone for clearer audio.</p> <p>Check VOR sensitivity settings if enabled.</p>
Low playback volume from speaker.	<p>Increase volume using the VOL+ button.</p> <p>The built-in speaker may have limited output; use earphones for better sound quality and volume.</p>
Device freezes or becomes unresponsive.	<p>Remove and reinsert batteries to perform a hard reset.</p>

SPECIFICATIONS

Feature	Detail
Brand	NANU SHOP
Manufacturer	Tomate
Model Number	MT-556
Product Type	Electronics
Memory Storage Capacity	8 GB
Hardware Interface	USB
Compatible Devices	Smartphone (for file transfer, not direct connection)
Microphone Form Factor	Built-in
Audio Port	3.5 millimeters
Power Source Type	Battery Powered (2 AAA batteries required)
Media Format	WMA, MP3 Audio
Color	Black
Product Weight	185 g
Package Dimensions	14 x 9 x 6 cm

Feature	Detail
Available for purchase since	June 18, 2024

WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty of **90 days** from the date of purchase. Please retain your proof of purchase for warranty claims.

For further assistance, technical support, or warranty inquiries, please visit the official NANU SHOP store on Amazon: [NANU SHOP Amazon Store](#).