

[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns 63-inch Farmhouse Sideboard Buffet Cabinet Instruction Manual

Tribesigns B0D7DK771G

Tribesigns 63-inch Farmhouse Sideboard Buffet Cabinet Instruction Manual

Model: B0D7DK771G

1. INTRODUCTION

Thank you for choosing the Tribesigns 63-inch Farmhouse Sideboard Buffet Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The Tribesigns 63-inch Farmhouse Sideboard Buffet Cabinet, featuring a light oak finish with black geometric patterns on the doors, positioned in a living room with decorative items on top.

2. SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use.
- Do not stand or climb on the cabinet.
- Distribute weight evenly across shelves and the top surface.
- Install the anti-tip device to prevent accidental tipping, especially in households with children or pets.
- Keep small parts and packaging materials away from children.

3. PACKAGE CONTENTS

Before assembly, verify that all components and hardware listed below are present. If any parts are missing or damaged,


please contact customer support.

Components:

- Top Panel
- Bottom Panel
- Side Panels (Left & Right)
- Back Panels
- Adjustable Shelves
- Doors (with geometric pattern)
- Metal Legs/Frame

Hardware:

- Screws, Bolts, Nuts
- Cam Locks and Dowels
- Hinges
- Shelf Pins
- Adjustable Feet Pads
- Anti-tip Kit (Wall anchor, strap, screws)
- Assembly Tool (Hex key/Allen wrench)



Strong Metal Legs



Soft Closing Hinge



Exquisite Pattern

Image 3.1: Detailed view of the cabinet's construction, highlighting the strong metal legs, soft-closing hinges, and the intricate geometric pattern on the doors.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people. Follow the numbered steps provided in the included assembly guide. The following is a general overview.

4.1 Pre-Assembly

- Clear a spacious area for assembly.
- Lay out all parts and hardware, comparing them with the package contents list.
- Ensure you have a Phillips head screwdriver (not included) in addition to the provided hex key.

4.2 Step-by-Step Assembly

1. Attach the cam bolts and dowels to the side panels, top panel, and bottom panel as indicated in the detailed diagram.

2. Connect the side panels to the bottom panel using cam locks.
3. Slide the back panels into the grooves on the side and bottom panels.
4. Attach the top panel to the assembled structure using cam locks.
5. Secure the metal support frame to the bottom of the cabinet using the provided screws.
6. Install the hinges onto the doors and the cabinet frame. Attach the doors to the cabinet, ensuring proper alignment.
7. Insert shelf pins into the desired holes for the adjustable shelves. Place the shelves onto the pins.
8. Attach the adjustable feet pads to the bottom of the metal frame.

4.3 Anti-Tip Device Installation

For safety, it is crucial to install the anti-tip device. Locate a suitable wall stud or use appropriate wall anchors for your wall type.

1. Position the cabinet in its final desired location.
2. Mark the wall where the anti-tip bracket will be secured, ensuring it aligns with the top rear of the cabinet.
3. Drill pilot holes if necessary and attach the bracket to the wall using the provided screws.
4. Attach the other bracket to the rear top edge of the cabinet.
5. Connect the two brackets with the provided strap, ensuring it is taut.

5. OPERATING INSTRUCTIONS

5.1 Door Operation

The cabinet features soft-closing hinges. Gently push the doors to close them, and they will slowly retract into place. To open, pull the doors from the edge.

5.2 Shelf Adjustment

The internal shelves are adjustable. To change shelf height, remove all items from the shelf, lift the shelf, and reposition the shelf pins into the desired holes on the side panels. Ensure all four pins are securely in place before placing the shelf back.

ENOUGH STORAGE SPACE

2 Tier Shelves for all your food cans and kitchen essentials



Image 5.1: The interior of the cabinet, demonstrating the two-tier shelving system with various kitchen items, highlighting the storage capacity.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

7.1 Cabinet is Wobbly

- Ensure all screws and cam locks are fully tightened.
- Verify that the cabinet is on a level surface. Adjust the adjustable feet pads if needed to stabilize the unit.
- Confirm the back panels are correctly seated in their grooves.

7.2 Doors Do Not Align Properly

- Adjust the hinges. Most hinges have screws that allow for vertical, horizontal, and depth adjustments. Refer to the hinge manufacturer's instructions or a general guide for hinge adjustment.
- Ensure the cabinet itself is level and square.


7.3 Difficulty Closing Doors

- Check for any obstructions inside the cabinet or along the door's path.
- Inspect hinges for damage or misalignment.

8. SPECIFICATIONS

Feature	Detail
Brand	Tribesigns
Model	B0D7DK771G
Color	Light Oak & Black
Product Dimensions (D x W x H)	12.8"D x 62.99"W x 36.02"H
Material	Engineered Wood, Metal Frame
Special Features	4-Tier Storage Shelves, Adjustable Feet Pads, Removable Shelf, Two-tone Doors
Recommended Load (Top)	50 lbs
Recommended Load (Each Shelf)	15 lbs

Dimensions & Storage Capacity



Recommended Load

Top 50lbs

Each Shelf 15 lbs

Image 8.1: A detailed diagram illustrating the overall dimensions (12.8"D x 62.99"W x 36.02"H) and recommended load capacities for the top (50 lbs) and each shelf (15 lbs).

9. WARRANTY AND SUPPORT

Tribesigns provides an 18-month warranty for this product, covering manufacturing defects. For warranty claims, missing parts, or any other inquiries, please contact Tribesigns customer service.

Customer Service: Please refer to the contact information provided with your purchase or visit the official Tribesigns website for support.

© 2025 Tribesigns. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question