



[Manuals.plus](#) /

> [COBIZI](#) /

> [COBIZI 10x30 Pop Up Canopy with Removable Sidewalls Instruction Manual](#)

## COBIZI 10x30 Pop Up Canopy with Removable Sidewalls

# COBIZI 10x30 Pop Up Canopy with Removable Sidewalls Instruction Manual

Model: 10x30 Pop Up Canopy with Removable Sidewalls

[Introduction](#) [Safety Guidelines](#) [Package](#)  
[Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient setup, operation, and maintenance of your COBIZI 10x30 Pop Up Canopy with Removable Sidewalls. This heavy-duty canopy is designed for various outdoor events, offering UPF 50+ sun protection and waterproof capabilities. Please read this manual thoroughly before assembly and use.



The COBIZI 10x30 Pop Up Canopy with removable sidewalls, providing a spacious shaded area for outdoor gatherings.

## SAFETY GUIDELINES

---

Adherence to these safety guidelines is crucial for preventing injury and damage to the canopy:

1. Always anchor the tent securely to the ground using the provided ropes, sandbags, and stakes, especially in windy conditions.
2. Do not use the tent during extreme weather conditions, including high winds or storms.
3. This tent provides UPF 50+ UV protection, but users should still take precautions against sun exposure, such as wearing protective clothing, using sunscreen, and staying hydrated.
4. The frame is rust-resistant and corrosion-resistant, but users should still inspect the tent for any signs of damage or wear before each use.
5. Always follow the manufacturer's instructions for setup, use, and dismantling to ensure the tent's structural integrity and longevity.

## PACKAGE CONTENTS

---

Verify that all components listed below are present in your package:

- 1x 10x30 Canopy Frame
- 1x 10x30 Canopy Top Cover
- 8x PU coated Panels (5x Sidewalls with Window and 3x Sidewalls with Zipper)
- 4x 420D Oxford cloth PVC coated Sandbags
- 4x Ground Pegs
- 8x Wind Ropes
- 1x Wheeled Bag
- 1x Manual

## PACKAGE LIST



Image showing all components included in the COBIZI 10x30 Pop Up Canopy package: frame, canopy top, sidewalls, sandbags, ground pegs, wind ropes, wheeled bag, and manual.

## SETUP INSTRUCTIONS

The COBIZI 10x30 Pop Up Canopy is designed for quick assembly, typically requiring 4-6 people. No tools are needed.

1. **Step 1: Unfold the Heavy-Duty Frame.** Place the folded frame in your desired location and begin to gently pull the legs outwards to expand the frame partially.
2. **Step 2: Attach Canopy Top to the Frame.** Drape the canopy top cover over the partially expanded frame. Secure the canopy top to the frame using the hook-and-loop fasteners located on the underside of the canopy.
3. **Step 3: Prop Up the Frame and Adjust Height.** With the canopy top attached, fully extend the frame. Use the safety thumb buttons on the legs to adjust the canopy to one of the three available height settings (6.2ft/74.4in, 6.4ft/76.8in, or 6.6ft/79.2in). Ensure all legs are locked into place at the desired height.
4. **Step 4: Install Sidewalls and Secure the Canopy.** Attach the removable sidewalls using the full strip of Velcro and zippers. Secure the canopy using the provided sandbags, ground pegs, and wind ropes to enhance stability, especially in windy conditions.



Visual guide illustrating the four main steps for setting up the COBIZI 10x30 Pop Up Canopy: unfolding the frame, attaching the canopy top, raising the frame and adjusting height, and installing sidewalls with securing accessories.

Your browser does not support the video tag.

Video demonstrating the setup process of a COBIZI canopy, highlighting the ease of assembly and the stability of the frame. This video shows the canopy frame and top being set up, with a focus on its robust construction and suitability for various outdoor conditions, including light rain.

## OPERATION

---

### Adjusting Height

The canopy offers three adjustable height settings. To adjust, locate the thumb buttons on each leg. Press the button and slide the inner leg section up or down to the desired height. Ensure the button clicks into place securely at each leg for stability.

### Using Removable Sidewalls

The canopy includes 8 removable sidewalls: 5 with windows and 3 with zippers. These can be attached or removed as needed using the integrated Velcro strips and zippers. This allows for flexible configuration, providing protection from sun, wind, or privacy, or opening up the space for an unobstructed view.




Image demonstrating different configurations of the COBIZI canopy with its removable sidewalls, showing options with all sidewalls, partial sidewalls, and open access.

## MAINTENANCE

---

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the fabric to air dry completely before storage to prevent mildew.
- **Frame Care:** The alloy steel frame is powder-coated for rust resistance. Inspect the frame regularly for any signs of damage or corrosion. Clean any dirt or debris from the frame.
- **Storage:** When not in use, disassemble the canopy and store all components in the provided wheeled bag in a dry, cool place, away from direct sunlight.
- **Inspection:** Before each use, inspect all parts, including the frame, fabric, ropes, and stakes, for wear, damage, or missing components. Replace any damaged parts immediately.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter:

- **Canopy not stable:** Ensure all legs are fully extended and locked. Use all provided sandbags, ground pegs, and wind ropes to anchor the canopy securely. Do not use in high winds.
- **Water pooling on canopy top:** Ensure the canopy top is taut and properly secured to the frame. Adjust the height if necessary to create proper tension and allow water to run off.
- **Difficulty extending/retracting legs:** Check for any obstructions or debris in the leg mechanisms. Ensure the thumb buttons are fully depressed when attempting to adjust the height.

## SPECIFICATIONS

<b>Brand</b>	COBIZI
<b>Model</b>	10x30 Pop Up Canopy with Removable Sidewalls
<b>Material</b>	Alloy Steel, Oxford fabric with PU coating
<b>Color</b>	Blue
<b>Item Weight</b>	142 Pounds
<b>Dimensions (L x W x H)</b>	354"L x 118"W x 132"H
<b>Floor Area</b>	300 Square Feet
<b>Max Ceiling Height</b>	79.2 Inches
<b>Ultraviolet Light Protection</b>	UPF 50+
<b>Water Resistance Level</b>	Waterproof (2.1psi pressure)
<b>Frame Type</b>	Truss (Heavy Duty)
<b>Required Assembly</b>	Yes

## WARRANTY AND SUPPORT

COBIZI is committed to providing high-quality products. If you encounter any issues or have questions regarding your 10x30 Pop Up Canopy, please contact our customer service team. We strive to offer the best service and support.

For assistance, please refer to the contact information provided with your purchase or visit the official COBIZI store on Amazon: [COBIZI Store](#).