

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VGR](#) /

› [VGR V-643 Ultra Premium Hair Clipper and Trimmer Set Instruction Manual](#)

VGR V-643

VGR V-643 Ultra Premium Hair Clipper and Trimmer Set Instruction Manual

Model: V-643

[Safety Information](#) [Package Contents](#) [Product Overview](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Keep away from water when plugged in.
- Use caution when operating near eyes and ears.
- Keep out of reach of children.
- Do not use if the cord or device is damaged.
- Only use the provided charging cable and accessories.
- Do not disassemble the appliance. Refer all servicing to qualified personnel.
- Ensure the appliance is fully dry before charging or use.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Hair Clipper (VGR V-643)
- Hair Trimmer (VGR V-643 T-Cutter)
- 12 Guide Combs for Clipper (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm, and others)
- 4 Guide Combs for Trimmer (1mm, 3mm, 5mm, 7mm)
- USB Type-C Charging Cable
- Cleaning Brush

- Lubricating Oil



Image 2.1: The VGR V-643 Hair Clipper and Trimmer Set, showcasing both devices and all included accessories such as guide combs, charging cable, cleaning brush, and oil.

3. PRODUCT OVERVIEW

The VGR V-643 set includes a full-size hair clipper and a precision T-cutter trimmer, both designed with durable metal housing and advanced blade technology for efficient grooming.

3.1. Hair Clipper

The hair clipper features self-sharpening ceramic and powder metallurgic blades for smooth cutting of various hair types. It includes an integrated taper lever for fine-tuning cutting lengths from 0.5mm to 2mm without guide combs, and supports 8 additional guide combs for longer styles.



Image 3.1: Detailed view of the VGR V-643 Hair Clipper, highlighting its advanced ceramic and powder metallurgic blade and the range of guide combs available for various cutting lengths.

3.2. Hair Trimmer (T-Cutter)

The T-cutter trimmer is equipped with fine-cutting teeth, ideal for precise detailing, outlining, and zero-gapped trimming. It comes with 4 guide combs for specific trimming lengths.

LI-ION POWER




Image 3.2: Detailed view of the VGR V-643 Hair Trimmer, showing its precision blade and the included guide combs for detailed grooming.

3.3. Key Features

- **Metal Housing:** Both devices feature a durable and ergonomic metal housing.
- **Digital LED Display:** Shows battery charge status and current RPM.
- **4-Speed Motor:** Adjustable motor speeds from 5500 to 7000 RPM for different hair types.
- **Cordless/Corded Operation:** Can be used wirelessly or while plugged in.
- **Long Battery Life:** Clipper: 2600mAh Li-ion battery, up to 250 minutes run time. Trimmer: 1600mAh Li-ion battery, up to 240 minutes run time.



Image 3.3: Close-up of the VGR V-643 devices, illustrating the ON/OFF and speed buttons, the LED digital display showing power and RPM, and the USB charging port.

4. SETUP

4.1. Initial Charging

1. Before first use, fully charge both the hair clipper and trimmer.
2. Connect the USB Type-C charging cable to the charging port on the device.
3. Plug the other end of the USB cable into a compatible power source (e.g., laptop, power bank, USB adapter, car charger).
4. The LED display will indicate charging status.
5. **Clipper:** Full charge takes approximately 3.5 hours for up to 250 minutes of cordless operation.
6. **Trimmer:** Full charge takes approximately 2.5 hours for up to 240 minutes of cordless operation.
7. Unplug the device once fully charged to prevent overcharging.



Image 4.1: Illustration of the charging process for the VGR V-643 devices, detailing charging times, battery capacities, and compatible charging modes such as laptop, power cord, USB, car charger, and power bank.

4.2. Attaching Guide Combs

To achieve desired hair lengths, select the appropriate guide comb and attach it securely to the blade. Ensure the comb clicks into place.

- **Clipper Guide Combs:** 1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm.
- **Trimmer Guide Combs:** 1mm, 3mm, 5mm, 7mm.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off and Speed Adjustment

1. Press the **Power Button** to turn the device on or off.
2. Use the **Speed Adjustment Buttons** (up/down arrows) to cycle through the 4 available motor speeds (5500-7000 RPM). Select a lower speed for finer hair or sensitive areas, and a higher speed for thicker hair.

3. The LED display will show the current RPM and remaining battery percentage.

5.2. Using the Hair Clipper

1. Ensure hair is clean and dry for best results.
2. Attach the desired guide comb for the intended hair length. For lengths between 0.5mm and 2mm, adjust the integrated taper lever without a comb.
3. Hold the clipper with the blade teeth pointing upwards.
4. Begin cutting from the bottom of the head, moving upwards against the direction of hair growth.
5. Use smooth, overlapping strokes for an even cut.

5.3. Using the Hair Trimmer

1. The trimmer is ideal for detailing, outlining, and achieving very short lengths.
2. Attach one of the 1mm, 3mm, 5mm, or 7mm guide combs if a specific length is desired. For a close, zero-gapped trim, use without a comb.
3. Hold the trimmer at a slight angle to the skin.
4. Use light pressure and controlled movements for precise lines and edges.

6. MAINTENANCE

Regular cleaning and lubrication ensure optimal performance and extend the lifespan of your VGR V-643 set.

6.1. Cleaning the Blades

1. Turn off the device and disconnect it from the power source.
2. Use the provided cleaning brush to remove loose hairs from the blades and inside the cutting head.
3. For a more thorough clean, the blades can be carefully detached (refer to specific blade removal instructions if available in the full manual, or consult VGR support).
4. Do not rinse the entire device under water. The blades may be rinsed if detachable and specified as washable, but ensure they are completely dry before reattaching and using.

6.2. Lubricating the Blades

1. After cleaning and before each use (or regularly, depending on frequency of use), apply 1-2 drops of the provided lubricating oil to the blades.
2. Turn on the device for a few seconds to allow the oil to distribute evenly across the blades.
3. Wipe off any excess oil with a soft cloth.
4. Lubrication reduces friction, maintains cutting efficiency, and prevents blade wear.

7. TROUBLESHOOTING

If you encounter issues with your VGR V-643 set, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Device not charged.	Charge the device fully. Ensure the charging cable is properly connected.
Poor cutting performance or pulling hair.	Blades are dull or dirty; Insufficient lubrication; Hair is too thick for current speed.	Clean and lubricate the blades. Increase motor speed. Ensure blades are properly aligned.
Device not charging.	Faulty charging cable or adapter; Charging port obstruction.	Try a different USB cable or power adapter. Check the charging port for debris.
Excessive noise or vibration.	Blades not properly aligned or loose; Lack of lubrication.	Ensure blades are securely attached and aligned. Apply lubricating oil.

If the problem persists after attempting these solutions, please contact VGR customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	V-643
Brand	VGR
Product Name	VGR V-643 Ultra Premium Metal Housing Hair Clipper Trimmer Set
Power Source	Battery Powered (Cordless/Corded)
Clipper Battery	2600mAh Lithium-Ion
Clipper Charge Time	Approx. 3.5 Hours
Clipper Run Time	Up to 250 Minutes
Trimmer Battery	1600mAh Lithium-Ion
Trimmer Charge Time	Approx. 2.5 Hours
Trimmer Run Time	Up to 240 Minutes
Blade Material	Ceramic, Powder Metallurgic
Motor Speed	4 Speeds, 5500-7000 RPM
Clipper Guide Combs	12 (e.g., 1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm)
Trimmer Guide Combs	4 (1mm, 3mm, 5mm, 7mm)
Product Dimensions	24 x 15.7 x 8 cm

Feature	Detail
Weight	1.02 kg

9. WARRANTY AND SUPPORT

The VGR V-643 Ultra Premium Hair Clipper and Trimmer Set comes with a **12-month quality warranty** from the date of purchase.

This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or failure to follow the instructions in this manual.

For warranty claims, technical support, or any questions regarding your product, please contact VGR customer service through the retailer where you purchased the product or visit the official VGR website for contact information.

Please retain your proof of purchase for warranty validation.