

[Manuals.plus](#) /

› [Altec Lansing](#) /

› Altec Lansing HydraMOTION 2.0 Wireless Bluetooth Speaker User Manual

Altec Lansing HydraMOTION 2.0

Altec Lansing HydraMOTION 2.0 Wireless Bluetooth Speaker

USER MANUAL



Introduction

Thank you for choosing the Altec Lansing HydraMOTION 2.0 Wireless Bluetooth Speaker. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new speaker. Please read it thoroughly to ensure optimal performance and longevity of your device.

The HydraMOTION 2.0 is designed for adventure, featuring a rugged IP67 waterproof rating, long-lasting 16-hour battery life, vibrant RGB lights, and the ability to connect with over 100 other speakers for an immersive audio experience.



The Altec Lansing HydraMOTION 2.0 speaker, showcasing its waterproof design with water splashes around it.

What's in the Box

- HydraMOTION 2.0 Wireless Bluetooth Speaker
- Carry Strap
- USB-C Charging Cable (not explicitly listed but standard for USB-C quick charge)
- Mounting Bracket (as indicated by images)

Product Overview

Controls and Indicators



Detailed view of the speaker's control panel, indicating the function of each button.

Volume Up (+) / Track Forward: Press briefly to increase volume. Press and hold to skip to the next track.

Volume Down (-) / Track Back: Press briefly to decrease volume. Press and hold to go to the previous track.

Play/Pause / Bluetooth Pairing: Press briefly to play or pause music. Press and hold to enter Bluetooth pairing mode.

LED Light Modes: Press to cycle through different RGB light modes.

Voice Assistant: Press to activate your device's voice assistant (e.g., Siri, Google Assistant).

Power On/Off: Press and hold to turn the speaker on or off.

Bluetooth Indicator Light: Shows Bluetooth connection status.

Key Features

- **IP67 Waterproof & Floatable:** Designed to withstand water, sand, and snow, and floats in water for easy retrieval.
- **16-Hour Battery Life:** Enjoy extended playtime on a single charge.
- **RGB LED Lights:** Multiple lighting modes to enhance your listening experience.

- **Party Sync:** Connect with over 100 Altec Lansing speakers for expansive sound.
- **Voice Assistant Integration:** Access your smartphone's voice assistant directly from the speaker.
- **Mountable Design:** Includes a mount for easy attachment to bikes, ATVs, and more.



UP TO
12
HOURS
PLAY TIME*



The HydraMOTION 2.0 highlighting its key features: 12+ hours playtime, 2 ways to play, IP67 rating, floats in water, Party Sync, Hyper-Edge lighting modes, and End-Firing ABRs.

Setup

Initial Charging

Before first use, fully charge your HydraMOTION 2.0 speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a USB power adapter (not included). The charging indicator light will show charging status and turn off when fully charged.

Powering On/Off

To power on the speaker, press and hold the Power button until you hear an audible tone and the indicator lights

illuminate. To power off, press and hold the Power button again until the lights turn off.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press and hold the Play/Pause button until the Bluetooth indicator light begins to flash rapidly, indicating it's in pairing mode.
3. On your smartphone or audio device, enable Bluetooth and search for available devices.
4. Select "HydraMOTION 2.0" from the list of devices.
5. Once connected, the Bluetooth indicator light will turn solid, and you will hear a confirmation tone.

Music Playback

- **Play/Pause:** Press the Play/Pause button.
- **Volume Adjustment:** Press the Volume Up (+) or Volume Down (-) buttons.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.

Voice Assistant

Press the Voice Assistant button to activate your connected device's voice assistant (e.g., Siri, Google Assistant). Use the built-in microphone for commands.

Party Sync Mode

To connect multiple HydraMOTION 2.0 speakers (up to 100+) for a synchronized audio experience:

1. Ensure all speakers are powered on and not connected to any Bluetooth device.
2. On the first speaker (master speaker), press and hold the Bluetooth button until it enters pairing mode.
3. On the second speaker (slave speaker), press the Bluetooth button briefly. It will automatically search for and connect to the master speaker.
4. Repeat for additional speakers. Once connected, all speakers will play the same audio.

RGB Light Modes

Press the LED Light Modes button to cycle through the available lighting effects. The speaker offers various dynamic light shows to match your mood or music.

Mounting the Speaker

The HydraMOTION 2.0 comes with a mounting bracket for easy attachment to various surfaces like bike handlebars, golf carts, or ATVs. Secure the bracket to your desired location, then slide the speaker into the bracket until it clicks into place.



The HydraMOTION 2.0 speaker shown with its included mounting bracket, ready for attachment.



#MOUNTIT #CLIPIT

The HydraMOTION 2.0 speaker securely mounted on the frame of a bicycle, demonstrating its portability.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker's exterior. Do not use harsh chemicals or abrasive cleaners.
- **Water Exposure:** While IP67 rated, ensure the charging port cover is securely closed before exposing the speaker to water. After exposure to saltwater or chlorinated water, rinse the speaker with fresh water and allow it to dry completely before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.



The HydraMOTION 2.0 speaker resting on green grass, with water droplets on its surface, emphasizing its all-proof durability.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not held long enough	Charge the speaker; Press and hold the Power button for 3-5 seconds
Cannot pair with Bluetooth device	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker	Ensure speaker is in pairing mode (flashing light); Turn on device Bluetooth; Move device closer (within 100 ft)

Problem	Possible Cause	Solution
No sound or low volume	Volume too low on speaker/device; Speaker not connected	Increase volume on both speaker and device; Re-pair Bluetooth connection
Party Sync not working	Speakers not in correct mode; Too far apart	Ensure all speakers are disconnected from other devices before initiating Party Sync; Keep speakers within range of each other

Specifications

Feature	Detail
Model Name	HydraMOTION 2.0
Speaker Type	Outdoor
Special Features	Waterproof, Built-in Microphone, Shockproof, Floatable, RGB Lights
Recommended Uses	Indoor/Outdoor
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Range	100 Feet
Battery Life	Up to 16 Hours
Power Source	Battery Powered (1 Lithium Ion battery included)
Speaker Maximum Output Power	12 Watts
Product Dimensions	3.5"D x 3.5"W x 10.25"H
Item Weight	1.98 pounds
UPC	021331127143

Warranty and Support

The Altec Lansing HydraMOTION 2.0 Wireless Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, product registration, or technical support, please visit the official Altec Lansing website or contact their customer service. Keep your proof of purchase for warranty claims.

For further assistance, you may visit the Altec Lansing Store online:[Altec Lansing Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the purpose of the standard USB-A port on the Altec Lansing HydraMOTION 2.0, and how does it differ from the USB-C port?

On the Altec Lansing HydraMOTION 2.0, the two USB ports serve distinct purposes: USB-C Port: This is the primary input port used exclusively for charging the speaker's internal battery. Standard USB (USB-A) Port: This is a...

[Read full answer](#)