

WEEME HL06SL

WEEME Professional Hair Clippers 3-in-1 User Manual

Model: HL06SL

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your WEEME Professional Hair Clippers, a versatile 3-in-1 grooming device designed for hair clipping, beard trimming, and electric shaving. Please read this manual thoroughly before first use and retain it for future reference.

The device features a durable zinc alloy housing, adjustable blades, and an LED display for battery status and speed settings. It is powered by a rechargeable lithium-ion battery, offering cordless operation.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Keep the appliance dry. Do not use it near water or in wet conditions.
- Do not immerse the appliance in water.
- Keep out of reach of children.
- Ensure the appliance is fully charged before use to maintain optimal performance.
- Do not use if the blades are damaged or broken, as this may cause injury.
- Only use the provided USB charging cable.

3. PRODUCT COMPONENTS

The WEEME Professional Hair Clippers set includes the following components:

- Hair Clipper Unit
- Electric Razor Head
- Detail Trimmer Head
- USB Charging Cable
- Multiple Length Limit Combs

- Cleaning Brush
- Lubricating Oil



Image 3.1: Overview of the WEEME Professional Hair Clippers and its components.

4. SETUP

4.1 Charging the Device

Before initial use, fully charge the hair clipper. The LED display will indicate the battery power level.

- Connect the USB charging cable to the charging port on the clipper and to a compatible USB power source.
- The LED display will show the charging progress.
- A full charge typically takes approximately 1.5 to 2 hours, providing 120-180 minutes of run time.



Image 4.1: Illustration of charging time (120 minutes) and running time (200 minutes) for the clippers.

4.2 Attaching Limit Combs

Select the appropriate limit comb for your desired hair length. The combs are designed for easy installation and disassembly.

- Ensure the clipper is turned off.
- Align the chosen limit comb with the clipper blade.
- Gently push the comb until it clicks securely into place.
- To remove, gently pull the comb away from the blade.



Image 4.2: Display of various length limit combs (1.5mm to 13mm) and their attachment mechanism.

5. OPERATING INSTRUCTIONS

5.1 General Operation

- Ensure the hair clipper is fully charged.
- Select and attach the desired blade head (clipper, trimmer, or shaver) and any necessary limit combs.
- Press the power button to turn on the device. The LED display will show the current battery level and speed setting.
- Adjust the blade settings or speed as needed using the controls on the device.
- Guide the clipper smoothly through hair or over the skin, moving against the direction of hair growth for best results.
- After use, turn off the device and clean it as described in the Maintenance section.



Hair Clipper



Hair Sculpting



Beard Shaving

Image 5.1: Examples of the device being used for hair clipping, hair sculpting, and beard shaving.

5.2 Key Features

- **Adjustable Tooth Spacing:** The blades feature adjustable tooth spacing for precise cutting lengths, ranging from 0.05 inches (1.5mm) to 0.17 inches (4.5mm) without a comb.
- **Stainless Steel Cutter Head:** Equipped with a durable stainless steel cutter head for efficient and precise cutting.
- **Rounded Tip:** The blade tips are rounded to prevent skin irritation during use.
- **High-Speed Motor:** A powerful motor ensures consistent performance through various hair types.
- **LED Display:** Provides real-time information on battery status and operational speed.



Image 5.2: Detailed view of the clipper highlighting features such as rounded blade tips, stainless steel cutter head, high-speed motor, and LED display.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your WEEME Hair Clippers.

- **Cleaning:** After each use, turn off the clipper and detach any limit combs. Use the provided cleaning brush to remove hair clippings from the blades and the device body.
- **Lubrication:** Periodically apply a small drop of lubricating oil (included) to the blades to maintain smooth operation and prevent rust. Turn on the clipper for a few seconds to distribute the oil.
- **Storage:** Store the clipper in a dry, cool place, away from direct sunlight and moisture.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Charge the device when the LED display indicates low power.

7. TROUBLESHOOTING

- If you encounter any issues with your WEEME Hair Clippers, refer to the following common problems and solutions:
- **Clipper not turning on:** Ensure the device is fully charged. If the battery is low, connect it to the charger.
 - **Reduced cutting performance:** Clean the blades thoroughly to remove any trapped hair. Apply lubricating oil to the blades. Ensure the blades are not damaged.
 - **Device making unusual noise:** Clean and lubricate the blades. If the noise persists, discontinue use and contact customer support.
 - **Battery not charging:** Check the USB cable and power adapter for damage. Ensure the charging port is clean and free of debris.

8. SPECIFICATIONS

Feature	Specification
Brand	WEEME
Model Number	HL06SL
Power Mode	USB Charging
Operating Voltage	≤36V
Battery Type	Rechargeable Lithium-Ion Battery (3 included)
Charging Time	Approx. 1.5 - 2 Hours
Run Time	120-180 Minutes
Blade Material	Stainless Steel
Included Components	Hair Clipper, Razor, Trimmer, Limit Combs, USB Cable, Cleaning Brush, Oil
UPC	762730236943

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact WEEME customer service through your retailer or the official WEEME website. Please have your model number (HL06SL) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question