

[Manuals.plus](#) /

› [LEDIARY](#) /

› LEDIARY 42-Inch Retractable Ceiling Fan with Lights (Model: d32f18b0-6c6b-444c-b4a9-34d8d00c74d8)

LEDIARY d32f18b0-6c6b-444c-b4a9-34d8d00c74d8

LEDIARY 42-Inch Retractable Ceiling Fan with Lights

Model: d32f18b0-6c6b-444c-b4a9-34d8d00c74d8

1. INTRODUCTION

Thank you for purchasing the LEDIARY 42-inch Retractable Ceiling Fan with Lights. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read it thoroughly before installation and keep it for future reference.



Image 1.1: The LEDIARY 42-inch retractable ceiling fan with integrated lighting and remote control.

This ceiling fan features a modern design with retractable blades, adjustable color temperature (3000K-6000K), 6 fan speeds, and a reversible DC motor for year-round comfort. It is designed for indoor use in various rooms such as bedrooms, living rooms, and dining rooms.

2. SAFETY INFORMATION

Please observe the following safety precautions to reduce the risk of fire, electric shock, or personal injury:

- Read all instructions and safety information before installing your new fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Before installation, disconnect power by turning off the circuit breakers to the fan's electrical box.
- Ensure the installation site allows the fan blades to rotate without obstruction.

- The outlet box and support structure must be securely mounted and capable of reliably supporting a minimum of 35 lbs (15.9 kg).
- Do not operate the fan if any part is damaged.
- Do not insert objects into the path of the fan blades.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Ceiling Fan Motor Assembly
- Lampshade with Integrated LED Lights
- Retractable Fan Blades (pre-attached to motor assembly)
- Canopy
- Downrods (5-inch and 10-inch options)
- Remote Control
- Mounting Bracket
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

2 Mount Options




Image 3.1: Detailed display of key components including the lampshade, fan blade, two downrod options (5" and 10"), and the canopy.

4. INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before beginning installation.

4.1 Mounting Options

This fan supports both flat and sloped ceiling installations. Ensure your ceiling can support the fan's weight and that the mounting bracket is securely fastened.

Multi-Functional Ceiling Fan with Simple Remote Control



6 Fan Speeds



Reverse Motor



Timer Setting



Image 4.1: The fan can be installed on both flat ceilings and sloped ceilings (up to 15 degrees).

4.2 Downrod Selection

Two downrod lengths (5-inch and 10-inch) are provided to accommodate different ceiling heights. Choose the appropriate length for optimal airflow and aesthetic appeal.



Product Size

2 Downrod Options



Sloped Ceiling Adaptable



Room Size: 100~144sqft



Image 4.2: Product dimensions and available downrod lengths. The fan is adaptable for sloped ceilings.

4.3 General Installation Steps (Summary)

1. Secure the mounting bracket to the ceiling electrical box.
2. Assemble the downrod with the canopy and motor assembly.

3. Hang the fan assembly onto the mounting bracket.
4. Connect electrical wires according to the wiring diagram (refer to detailed diagram in separate installation guide).
5. Secure the canopy to cover the wiring.
6. Install the lampshade.
7. Restore power and test the fan and light functions.

5. OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan is controlled by the included remote control. Ensure the remote has batteries installed.



Image 5.1: The multi-functional remote control for the ceiling fan, detailing buttons for fan speeds, reverse motor, and timer settings.

5.1 Light Control

- **Light ON/OFF Button:** Press to turn the light on or off.
- **Color Temperature Adjustment:** With the light on, press the 'Light ON/OFF' button repeatedly to cycle through the three color temperatures: 3000K (Warm White), 4000K (Cool White), and 6000K (Clear White).



Image 5.2: The fan light offers three adjustable color temperatures: 3000K (Warm White), 4500K (Cool White), and 6000K (Clear White).

5.2 Fan Speed Control

Use the speed buttons (1-6) on the remote control to adjust the fan's rotation speed.

- **Speeds 1-2:** Soft Wind, ideal for sleeping.
- **Speeds 3-4:** Natural Wind, suitable for reading or light activity.
- **Speeds 5-6:** Cool Wind, for maximum airflow.




Image 5.3: The fan offers 6 adjustable speeds, categorized for different comfort levels from soft to cool wind.

5.3 Reversible Motor Function

The fan features a reversible DC motor, allowing for both summer and winter operation.

- **Summer Mode (Forward Airflow):** Blades rotate counter-clockwise, pushing air downwards to create a cooling effect.
- **Winter Mode (Reverse Airflow):** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling.



Image 5.4: Reversible air circulation for optimal comfort in both summer and winter seasons.

5.4 Timer Setting

Use the timer buttons (1H, 2H, 4H) on the remote control to set the fan to automatically turn off after a specified duration.




Image 5.5: Timer settings allow the fan to operate for 1, 2, or 4 hours before automatically shutting off.

5.5 Retractable Blades

The fan blades automatically extend when the fan is turned on and retract when the fan is turned off, providing a sleek appearance when not in use.

Ceiling Fans with Lights

Changeable Shape & Retractable Ceiling Fan

Fan OFF



Canopy

Fan ON



Fan Blade

Image 5.6: The fan blades retract when the fan is off and extend when the fan is operating.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is disconnected before cleaning.
- **Blade Cleaning:** Gently wipe the fan blades with a soft cloth to remove dust.
- **Light Fixture:** Clean the lampshade with a soft, dry cloth.
- **Tighten Fasteners:** Periodically check all screws and fasteners for tightness.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan Loose wire connections Remote control battery low/dead	Check circuit breaker and wall switch Verify all wire connections are secure (power off first) Replace remote control batteries
Light does not work	No power to the light Loose wire connections LED driver issue	Check circuit breaker and wall switch Verify light wire connections (power off first) Contact customer support
Fan wobbles	Loose mounting screws Unbalanced blades	Ensure all mounting screws are tight Check for bent blades or uneven installation
Remote control not working	Batteries are dead or incorrectly inserted Remote not paired (if applicable)	Replace batteries, ensure correct polarity Refer to remote pairing instructions (if provided separately)

If the problem persists after attempting these solutions, please contact LEDIARY customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	LEDIARY
Model Name	d32f18b0-6c6b-444c-b4a9-34d8d00c74d8
Size	42 Inch
Color	Gold
Product Dimensions	21.6"D x 21.6"W x 12.6"H
Power Source	DC
Number of Blades	3 (Retractable)
Number of Power Levels	6 Fan Speeds

Feature	Detail
Light Color Temperature	3000K / 4000K / 6000K (Adjustable)
Control Method	Remote Control
Special Features	Adjustable Color Temperature, Adjustable Height (Downrods), Energy Efficient DC Motor, Portable, Timer, Reversible Motor
Room Type Recommendation	Bedroom, Dining Room, Kitchen, Living Room, Study Room
Installation Type	Flush Mount (with downrod options)
Item Weight	18.91 pounds

9. WARRANTY AND SUPPORT

LEDIARY offers a **2-year after-sales support** for this product. If you encounter any issues during purchase, installation, or operation, please do not hesitate to contact our customer service team.

Customer Support:

For technical assistance, warranty claims, or general inquiries, please refer to the contact information provided with your purchase or visit the official LEDIARY website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question