

KPAW X1

KPAW X1 Automatic Card Shuffler

Model: X1 | Brand: KPAW

Your guide to effortless and efficient card shuffling.

INTRODUCTION

The KPAW X1 Automatic Card Shuffler is designed to provide a convenient, hands-free, and efficient shuffling experience for various card games. Its innovative features ensure smooth operation and compatibility with different card sizes, making it an essential tool for any card game enthusiast. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you get the most out of your device.



Image: The KPAW X1 Automatic Card Shuffler actively shuffling cards, demonstrating its primary function.

WHAT'S IN THE BOX

Upon unboxing your KPAW X1 Automatic Card Shuffler, please ensure all the following items are present:

- Card Shuffler
- 1 × Charging Cable (USB-C)
- 1 × User Manual
- 1 × Packaging Box

SETUP

Initial Charging

The KPAW X1 features a built-in rechargeable battery for ultimate convenience. Before first use, or when the battery is low, charge the device using the provided USB-C cable.

1. Locate the USB-C charging port on the shuffler.
2. Connect the provided USB-C cable to the shuffler and a compatible power source (e.g., USB wall adapter, computer USB port).
3. The light indicator on the charging port will turn RED while charging and GREEN when fully charged.
4. **Important Note:** This automatic card shuffler cannot operate while charging. Please do NOT use it during charging.

ULTRA-LONG BATTERY LIFE

Meet Long-Term Wireless Use




Image: Detailed view of the shuffler's underside, highlighting the USB-C charging port and internal battery.

Card Placement

The shuffler is designed to accommodate 1-2 decks of cards. Its retractable wings allow for various

card sizes.

1. Adjust the retractable wings by pushing or pulling them to fit your card size.
2. Divide your deck(s) into two roughly equal halves.
3. Place one half of the cards into each side tray of the shuffler. Ensure cards are neatly stacked and facing the correct direction for shuffling.

RETRACTABLE WING

Work for Various Size of Cards



Image: Illustration of the retractable wings, demonstrating how they adjust to fit various card sizes like Regular, Texas Hold'em, UNO, Mahjong, and Gaming cards.

OPERATING INSTRUCTIONS

One-Press AUTO Shuffling

The KPAW X1 features a smart sensor that automatically detects cards and stops shuffling once completed, eliminating the need to hold down the button.

1. Ensure cards are properly placed in both side trays as described in the Setup section.
2. Press the **AUTO** button once. The shuffler will begin processing the cards.
3. The built-in smart sensor will detect when all cards have been shuffled and automatically stop the machine.
4. Collect the shuffled cards from the bottom tray.

FULL AUTOMATION

Easily One Press to Initiate and Automatically Stop with the Intelligent Sensor



AUTO

Built-in **KPAW Infrared Sensor** accurately stops shuffling.

Have to hold until completed

Image: A hand pressing the AUTO button on the shuffler, illustrating the one-press automatic shuffling feature.

Manual Mode

For more control, you can use the manual shuffling mode.

- Place cards in the side trays.
- Press and hold the **Manual** button. The shuffler will operate as long as the button is held down.
- Release the button to stop shuffling.

Versatile Compatibility

The KPAW X1 is designed to work with various card sizes, from standard poker and bridge cards to UNO and Mahjong cards. The innovative retractable wings ensure a snug fit and smooth operation for different dimensions.

INNOVATIVE SUSPENSION NEEDLE

No More Hassle from Spilling Cards



Image: The shuffler's internal mechanism, showing the stainless steel suspension needle that synchronizes with the retractable wings to organize cards and prevent spilling during shuffling.

Low Noise Operation

Engineered for a quieter gaming experience, the KPAW X1 operates with significantly less noise compared to many other shufflers, allowing for a more focused and enjoyable game night.

SMOOTH & LOW-NOISE

Quieter than Most for a
More Enjoyable Game Experience



Image: A family enjoying a card game with the KPAW X1 shuffler in the foreground, emphasizing its quiet operation compared to other shufflers.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from KPAW Gaming Tech. demonstrating the features and operation of the KPAW X1 Automatic Card Shuffler.

MAINTENANCE

To ensure the longevity and optimal performance of your KPAW X1 Automatic Card Shuffler, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe the exterior of the shuffler with a soft, dry cloth. For stubborn dirt, a

slightly damp cloth can be used, but ensure no moisture enters the internal mechanisms.

- **Card Quality:** Use clean, undamaged cards. Dirty, bent, or sticky cards can affect shuffling performance and potentially damage the shuffler's internal components.
- **Storage:** When not in use, store the shuffler in a dry, cool place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your KPAW X1 Automatic Card Shuffler, please refer to the following common problems and their solutions:

- **Shuffler not turning on or operating:**
 - Ensure the device is fully charged. Check the charging indicator light (RED for charging, GREEN for fully charged).
 - Remember, the shuffler cannot operate while it is charging. Disconnect the charging cable before use.
- **Cards getting stuck or jamming during shuffling:**
 - Ensure the cards are neatly stacked and evenly divided in the side trays. Uneven stacks can cause jams.
 - Check the condition of your cards. Worn, bent, or sticky cards are more prone to jamming. Replace damaged cards if necessary.
 - Verify that the retractable wings are properly adjusted for the size of your cards.
 - If a jam occurs, gently remove the cards and re-align them before attempting to shuffle again.
- **Shuffling is not thorough:**
 - For a more randomized shuffle, run the cards through the shuffler multiple times (e.g., 2-3 times).

SPECIFICATIONS

| | |
|--------------------|----------------------------------|
| Product Name | Automatic Card Shuffler |
| Model Number | X1 |
| Product Dimensions | 6.6 x 4.7 x 3.1 inches |
| Item Weight | 11.2 ounces |
| Battery Type | 1 Lithium Ion battery (included) |
| Battery Capacity | 2000mAh |

| | |
|-------------------|---------|
| Charging Port | USB-C |
| Material | ABS/POM |
| Country of Origin | China |
| Manufacturer | KPAW |

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your KPAW X1 Automatic Card Shuffler, please refer to the contact information provided on the product packaging or visit the official KPAW website. Keep your purchase receipt as proof of purchase for warranty claims.

Patent Product - All Rights Reserved.