

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RisoPhy](#) /

› [RisoPhy Gaming Keyboard User Manual](#)

RisoPhy B0D7HCZSRP

RisoPhy Gaming Keyboard User Manual

Model: B0D7HCZSRP

INTRODUCTION

Welcome to your new RisoPhy Gaming Keyboard. This manual provides essential information for setup, operation, and maintenance of your 104-key, all-metal panel, rainbow LED backlit keyboard. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

- RisoPhy Gaming Keyboard
- Integrated USB Cable

SETUP

The RisoPhy Gaming Keyboard is designed for plug-and-play simplicity, requiring no additional software installation.

- Locate an available USB-A port on your computer (PC, Mac, Gaming Console, Laptop, Xbox).
- Connect the integrated USB cable from the keyboard to the USB-A port.
- The operating system will automatically detect and configure the keyboard.



Image: The RisoPhy Gaming Keyboard, a black 104-key wired keyboard with rainbow LED backlighting, connected via its USB cable.

OPERATING INSTRUCTIONS

Backlight Control

The keyboard features vibrant rainbow LED backlighting with adjustable modes and brightness levels.

- **Key:** Press this key (often located near the top right) to cycle through static backlight, dynamic backlight, or turn off the backlight.
- **Fn + PgUp:** Increase backlight brightness.
- **Fn + PgDn:** Decrease backlight brightness.
- **Fn + +/-:** Adjust the speed of the dynamic backlight effect.

Note: The backlighting is a fixed rainbow color spectrum and does not support individual key RGB customization.

LIGHT UP YOUR GAMING AREA



Image: The Risophy Gaming Keyboard illuminated with vibrant rainbow backlighting, showcasing its two backlit modes and adjustable brightness.

Multimedia Keys

Access common multimedia functions quickly using the Fn key in combination with the F-keys.

Function Key	Action
Fn + F1	Media Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Stop
Fn + F6	Previous Track

Function Key	Action
Fn + F7	Play/Pause
Fn + F8	Next Track
Fn + F9	Email
Fn + F10	Web Browser
Fn + F11	My Computer
Fn + F12	Calculator

Note: Multimedia keys might not work on Mac operating systems.

Gaming Features

- **19-Key Anti-Ghosting:** Ensures all key presses are registered accurately, even during rapid, simultaneous inputs, preventing missed commands.
- **WSAD and Arrow Key Swap:** Press Fn + W to swap the functionality of the WSAD keys with the arrow keys. Press again to revert.
- **Windows Key Lock:** Press Fn + Win to lock or unlock the Windows key, preventing accidental interruptions during gaming sessions.

19 KEY ANTI-GHOSTING




Image: A visual representation of the 19-key anti-ghosting feature, along with instructions for swapping WSAD and arrow keys, and locking the Windows key.

DESIGN AND DURABILITY

- All-Metal Panel:** The keyboard features a robust aluminum alloy shell, enhancing both its aesthetic appeal and structural integrity.
- Ergonomic Wrist Rest:** An integrated wrist rest combined with a 7° typing angle provides natural hand positioning, reducing strain during prolonged use.
- Spill-Resistant Design:** Equipped with 4 drainage holes on the underside, the keyboard is designed to protect against damage from accidental liquid spills.
- Durable Keycaps:** The laser-etched keycaps are fade-proof, ensuring legends remain clear and visible over time.
- Long Lifespan:** Constructed with a classic crater structure, this keyboard is built to withstand approximately 50 million keystrokes.

COMFORTABLE TYPING EXPERIENCE



Foldable Kickstands



Stepped Key-layout



Integrated Wrist Rest




Image: The keyboard viewed from the side, illustrating the integrated wrist rest and the ergonomic 7-degree typing angle for comfortable use.

SPILL-RESISTANT DESIGN



Image: An overhead view of the keyboard with a close-up inset showing the non-fading keycaps and metallic frame, along with an illustration of the 4 drainage holes on the underside for spill resistance.

MAINTENANCE

To ensure the longevity and optimal performance of your Risophy Gaming Keyboard, follow these maintenance guidelines:

- Cleaning:** The keycaps are removable for easy cleaning. Use a soft, damp cloth to wipe down the surface of the keyboard. For deeper cleaning, carefully remove keycaps and clean underneath with compressed air or a small brush. Always ensure the keyboard is disconnected from your computer before cleaning.
- Spill Management:** In case of accidental liquid spills, immediately disconnect the keyboard from your computer. Turn it upside down to allow liquid to drain through the integrated drainage holes. Allow the keyboard to dry completely before reconnecting it.




Image: Several keycaps are shown detached from the keyboard, demonstrating their removability for cleaning and maintenance.

TROUBLESHOOTING

If you encounter any issues with your RisoPhy Gaming Keyboard, please refer to the following common troubleshooting steps:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and the computer's USB port.
 - Try connecting the keyboard to a different USB port on your computer.
 - Restart your computer to refresh the USB connections.
- **Backlight Not Working:**
 - Press the  (light bulb) key to cycle through backlight modes and ensure it is not turned off.
 - Adjust brightness levels using Fn + PgUp and Fn + PgDn.
- **Multimedia Keys Not Functioning (Mac):**

- As noted in the Operating Instructions, some multimedia keys may not be fully compatible with Mac operating systems. This is expected behavior.

- Keys Sticking or Not Registering:**

- Check for any debris or foreign objects under the keycaps. Clean the keyboard as described in the Maintenance section.
- Ensure the anti-ghosting feature is not being inadvertently affected by other software or settings.

Your browser does not support the video tag.

Video: An unboxing and initial overview of the RisoPhy Wired Keyboard, demonstrating its basic features and quiet key presses. This video can help users understand the physical aspects and initial setup.

SPECIFICATIONS

Feature	Detail
Brand	RisoPhy
Model	B0D7HCZSRP
Product Dimensions	17.2 x 7.3 x 1.97 inches
Item Weight	2.33 pounds
Connectivity Technology	USB-A (Wired)
Number of Keys	104
Keyboard Description	Gaming
Special Features	Backlit, Ergonomic, Integrated Stand, Waterproof, Wrist Rest
Compatible Devices	Gaming Console, Laptop, Mac, PC, Xbox
Keyboard Backlighting Color Support	Rainbow (Note: Not RGB)
Manufacturer	RisoPhy
Date First Available	June 19, 2024

WARRANTY AND SUPPORT

RisoPhy is committed to providing high-performance products and ensuring a positive customer experience. For any assistance, inquiries, or support regarding your RisoPhy Gaming Keyboard, please contact our customer service team.

You can reach customer service through the following methods:

- Via Product Page:** Click on the seller's name (JHJVH TECH STORE) on the product page and send us a message directly.
- Via Order History:** Navigate to your order history, click on the RisoPhy product, and then click on the store name to send us a message.

We strive to provide a prompt and satisfactory response to all customer needs.

[Visit the Official RisoPhy Store for more information and products.](#)




Image: A graphic illustrating contact options for customer support, including direct messaging through the seller or brand store.

Related Documents - B0D7HCZSRP

	<p><u>Mechanical Gaming Keyboard User Manual</u></p> <p>User manual for the RisoPhy Mechanical Gaming Keyboard, detailing setup, multimedia functions, lighting effects, macro recording, and disposal instructions.</p>
	<p><u>RisoPhy Wireless Mechanical Gaming Keyboard User Manual</u></p> <p>Comprehensive user manual for the RisoPhy Wireless Mechanical Gaming Keyboard, detailing setup, features, troubleshooting, and usage for 2.4G, Bluetooth, and wired modes.</p>