



[Manuals.plus](#) /

› [SMARTSTANDARD](#) /

› SMARTSTANDARD 34" x 84" White Sliding Barn Door with 6FT Black Hardware Instruction Manual

SMARTSTANDARD BDM-34H-KIT-WT

SMARTSTANDARD 34" x 84" White Sliding Barn Door with 6FT Black Hardware Instruction Manual

Model: BDM-34H-KIT-WT

INTRODUCTION

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your SMARTSTANDARD 34" x 84" White Sliding Barn Door with 6FT Black Hardware. Please read all instructions carefully before beginning installation to ensure safe and proper setup.



Image: The SMARTSTANDARD 34" x 84" White Sliding Barn Door with 6FT Black Hardware installed, showcasing its modern design and functionality.

The door is constructed from primed MDF and PVC, offering a flat, smooth, and sturdy design that resists bending. It features a waterproof and scratch-resistant PVC coating for enhanced durability and easy cleaning. The door comes pre-drilled for hangers and handles, and includes a pre-made groove for the floor guide.

SAFETY INFORMATION

- Always wear appropriate safety gear, including gloves and eye protection, during assembly and installation.
- Ensure the wall structure can support the weight of the barn door and hardware. Consult a professional if unsure.
- Use proper lifting techniques. The door can be heavy; two people are recommended for lifting and positioning.
- Keep children and pets away from the work area during installation.
- Verify all components are present and undamaged before starting assembly.

PACKAGE CONTENTS

Before starting, ensure all parts listed below are present in your package.



Image: All included components: door slats, sliding hardware kit, handle, floor guide, installation tools, and detailed instructions.

- MDF Barn Door Slats (Assembly Required)
- Sliding Hardware Kit (Track, Hangers, Spacers, Stops, Anti-Jump Disks)
- 12-inch Double-sided Handle
- Wall-mounted Floor Guide
- T-Shape Floor Guide
- Installation Tools (Hex Key)
- Detailed Instructions (This manual)

SETUP AND INSTALLATION

The SMARTSTANDARD barn door is designed for easy assembly and installation. Follow these steps carefully.

1. Door Assembly

The barn door comes as individual slats for better transportation. Assemble the door slats according to the provided diagrams. Ensure all pre-drilled holes align correctly for the top, bottom, and middle rails, and side slats.



Image: Door dimensions (34" width, 84" height, 1 3/8" thickness) and a visual representation of the slat assembly process.

2. Wall Preparation and Track Installation

Measure and mark the installation points on your wall. A minimum of 6 inches clearance is needed above the top of the door. The track length for this model is 6 feet. Ensure the track is level and securely mounted to wall studs or appropriate anchors.



Image: Essential measurements for installation, including 6" clearance above the door and fixed distances from wall holes to floor (85 11/16") and door to wall (1 3/8").

3. Hanger and Handle Installation

Attach the hangers to the top of the assembled door using the pre-drilled holes. Install the double-sided handle on the door, again utilizing the pre-drilled holes for a secure fit.

4. Mounting the Door to the Track

Carefully lift the door and hook the hangers onto the installed track. Install the anti-jump disks on the top edge of the door to prevent it from lifting off the track. Position the door stops at the desired open and closed positions on the track.

5. Floor Guide Installation

Install the floor guide (either wall-mounted or T-shape) to keep the bottom of the door stable and prevent it from swinging out. The door has a pre-made groove at the bottom designed to work with the floor guide.

Installation Overview Video

Your browser does not support the video tag.

Video: "How to Install SMARTSTANDARD Barn Door and Hardware Kit" - A step-by-step guide to assembling and installing your barn door and hardware.

OPERATING INSTRUCTIONS

To open or close the barn door, gently grasp the handle and slide the door along the track. The hangers are designed to glide smoothly and quietly. The floor guide will keep the bottom of the door aligned during movement.

- Avoid forcing the door if it encounters resistance. Check for obstructions on the track or floor guide.
- Ensure the door stops are correctly positioned to prevent the door from sliding too far.

CARE AND MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your barn door.



Image: The door's high-quality PVC coating provides waterproof, scratch-resistant, and easy-to-clean properties.

- **Cleaning:** Wipe the door surface with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that could damage the PVC coating.
- **Track and Rollers:** Periodically inspect the track and rollers for any debris or dust. Clean them with a dry cloth to ensure smooth gliding. Lubricate rollers if necessary with a silicone-based lubricant.
- **Hardware:** Check all screws and bolts on the hangers, handle, and track for tightness. Retighten if any are loose.
- **Floor Guide:** Ensure the floor guide is free of obstructions and properly aligned with the door's groove.

TROUBLESHOOTING

If you encounter issues with your barn door, refer to the following common solutions:

Problem	Possible Cause	Solution
Door does not slide smoothly	Debris on track, loose rollers, misaligned floor guide.	Clean track and rollers. Tighten roller bolts. Realign floor guide.
Door rubs against wall or floor	Incorrect wall spacing, misaligned track, or floor guide.	Verify wall spacing (1 3/8" fixed distance). Check track levelness and adjust floor guide.
Door feels wobbly	Loose hangers or track mounting bolts.	Ensure all hanger and track mounting bolts are securely tightened.
Door does not stay in open/closed position	Door stops are not properly positioned or tightened.	Adjust and tighten the door stops on the track.

If the problem persists, please contact customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	BDM-34H-KIT-WT
Door Dimensions (W x H)	34 inches x 84 inches
Door Thickness	1 3/8 inches
Solid Core Thickness	1/2 inch
Track Length	6 feet
Material	Primed MDF & PVC Coating
Color	White Door, Black Hardware
Assembly Required	Yes
Features	Waterproof, Scratch-resistant, Non-bending, Pre-drilled for hardware

WARRANTY INFORMATION

SMARTSTANDARD products are manufactured to high-quality standards. For specific warranty details regarding your barn door and hardware, please refer to the warranty card included in your package or contact SMARTSTANDARD customer service directly. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report missing/damaged parts, please contact SMARTSTANDARD customer support:

- **Online Support:** Visit the [SMARTSTANDARD Store on Amazon](#) for FAQs and additional resources.
- **Email:** Refer to your product packaging or the SMARTSTANDARD website for the most current contact email.
- **Phone:** Refer to your product packaging or the SMARTSTANDARD website for the most current contact phone number.

Please have your model number (BDM-34H-KIT-WT) and purchase date ready when contacting support.