

[Manuals.plus](#) /

› [COMFIER](#) /

› COMFIER Cordless Knee Massager CF-5320 User Manual

COMFIER CF-5320

COMFIER Cordless Knee Massager CF-5320 User Manual

Model: CF-5320

1. INTRODUCTION

Thank you for choosing the COMFIER Cordless Knee Massager CF-5320. This device is designed to provide targeted heat and vibration massage to the knee area, and can also be used on elbows and shoulders. Please read this manual thoroughly before use to ensure proper operation and safety.



Image 1.1: The COMFIER Cordless Knee Massager CF-5320, highlighting its heat and vibration features.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings before using this product.

- Do not use on broken or irritated skin.
- Avoid use during pregnancy.
- Do not use for extended periods without consulting a healthcare professional.
- Keep out of reach of children.
- Consult your doctor before use if you have any pre-existing medical conditions, are using medical devices, or are unsure about suitability.
- Do not immerse the device in water or use it in excessively humid environments.
- Use only the provided charging cable.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- COMFIER Cordless Knee Massager Unit
- Adjustable Knee Straps (18.9 inches)
- USB Charging Cable
- User Manual

4. PRODUCT OVERVIEW

The COMFIER Cordless Knee Massager features a user-friendly design with an LED screen and touch controls for easy operation.



Image 4.1: The massager in use, illustrating its multi-functionality with vibration modes and heat levels.

Components:

- **Main Unit:** Houses the control panel, heating elements, and vibration motors.
- **Control Panel:** Large LED screen with touch buttons for power, vibration, and heat settings.
- **Adjustable Straps:** Secure the massager to the knee, elbow, or shoulder.
- **Charging Port:** For connecting the USB charging cable.

5. SETUP AND CHARGING

5.1 Initial Charging

Before first use, fully charge the device. The battery indicator on the LED screen will flash during charging and remain solid when fully charged.

1. Connect the USB charging cable to the charging port on the massager.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. Allow approximately 3-4 hours for a full charge.



Image 5.1: Visual representation of the massager's battery and charging status.

5.2 Attaching the Straps

The adjustable straps allow for a secure and comfortable fit on various body parts.

1. Thread the straps through the loops on the massager unit.
2. Wrap the massager around your knee, elbow, or shoulder.
3. Secure the straps using the hook-and-loop fasteners, ensuring a snug but not overly tight fit.



Image 5.2: Detail of the adjustable straps for securing the massager.

6. OPERATING INSTRUCTIONS

The massager features an intuitive control panel for easy adjustment of settings.



Image 6.1: The control panel showing buttons for vibration and heat settings.

6.1 Power On/Off

- Press and hold the **Power Button** (usually indicated by a circle with a vertical line) to turn the device on or off.

6.2 Vibration Modes

The device offers three vibration modes to suit your preference:

- Press the **Vibration Button** (often indicated by wavy lines) to cycle through the modes:
 - **Low:** Gentle, continuous vibration.
 - **Medium:** Moderate, continuous vibration.
 - **High:** Stronger, continuous vibration.
 - **Auto:** Cycles through different vibration patterns and intensities.

6.3 Heat Levels

Three heat levels are available for soothing warmth:

- Press the **Heat Button** (often indicated by three wavy lines or a thermometer icon) to cycle through the heat settings:
 - **Low:** Approximately 105°F (40.6°C)
 - **Medium:** Approximately 122°F (50°C)
 - **High:** Up to 140°F (60°C)



Image 6.2: Illustration of the available heat levels and their temperatures.

6.4 Red Light Therapy

The device incorporates red light therapy, which operates automatically when the heat function is active.

6.5 Automatic Timer

For safety and optimal use, the massager is equipped with an automatic 10-minute shut-off timer. After 10 minutes, the device will power off automatically. You can restart it for another session if desired.



6.6 Multi-Area Application

While primarily designed for the knee, the flexible design allows for use on other areas such as the elbow and shoulder.



Image 6.4: The massager's versatility for use on knee, shoulder, and elbow.

7. MAINTENANCE

7.1 Cleaning

- Ensure the device is turned off and unplugged before cleaning.
- Wipe the surface of the massager with a soft, slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Do not immerse the device in water.

7.2 Storage

- Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the device away from sharp objects that could damage the surface or straps.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
No heat or vibration.	Function not activated or low battery.	Press the respective function button. Ensure the device is charged.
Battery indicator does not show low battery.	This model's indicator may not show gradual depletion.	Track usage time. A full charge typically provides several sessions. Charge regularly (e.g., every 4 days of typical use).
Device stops unexpectedly.	Automatic 10-minute timer activated.	Restart the device if further use is desired.

9. SPECIFICATIONS

Feature	Detail
Model Number	CF-5320
Product Dimensions	10 x 6.5 x 5 inches
Item Weight	1.79 Pounds
Battery Type	1 Lithium Ion battery (included)
Power Source	Battery Powered
Material	Polyester
Heat Levels	3 (approx. 105°F, 122°F, 140°F)
Vibration Modes	3 (Low, Medium, High, Auto)
Automatic Timer	10 minutes

10. WARRANTY AND SUPPORT

COMFIER offers a 30-day warranty for this product. If you are not satisfied or encounter any issues, you may be eligible for a replacement or refund.

For support or warranty claims, please contact COMFIER directly via Amazon email. Do not hesitate to reach out for assistance.

11. LEGAL DISCLAIMER

Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for personal comfort and relaxation purposes only.

© 2025 COMFIER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D7HNMDJ5>

More documents and user manuals: <https://manuals.plus/>