

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Greesum](#) /

› [Greesum 5-Piece Outdoor Acacia Wood Patio Dining Set \(Model LCW\) Instruction Manual](#)

Greesum LCW

Greesum 5-Piece Outdoor Acacia Wood Patio Dining Set (Model LCW)

Instruction Manual

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Greesum 5-Piece Outdoor Acacia Wood Patio Dining Set, Model LCW. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

CAUTION: This product requires assembly. Always follow the assembly instructions carefully to avoid injury. Keep sharp edges away from children and pets. Do not leave children unattended while using this product.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Square Dining Table
- 4 x Dining Chairs
- 4 x Seat Cushions
- Assembly Hardware (screws, wrench)
- Instruction Manual



Image: The complete Greesum 5-Piece Patio Dining Set, including the square table and four chairs, ready for use in an outdoor setting.

4. SETUP (ASSEMBLY INSTRUCTIONS)

Assembly of the Greesum 5-Piece Outdoor Patio Dining Set is designed to be straightforward. Please follow the steps below carefully. An Allen wrench and necessary screws are included.

4.1. Table Assembly

1. Unpack all table components and lay them out on a soft, clean surface to prevent scratches.
2. Attach the four table legs to the tabletop using the provided screws and Allen wrench. Ensure all connections are secure.
3. Carefully flip the table upright.

Video: A demonstration of the unboxing and assembly process for the patio dining table, including attaching the legs and securing components.

4.2. Chair Assembly (for each of the 4 chairs)

1. Unpack all chair components. Each chair typically consists of a seat base, backrest, and armrests/legs.
2. Connect the backrest to the seat base using the designated screws.
3. Attach the armrests/legs to the assembled seat and backrest, ensuring all screws are tightened securely.
4. Place the thick padded cushions onto the chair seats.

Video: A visual guide demonstrating the assembly of the patio dining chairs, showing how to connect the various parts and secure them.

PRODUCT DIMENSION



Table x 1



Chair x 4



29.1"



In the Yard



On the Deck



Poolside

Image: Detailed product dimensions for the table and chairs, indicating one table and four chairs are included in the set.

5. OPERATING INSTRUCTIONS

Your Greesum 5-Piece Outdoor Patio Dining Set is designed for comfortable outdoor dining and relaxation. The set is suitable for use in various outdoor environments such as yards, gardens, porches, decks, and poolside areas.

- Placement:** Position the dining set on a flat, stable surface to ensure stability.
- Cushions:** The chairs are equipped with thick padded cushions for enhanced comfort. These cushions can be removed for cleaning or storage.
- Umbrella Hole:** The table features a central hole for an umbrella (umbrella not included), providing shade on sunny days.



Image: A family enjoying a meal together at the Greesum patio dining set, highlighting its suitability for family gatherings.

6. MAINTENANCE

Proper care will extend the life and appearance of your dining set.

- **Wood Care:** Wipe the acacia wood surfaces with a dry cloth to remove dust and debris. Avoid harsh chemicals. Regular oiling may be required to maintain the wood's luster and protect it from weathering.
- **Cushion Care:** The cushions are designed with removable covers for easy cleaning. Follow the care instructions on the cushion labels. Store cushions indoors during inclement weather or prolonged periods of non-use to prevent fading and damage.
- **All-Weather Durability:** The set is made from high-quality Asian wood, designed to withstand various climates. However, prolonged exposure to extreme weather conditions (e.g., heavy rain, snow, intense sun) may require additional protective measures like furniture covers.

ACACIA WOOD QUALITY

Make furniture of higher quality



Sturdy



Easy to Clean



Weatherproof



Image: A close-up view of the acacia wood tabletop and a chair with its cushion, illustrating the material quality and design.

7. TROUBLESHOOTING

If you encounter any issues with your dining set, please refer to the following common solutions:

- Wobbling:** Ensure all screws and bolts are securely tightened. Adjust the leveling feet (if present) on uneven surfaces.
- Loose Parts:** Periodically check and tighten all fasteners to maintain structural integrity.
- Wood Discoloration:** Exposure to elements can cause natural wood to change color over time. Regular maintenance with wood oil can help preserve its original appearance.

8. SPECIFICATIONS

Brand	Greesum
Model Number	LCW
Set Name	5 Piece Patio Dining Set
Material	Acacia Wood

Color	White
Product Dimensions (L x W x H)	21.65 x 19.68 x 33 inches
Item Weight	58.4 pounds
UPC	760606059535
Product Care Instructions	Wipe with Dry Cloth

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Greesum 5-Piece Outdoor Patio Dining Set, please contact Greesum customer service. Specific warranty details may vary; please refer to your purchase documentation for complete information.

Customer Support is available to assist you with any product-related inquiries.

Related Documents - LCW

 <p>Greesum Patio Furniture Set: Parts List and Assembly Instructions</p> <p>Comprehensive guide for assembling your Greesum patio furniture set. Includes a detailed parts list for the chair and coffee table, along with step-by-step assembly instructions.</p>	
 <p>Greesum Brown 4-Piece Wicker Outdoor Patio Furniture Set Assembly and Care</p> <p>Comprehensive guide for the Greesum 4-Piece Wicker Outdoor Patio Furniture Set, covering assembly instructions, parts list, usage, care, and warranty information for outdoor living spaces.</p>	
 <p>Руководство по эксплуатации часов Casio модуль 5161</p> <p>Полное руководство пользователя для часов Casio с модулем 5161, охватывающее настройку времени, мировое время, будильники, водонепроницаемость, калибровку и технические характеристики.</p>	

User Manual of Product 1:
Shintenchi 4 Piece Outdoor Wicker Furniture Sets, Small Wicker
Patio Conversation Furniture Sets, 4 Piece Wicker Furniture Set with Tempered
Glass Coffee Table For Backyard Porch Garden Products
Brands: Shintenchi

User Manual of Product 2:
Greensum 3 Piece Patio Furniture Set, Outdoor Wicker Chair
Conversation Set, Brown and Beige, 26.8x12.1x19.3 Inches

[Shintenchi & Greesum Patio Furniture Assembly Manual | Wicker Rattan Sets](#)

Comprehensive assembly instructions for Shintenchi 4-piece and Greesum 3-piece outdoor patio furniture sets, including wicker rattan chairs and coffee tables. Detailed parts lists, step-by-step diagrams, and safety warnings for easy setup.