

t215

JMMO Gadgetgyz T215 Wireless Hi-Fi Stereo Earbuds

User Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your JMMO Gadgetgyz T215 Wireless Hi-Fi Stereo Earbuds. Please read this manual thoroughly before using the product to ensure proper function and to extend the lifespan of your device.

SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, direct sunlight, or fire.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble, repair, or modify the product yourself. This may void the warranty and cause damage.
- Keep the device away from water and liquids, although it has an IPX4 rating, prolonged submersion is not recommended.
- Use only the provided charging cable or a certified equivalent.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.

PACKAGE CONTENTS

Please check the package for the following items:

- 2 x JMMO T215 Earbuds (Left and Right)
- 1 x Charging Case
- 1 x Charging Cable
- 1 x User Manual (This document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your JMMO T215 Earbuds and charging case.



Image: The JMMO T215 earbuds resting inside their open charging case. The earbuds are black, and the case is also black with a small green indicator light visible, showing the charging status.

- **Earbuds:** Left and Right earbuds with touch control areas.
- **Charging Case:** Stores and charges the earbuds, also acts as a power bank for the earbuds.
- **Charging Port:** Located on the charging case for connecting the charging cable.
- **LED Indicator:** On the charging case and earbuds to show charging status and connection status.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the charging case and earbuds.

1. Connect the provided charging cable to the charging port on the case and to a USB power source.
2. The LED indicator on the case will show charging status. It will typically turn solid or off when fully charged.
3. Place the earbuds into the charging case. Ensure they are correctly seated; the earbuds' indicators will light up to show they are charging.
4. A full charge provides approximately 4 hours of playtime for the earbuds, with the charging case providing an additional 10 hours (total 14 hours).



Image: A diagram illustrating the battery life of the earbuds. It shows "4 Hrs Playtime" for the earbuds themselves and "14 Hrs With Charging Case", indicating the total listening time with recharges from the case.

2. Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their LED indicators will flash.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "JMMO T215" or "Gadgetgyz T215" in the list of available Bluetooth devices.
5. Select "JMMO T215" to connect. Once connected, the earbud indicators will stop flashing.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

The JMMO T215 earbuds feature touch controls for various functions.



Image: A visual guide to the touch controls on the earbuds. It shows icons for single click, double click, triple click, long press for 2 seconds, and long press for 5 seconds, along with their corresponding functions.

Power On/Off

- **Power On:** Open the charging case, or long press the MFB (Multi-Function Button) on either earbud for 2 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long press the MFB on either earbud for 5 seconds.

Music Playback Controls

- **Play/Pause:** Single click the MFB on either earbud.
- **Next Track:** Double click the MFB on the *right* earbud.
- **Previous Track:** Double click the MFB on the *left* earbud.
- **Volume Up:** Triple click the MFB on the *right* earbud.
- **Volume Down:** Triple click the MFB on the *left* earbud.

Call Management

- **Answer/End Call:** Single click the MFB on either earbud.
- **Reject Call:** Long press the MFB on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant (Siri, Google Assistant):** Long press the MFB on either earbud for 2 seconds (when not on a call).



Image: A graphic illustrating "ADVANCED SWITCHING" with two earbuds and a double-headed arrow between them, signifying smooth playback transition between the left and right earbuds.

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.

Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and humidity.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not charging	<ul style="list-style-type: none">• Ensure the charging cable is securely connected to both the case and the power source.• Check if the charging contacts on the earbuds and inside the case are clean and free of debris.• Try a different charging cable or power adapter.

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on your device. • Make sure the earbuds are out of the charging case and in pairing mode (LEDs flashing). • Forget "JMMO T215" from your device's Bluetooth list and try pairing again. • Restart your device and the earbuds.
No sound or low volume	<ul style="list-style-type: none"> • Increase the volume on both your device and the earbuds. • Ensure the earbuds are properly connected to your device. • Check if the earbuds are clean and free of earwax buildup.
One earbud not working	<ul style="list-style-type: none"> • Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. • Ensure both earbuds are charged. • Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, a full re-pairing often resolves this).

SPECIFICATIONS

Model Name:	T215 (tws)
Connectivity:	Wireless (Bluetooth)
Form Factor:	In Ear
Colour:	Black
Special Features:	Fast Charging, Microphone Included
Waterproof Rating:	IPX4 (Sweat and splash resistant)
Playtime (Earbuds):	Up to 4 hours
Total Playtime (with Case):	Up to 14 hours
Included Components:	2 x Earbuds, 1 x Charging Case, 1 x Charging Cable, 1 x User Manual



Image: A detailed cutaway diagram of an earbud's internal speaker components, highlighting a 13mm composite diaphragm dynamic speaker for superior sound quality.

WARRANTY AND SUPPORT

The JMMO Gadgetgыз T215 Earbuds come with a manufacturer's warranty of 1 year from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

For warranty claims or technical support, please contact the seller or refer to the purchase platform for contact information. Please have your proof of purchase ready.

Spare part information is not available or provided by the manufacturer.