

[Manuals.plus](#) /

› [KAFF](#) /

› KAFF PRESTON PRS 783 Built-in Hob Instruction Manual

KAFF PRS 783

KAFF PRESTON PRS 783 Built-in Hob Instruction Manual

Model: PRS 783

1. SAFETY INFORMATION

Please read all instructions carefully before installing or using this appliance. Keep this manual for future reference. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- **Gas Safety:** Ensure proper ventilation. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **Electrical Safety:** This appliance uses auto electric ignition. Ensure the electrical supply is properly grounded and meets local codes.
- **Installation:** Installation must be performed by a qualified technician in accordance with all local codes and regulations.
- **Children Safety:** Keep children away from the appliance during operation and when it is hot.
- **Hot Surfaces:** Burners and pan supports will become hot during use. Use oven mitts or pot holders.
- **Flame Failure Device:** This hob is equipped with a flame failure device which automatically cuts off the gas supply if the flame extinguishes.

2. PRODUCT OVERVIEW

The KAFF PRESTON PRS 783 Built-in Hob is designed for efficient and safe cooking. It features a sleek glass top, high-efficiency brass burners, and user-friendly controls.

Key Features:

- **Type:** Built-in Hob / Hobtop
- **Finish:** 8mm Thick Premium Matte Black Tempered Glass with Round Edges

- **Burners:** 3 Count (2 Triple Ring Burners, 1 Dual Ring Burner) with High Efficiency Full Brass Burners
- **Ignition:** Automatic Electric Ignition
- **Pan Support:** Heavy Duty Cast Iron Pan Support with integrated flame protector
- **Controls:** Ergonomic Designer Metal Knobs
- **Safety:** Full Flame Failure Device
- **Convenience:** Digital Timer

Components:

Familiarize yourself with the main components of your hob:



Overall view of the KAFF PRESTON PRS 783 Built-in Hob, showcasing its three burners, control knobs, and sleek black glass surface.

KAFF


PRS 783



8MM THICK PREMIUM **MATTE BLACK TEMPERED**
GLASS WITH ROUND EDGES

The hob features an 8mm thick premium matte black tempered glass top with round edges, providing durability and a modern aesthetic.

KAFF



PRS 783




DIGITAL TIMER

The integrated digital timer allows for precise cooking control, automatically turning off the flame when the set time expires.

KAFF

PRS 783



AUTO IGNITION ELECTRIC

The automatic electric ignition system provides convenient and instant flame lighting with a simple turn of the knob.

KAFF

PRS 783



FLAME FAILURE DEVICE



Each burner is equipped with a flame failure device, enhancing safety by automatically cutting off the gas supply if the flame accidentally extinguishes.

KAFF

PRS 783



**HEAVY DUTY CAST IRON
PAN SUPPORT WITH
INTEGRATED FLAME PROTECTOR**



The hob features high-efficiency full brass burners, designed for optimal heat distribution and durability.

KAFF

PRS 783



**HIGH EFFICIENCY
FULL BRASS BURNERS**



Heavy-duty cast iron pan supports with integrated flame protectors provide stable support for cookware and enhance safety.

3. SETUP AND INSTALLATION

Installation of the KAFF PRESTON PRS 783 Built-in Hob should only be carried out by a qualified and authorized technician. Incorrect installation can lead to gas leaks, electric shock, or fire hazards.

Pre-Installation Checks:

- Verify that the gas supply type (LPG/Natural Gas) matches the appliance specifications.
- Ensure the electrical supply meets the voltage requirements (230 Volts).
- Confirm adequate ventilation in the kitchen area.

Countertop Preparation:

The countertop must be cut to the specified dimensions to properly accommodate the hob.

- **Inner Cutting Size (L x W):** 705 mm x 400 mm
- **Outer Size (L x W x H):** 780 mm x 450 mm x 145 mm



Detailed dimensions of the hob for accurate countertop cutting and installation.

Gas Connection:

- Connect the hob to the gas supply using a certified flexible hose or rigid pipe.
- Ensure all connections are leak-tested using a soapy water solution. Never use an open flame to check for leaks.

Electrical Connection:

- Plug the appliance into a properly grounded electrical outlet.
- Ensure the power cord is not pinched or damaged during installation.

4. OPERATING INSTRUCTIONS

Follow these steps to safely operate your KAFF PRESTON PRS 783 Built-in Hob.

Lighting a Burner:

1. Place your cookware centrally on the pan support over the desired burner.
2. Push down and turn the corresponding metal knob counter-clockwise to the 'High Flame' position. You will hear a clicking sound as the auto electric ignition sparks.
3. Hold the knob down for a few seconds after the flame ignites. This allows the flame failure device sensor to heat up and keep the gas flowing.
4. Release the knob. If the flame goes out, repeat the process.
5. Adjust the flame size by turning the knob between the 'High Flame' and 'Low Flame' positions.

Using the Digital Timer:

The digital timer allows you to set a cooking duration, after which the hob will automatically turn off the flame.

1. With a burner lit, press the timer button (refer to the hob's control panel for exact button).
2. Use the '+' and '-' buttons to set the desired cooking time.
3. The timer will start counting down. Once the time expires, the gas supply to the selected burner will be cut off, and the flame will extinguish.
4. An audible alert may sound to indicate the timer has finished.

Turning Off a Burner:

To turn off a burner, simply turn the corresponding knob clockwise to the 'OFF' position. Ensure the flame is completely extinguished.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob.

General Cleaning:

- Always ensure the hob is cool before cleaning.
- Disconnect the appliance from the electrical supply before cleaning.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals as they can damage the glass surface and other components.

Glass Top:

- Wipe the tempered glass surface with a soft cloth dampened with warm soapy water.
- For stubborn stains, use a non-abrasive glass cleaner specifically designed for hob tops.
- Dry thoroughly with a clean, soft cloth to prevent water spots.

Burners and Pan Supports:

- Remove the cast iron pan supports and brass burner components (burner caps, flame spreaders) when cool.
- Wash these components in warm soapy water. For heavy grease or burnt-on food, soak them for a while.
- Use a soft brush or sponge to clean. Ensure all gas ports on the burner are clear and free from debris.
- Dry all components completely before reassembling them. Moisture can affect ignition.

Control Knobs:

- The metal knobs can be gently pulled off for cleaning.
- Wash with warm soapy water and dry thoroughly before replacing.

6. TROUBLESHOOTING

If you encounter issues with your hob, refer to the table below for common problems and solutions. If the problem persists, contact customer service.

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply Power outage Burner components wet or clogged Ignition electrode dirty or damaged	Check gas valve and supply Check electrical connection Ensure burner components are dry and clean Clean electrode or contact service
Flame is uneven or yellow	Burner ports clogged Incorrect gas pressure	Clean burner ports Contact a qualified technician to check gas pressure
Flame goes out after releasing knob	Flame failure device not heating up Knob not held down long enough	Hold knob down for 3-5 seconds after ignition Ensure burner components are correctly assembled and clean
Digital timer not working	Electrical issue Control panel malfunction	Check power supply Contact customer service

If you are unable to resolve the issue using the troubleshooting guide, please contact KAFF customer support for assistance.

7. SPECIFICATIONS

Detailed technical specifications for the KAFF PRESTON PRS 783 Built-in Hob.

Feature	Detail
Model Number	PRS 783
Brand	KAFF
Colour	Black
Material	Stainless Steel (base), Tempered Glass (top)
Heating Elements	3 (2 Triple Ring, 1 Dual Ring)
Special Features	8mm Thick Black Tempered Glass, Auto Electric Ignition, Digital Timer, Flame Failure Device
Controls Type	Knob
Voltage	230 Volts
Item Dimensions (D x W x H)	78D x 45W x 14.5H Centimeters
Inner Cutting Size (L x W)	705 x 400 mm

Feature	Detail
Item Weight	18 Kilograms

8. WARRANTY AND SUPPORT

Warranty Information:

The KAFF PRESTON PRS 783 Built-in Hob comes with a manufacturer's warranty:

- **2 Years Warranty:** Applicable on Burners, Glass, Ignition Wire, Switch, Bypass & Generator.

Please retain your purchase receipt and the warranty card included in the box for any warranty claims.

Customer Support:

For any service, support, or warranty-related queries, please contact KAFF customer care:

- **Manufacturer:** KAFF Appliances (I) Pvt. Ltd.
- **Customer Care (Toll-Free):** 18001802221

Included Components:

Upon purchase, the package should contain:

- 1x Built-in Hob
- 1x Instruction Manual (this document)
- 1x Warranty Card