

[Manuals.plus](#) /

› [Intellitron](#) /

› Intellitron CK-2217D Multi-function Digital LED Wall Clock User Manual

## Intellitron CK-2217D

# Intellitron CK-2217D Multi-function Digital LED Wall Clock User Manual

Model: CK-2217D

## INTRODUCTION

Thank you for purchasing the Intellitron CK-2217D Multi-function Digital LED Wall Clock. This clock features a bright LED display showing time, date, day, and room temperature. This manual provides detailed instructions for setting up, operating, and maintaining your new clock.

## SAFETY INFORMATION

- Ensure the power source is 5V USB. Using an incorrect power adapter may damage the device.
- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water or other liquids.
- Do not attempt to disassemble or repair the clock yourself. Contact qualified service personnel for assistance.
- Keep out of reach of children.

## PACKAGE CONTENTS

- Intellitron CK-2217D Digital LED Wall Clock
- USB Power Cable
- External Temperature Probe (if included)
- User Manual

## PRODUCT OVERVIEW



Figure 1: Front View of the Clock. Shows the large digital time display at the top, and smaller displays for month, date, day, and temperature at the bottom.



Figure 2: Back View of the Clock. Displays the control buttons (SNOOZE, DOWN, UP, ALARM, SET) along the top edge, a USB power input, and an external temperature probe connection.

### Control Buttons:

- **SNOOZE:** Activates snooze function during an alarm; adjusts brightness.
- **DOWN:** Decreases values during setting; changes display mode.
- **UP:** Increases values during setting; changes display mode.
- **ALARM:** Enters/exits alarm setting mode; enables/disables alarm.

- **SET:** Enters/exits time/date setting mode; confirms settings.

## SETUP

---

### 1. Power Connection:

1. Connect the small end of the provided USB power cable to the USB input port on the back of the clock.
2. Connect the large end of the USB power cable to a 5V USB power adapter (not included) or a powered USB port.
3. The clock display will illuminate.

### 2. External Temperature Probe (if applicable):

- If your model includes an external temperature probe, plug its connector into the dedicated port on the back of the clock.
- Position the probe in the desired location for temperature measurement.

## OPERATING INSTRUCTIONS

---

### Setting Time and Date:

1. Press and hold the **SET** button for 3 seconds to enter time setting mode. The hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **SET** to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **UP** or **DOWN** buttons to adjust the minutes.
5. Press **SET** to confirm minutes and move to year setting.
6. Repeat the process using **UP/DOWN** and **SET** to set the year, month, and day.
7. After setting the day, press **SET** one last time to exit setting mode.

### Setting the Alarm:

1. Press the **ALARM** button once to enter alarm setting mode. The alarm hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the alarm hour.
3. Press **ALARM** to confirm the hour and move to alarm minute setting. The alarm minute digits will flash.
4. Use the **UP** or **DOWN** buttons to adjust the alarm minutes.
5. Press **ALARM** again to confirm and exit alarm setting mode.
6. To enable or disable the alarm, press the **ALARM** button briefly outside of setting mode. An alarm icon will appear/disappear on the display.

### Snooze Function:

- When the alarm sounds, press the **SNOOZE** button to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes (typically 5-9 minutes, consult product specifics if available).
- To turn off the alarm completely, press any other button (e.g., **ALARM** or **SET**) during the alarm or snooze period.

### Adjusting Display Brightness:

- Press the **SNOOZE** button repeatedly (outside of alarm mode) to cycle through different brightness levels.

### Changing Temperature Unit:

- Press the **DOWN** button briefly to switch between Celsius (°C) and Fahrenheit (°F) temperature display.

## MAINTENANCE

- Clean the clock surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the USB power cable is not bent or damaged.
- If the clock is not in use for an extended period, disconnect it from the power source.

## TROUBLESHOOTING

| Problem                            | Possible Cause                                     | Solution                                                                                                                                   |
|------------------------------------|----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| Clock does not power on.           | No power, faulty cable, or adapter.                | Check USB cable connection. Try a different USB power adapter or port.                                                                     |
| Display is dim.                    | Brightness setting is low.                         | Press the <b>SNOOZE</b> button to increase brightness.                                                                                     |
| Time/Date is incorrect.            | Not set correctly or power interruption.           | Re-set the time and date following the instructions in the 'Operating Instructions' section.                                               |
| Temperature reading is inaccurate. | External probe not connected or improperly placed. | Ensure the external temperature probe is securely connected and placed in an appropriate location away from direct heat sources or drafts. |

## SPECIFICATIONS

- **Model:** CK-2217D
- **Brand:** Intellitron
- **Material:** Plastic
- **Power Source:** 5V USB (Corded)
- **Display Type:** Digital LED
- **Functions:** Time, Date, Day, Temperature (Fahrenheit/Celsius)
- **Item Shape:** Rectangular
- **Item Depth:** Approximately 1.5 inches

## WARRANTY AND SUPPORT

Intellitron products are designed for reliability and performance. For warranty information or technical support, please refer to the documentation provided at the point of purchase or visit the official Intellitron website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Intellitron. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

## Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

## Question

Example: How do I reset this device or fix this error?

## Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**