

[Manuals.plus](#) /

› [ecozy](#) /

› ecozy Smart Ice Maker IM-BS261B User Manual

ecozy IM-BS261B

ecozy Smart Ice Maker User Manual

MODEL: IM-BS261B

1. Introduction

Thank you for choosing the ecozy Smart Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and retain it for future reference.



Image: The ecozy Smart Ice Maker, showcasing its design, ice production, and the accompanying mobile application interface.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Ensure the power supply matches the voltage specified on the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the outlet when not in use, before cleaning, and before servicing.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance away from heat sources and direct sunlight.
- Use only potable water in the ice maker.
- Do not block any ventilation openings.

3. Product Overview

The ecozy Smart Ice Maker is a portable countertop appliance designed for convenient ice production. It

features smart controls via a mobile app and voice commands, a self-cleaning function, and the ability to produce bullet-shaped ice in two sizes.

Components:

- Ice Maker Unit
- Ice Basket
- Ice Scoop
- Water Reservoir (internal)
- Control Panel (on top of unit)

4. Setup

4.1 Unpacking

1. Remove all packaging materials and accessories.
2. Inspect the ice maker for any damage. If damaged, do not operate and contact customer support.

4.2 Placement

- Place the ice maker on a flat, stable surface, away from direct sunlight and heat sources.
- Ensure there is at least 4 inches (10 cm) of space around the unit for proper ventilation.

4.3 Initial Cleaning

Before first use, clean the interior of the ice maker. Refer to the 'Maintenance' section for detailed cleaning instructions.

4.4 Water Filling

1. Open the lid of the ice maker.
2. Fill the water reservoir with potable water up to the 'MAX' fill line. Do not overfill.
3. Close the lid securely.

5. Operating Instructions

5.1 Powering On and Ice Production

1. Plug the ice maker into a grounded electrical outlet.
2. Press the 'POWER' button on the control panel to turn on the unit.
3. Select your desired ice size (Small or Large) using the 'SIZE' button. The ice maker will begin producing ice in approximately 6-8 minutes.

6-MIN Fast Ice Making

Discover the Magic of Rapid Ice Creation



Image: The ecozy Smart Ice Maker highlighting its rapid ice production capability, making ice in approximately 6 minutes.

5.2 App and Voice Control

The ecozy Smart Ice Maker can be controlled remotely via a smartphone app and voice commands (e.g., Alexa).


1. Download the ecozy app from your smartphone's app store.
2. Follow the in-app instructions to connect your ice maker to your Wi-Fi network and pair it with the app.
3. Once connected, you can use the app to start/stop ice production, select ice size, and schedule operations.
4. To enable voice control, link the ecozy skill/device in your smart home assistant app (e.g., Amazon Alexa).

Talk to Alexa Ice Appears

"Alexa,
turn on the ice maker."



Image: A user interacting with the ecozy Smart Ice Maker using voice commands through Alexa.



Tap the App, Ice on Tap

Your Ice is Just a Click Away

Image: The ecozy mobile application interface, demonstrating remote control capabilities for the ice maker.

5.3 App Alerts & Scheduling

- The app provides real-time notifications for low water levels or when the ice bin is full.
- You can schedule ice production up to 24 hours in advance using the app, ensuring ice is ready when needed.

Smart Reminder

Stay Cool with Smart Alerts, Never Miss Your Ice



Image: Examples of smart notifications and reminders provided by the ecozy app, alerting users to operational status.



Image: The ecozy Smart Ice Maker with a smartphone showing the scheduling feature, allowing users to plan ice production.

6. Maintenance

6.1 Automatic Self-Cleaning

The ice maker features a one-touch self-cleaning function to maintain hygiene and prevent limescale buildup.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the 'CLEAN' button (or activate via app) to start the self-cleaning cycle.
3. Once the cycle is complete, drain the water from the unit.

Automatic Self-Cleaning



Liberate
Your Hands



Clear
Limescale



Enjoy
Fresh Ice



Image: Visual representation of the automatic self-cleaning mechanism within the ecozy Smart Ice Maker.

6.2 Regular Cleaning

- Wipe the exterior with a soft, damp cloth.
- Clean the ice basket and ice scoop with mild detergent and rinse thoroughly.
- For internal cleaning beyond the self-clean cycle, use a solution of water and vinegar, run a cycle, then drain and rinse with clean water.

6.3 Storing Ice

The ice maker is not a freezer. Ice cubes will melt if left in the basket for extended periods. For long-term storage, transfer ice cubes to an ice bag and store them in a freezer.

7. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not producing ice	No water in reservoir; Power issue; Ambient temperature too high	Add water; Check power connection; Ensure proper ventilation
Ice cubes are too small or soft	Water temperature too high; Ambient temperature too high	Use colder water; Move to a cooler location
"ADD WATER" indicator on	Water level is low	Fill the water reservoir up to the MAX line
"ICE FULL" indicator on	Ice basket is full	Remove ice from the basket

8. Specifications

Feature	Specification
Brand	ecozy
Model Name	IM-BS261B
Product Dimensions (D x W x H)	8.7" x 11.41" x 11.57"
Capacity	26 Pounds (ice production per 24 hours)
Wattage	115 Watt-hours
Ice Type	Bullet Ice (Small/Large)
Control	App Remote, Voice Control (Alexa), Manual Buttons
Special Features	Self-Cleaning, App Alerts, Scheduling



Image: The ecozy Smart Ice Maker with its key dimensions clearly marked for reference.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ecozy website. Keep your proof of purchase for warranty claims.