

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DRIKLUX](#) /

› [DRIKLUX Automatic Watch Winder User Manual](#)

**DRIKLUX 22e2fae8-26dd-475e-b4a4-e13c05f019a9**

# DRIKLUX Automatic Watch Winder User Manual

Model: 22e2fae8-26dd-475e-b4a4-e13c05f019a9

## 1. INTRODUCTION

Thank you for choosing the DRIKLUX Automatic Watch Winder. This device is designed to keep your automatic watches wound and ready to wear, preventing them from stopping and requiring manual resetting. Featuring a super quiet Japanese motor, LED lighting, and a five-speed control mode, this winder offers reliable and convenient watch maintenance.

## 2. PRODUCT OVERVIEW

The DRIKLUX Watch Winder combines functional design with quiet operation to ensure your automatic watches are always in optimal condition. Its compact size and elegant appearance make it suitable for any setting.

### Key Features:

- Fashion Design:** Fine sand spraying technology with a transparent acrylic glass cover for a comfortable touch and aesthetic appeal.
- Super Quiet Operation:** Equipped with a Japanese motor and internal gearbox for extremely quiet performance.
- Rotational Mode Setting:** Supports a specific winding cycle to keep watches running.
- Selective Driving Mode:** Can be powered by an AC adapter or 2 AA batteries.
- LED Lighting Effect:** Enhances the display of your watch.



Image: DRIKLUX Watch Winder with its transparent acrylic lid open, showcasing the watch pillow inside.

### 3. PACKAGE CONTENTS

---

- 1 x DRIKLUX Automatic Watch Winder
- 1 x AC Power Adapter (located at the bottom of the brown corrugated box)
- 1 x User Manual (this document)

### 4. SETUP INSTRUCTIONS

---

#### 4.1 Power Connection

The watch winder can be powered by either the included AC adapter or 2 AA batteries (not included).

1. **Using AC Adapter:** Connect the AC adapter to the power input port on the back of the winder and plug it into a standard wall outlet (100-240V, 50/60HZ, 0.3A). Ensure batteries are removed if using AC power.
2. **Using Batteries:** Open the battery compartment on the back of the winder and insert 2 AA batteries, observing correct polarity. Disconnect the AC adapter if using battery power.



Image: Rear panel of the watch winder, showing the power input and control switches.

## 4.2 Placing Your Watch

1. Gently open the transparent acrylic cover.
2. Place your automatic watch onto the watch pillow. The watch pillow circumference is suitable for watches with a circumference of 6.7 to 7.7 inches.
3. Ensure the watch is securely seated on the pillow and the pillow is correctly positioned within the winder's rotating mechanism.
4. Close the transparent acrylic cover.



Image: An automatic watch securely placed inside the DRIKLUX Watch Winder with the lid closed.

## 5. OPERATING MODES

---

The DRIKLUX Watch Winder features a five-speed control mode, which includes a specific rotational pattern designed to keep your automatic watch wound.

### Rotational Cycle:

- The winder operates in a bi-directional, intermittent pause cycle.
- It turns clockwise for approximately 2 minutes.
- It then rests for 6 minutes.
- After the rest period, it resumes turning counterclockwise for 2 minutes.
- Finally, it pauses again for 6 minutes before repeating the cycle.

This cycle ensures your watch remains wound without being overwound.

### LED Lighting Effect:

The winder includes an LED lighting effect to illuminate your watch. Use the dedicated switch on the back panel to turn the LED light on or off according to your preference.



Image: The DRIKLUX Watch Winder with an automatic watch, illuminated by a blue LED light.

## 6. MAINTENANCE

---

### 6.1 Cleaning:

- Wipe the exterior of the winder with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents, as they may damage the finish.
- For the acrylic cover, use a soft, damp cloth and dry immediately to prevent water spots.

### 6.2 General Care:

- Keep the winder away from direct sunlight, extreme temperatures, and high humidity.
- Ensure the winder is placed on a stable, flat surface.
- Do not obstruct the ventilation openings.

## 7. TROUBLESHOOTING

---

### Watch is not turning:

- **Check Power:** Ensure the AC adapter is securely plugged in, or if using batteries, verify they are correctly inserted and not depleted.
- **Resting Time:** The winder operates with intermittent pauses. If you observe it not turning, it might be in its 6-minute resting period. Wait a few minutes to see if the rotation resumes.
- **Switches:** Confirm that the power switch on the back of the unit is in the 'ON' position.

## Unusual Noise:

- While the winder is designed to be super quiet, a faint motor sound may be audible in very quiet environments. If the noise is excessive or grinding, contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	22e2fae8-26dd-475e-b4a4-e13c05f019a9
Dimensions (L x W x H)	4.13 x 6.3 x 4.3 inches
Weight	Approximately 800g (1.72 Pounds)
Power Input	AC Adapter (100-240V, 50/60HZ, 0.3A) or 2 x AA Batteries
Watch Pillow Circumference	6.7 ~ 7.7 inches
Motor Type	Japanese Motor

## 9. WARRANTY & SUPPORT

### 9.1 Warranty:

The DRIKLUX Automatic Watch Winder comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

### 9.2 Customer Support:

If you encounter any problems with your product or have questions not covered in this manual, please do not hesitate to contact our customer support team. We are committed to providing assistance and will respond to your inquiries within 24 hours.

**Email:** [support@driklux.com](mailto:support@driklux.com) (Example email, please replace with actual support email if available)

**Related Documents - 22e2fae8-26dd-475e-b4a4-e13c05f019a9**

	<p><a href="#"><u>Driklux Watch Winder Safe WWS8 WWS12: Quick Start Guide &amp; Settings</u></a></p> <p>This guide provides detailed instructions for setting up, operating, and securing the Driklux Watch Winder Safe (WWS8, WWS12 series). Learn about opening and locking mechanisms, fingerprint and password settings, vibration alarms, watch winder configurations, and product specifications.</p>
	<p><a href="#"><u>Driklux Watch Winder and Fingerprint Lock Manual</u></a></p> <p>Comprehensive manual for Driklux watch winders and fingerprint locks, covering preparation, gear selection, operational modes, fingerprint management, charging, and specifications.</p>
	<p><a href="#"><u>Driklux Watch Winder Safe WWS8 WWS12: Quick Start Guide &amp; Settings</u></a></p> <p>This guide provides detailed instructions for setting up, operating, and securing the Driklux Watch Winder Safe (WWS8, WWS12 series). Learn about opening and locking mechanisms, fingerprint and password settings, vibration alarms, watch winder configurations, and product specifications.</p>
	<p><a href="#"><u>Driklux Watch Winder and Fingerprint Lock Manual</u></a></p> <p>Comprehensive manual for Driklux watch winders and fingerprint locks, covering preparation, gear selection, operational modes, fingerprint management, charging, and specifications.</p>
	<p><a href="#"><u>ICOM IC-475A/E 430MHz All Mode Transceiver Instruction Manual</u></a></p> <p>Detailed instruction manual for the ICOM IC-475A/E, a 430MHz all-mode transceiver featuring DDS technology, extensive memory functions, and advanced scanning capabilities for amateur radio operators.</p>