



Manuals.plus /

- › Aesfee /
- › Aesfee 5-in-1 Electric Grooming Kit User Manual

Aesfee AF-8098

User Manual

AESFEE 5-IN-1 ELECTRIC GROOMING KIT

Model: AF-8098

1. Product Overview

The Aesfee 5-in-1 Electric Grooming Kit (Model AF-8098) is a versatile personal grooming device designed for men. It provides a comprehensive solution for beard, hair, body, nose, and ear hair trimming and shaving. The kit includes multiple interchangeable heads and adjustable length settings to cater to various grooming needs.



Image 1.1: The Aesfee 5-in-1 Electric Grooming Kit, showcasing the main unit and its five interchangeable heads: hair clippers, beard trimmer, foil shaver, body hair trimmer, and nose/ear trimmer. A charging dock is also visible.

2. Safety Instructions

- Read all instructions before using the appliance.
- Keep the appliance dry. Do not immerse the main unit in water.
- This appliance is suitable for cleaning under running water. Ensure the charging port is completely dry before charging.
- Only use the provided USB-C cable for charging. Do not use chargers with a power output exceeding DC 5V 1A (e.g., iPhone chargers).
- Keep out of reach of children.
- Do not use the appliance if the blades are damaged, as this may cause injury.
- Avoid using the appliance on irritated or broken skin.
- Unplug the appliance before cleaning.

3. Package Contents

Verify that all items are present in the package:

- Main Trimmer Unit
- Hair Clippers Head
- Beard Trimmer Head
- Foil Shaver Head
- Body Hair Trimmer Head
- Nose Hair Trimmer Head
- 4 Comb Guides (various sizes)
- Charging Dock
- USB-C Charging Cable
- Cleaning Brush
- Instruction Manual (this document)

All-in-One Groomer Kit for Men



Easy to Replace Cutter Heads and One-Button for Operation

All Accessories Are Placed on the Dock to Save Space and Facilitate Storage

Image 3.1: A visual representation of all accessories included in the Aesfee All-in-One Groomer Kit, neatly arranged on the charging dock.

4. Setup

4.1 Charging the Appliance

Before first use, fully charge the grooming kit. The digital display will show the battery percentage.

1. Connect the USB-C charging cable to the charging dock.
2. Place the main trimmer unit onto the charging dock, ensuring it is seated correctly. Alternatively, you can plug the USB-C cable directly into the charging port on the bottom of the main unit.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (DC 5V 1A recommended, not included).
4. The display will illuminate, indicating charging is in progress. A full charge takes approximately 1.5 hours and provides up to 100 minutes of cordless use.

4.2 Attaching and Detaching Trimmer Heads

The grooming kit features interchangeable heads for different functions.

- **To Attach:** Align the desired trimmer head with the main unit and push it down firmly until it clicks into place.
- **To Detach:** Hold the main unit firmly and pull the trimmer head upwards to remove it.

5. Operating Instructions

5.1 General Operation

- Press the power button once to turn the appliance ON. The digital display will show the current battery percentage.
- Press the power button again to turn the appliance OFF.

5.2 Using the Hair Clippers and Beard Trimmer Heads

These heads are ideal for precise trimming of hair and beards, offering adjustable length settings.

1. Attach either the Hair Clippers Head or the Beard Trimmer Head to the main unit.
2. **Adjusting Length:** Rotate the dial on the trimmer head to select your desired cutting length. The Hair Clippers head offers lengths from 1 to 13mm, and the Beard Trimmer head offers lengths from 1 to 20mm. Two comb guides are included for additional length options.
3. Turn on the appliance.
4. Move the trimmer against the direction of hair growth for optimal results.

Precise Rotating Length Adjuster for Beard Trimmer and Hair Clippers

*Two guide combs can easily trim hair lengths from 1 to 20 mm
Easy to operate and convenient to store*



Sharp Stainless Steel Blades

*Cuts hair cleanly and thoroughly
without pulling hair*

Image 5.1: Detail of the precise rotating length adjuster on the beard trimmer and hair clippers heads, showing the range of 1 to 20mm and 1 to 13mm respectively, along with two comb guides.

Pro Hair Clippers & Beard Trimmer ***Powerful & Precise for Barbers and Home Use***



Stainless Steel Blade

***20 Precise
Trimming Lengths***

Image 5.2: The Aesfee grooming kit being used for beard trimming on an adult male and hair clipping on a young boy, demonstrating its versatility for both precise and general hair cutting.



Beard Trimmers

Precise Dial and Adjustable 20 Trimming Lengths to Meet All Your Grooming Needs

Image 5.3: A man using the beard trimmer head to precisely shape his beard, highlighting the adjustable dial for various trimming lengths.

5.3 Using the Foil Shaver Head

The foil shaver is designed for a close, smooth shave on the face, neck, or for achieving a zero-finish look.

- Attach the Foil Shaver Head to the main unit.
- Turn on the appliance.
- Gently press the shaver against your skin and move it in short, circular motions or straight strokes.



***Professional Triple Foils Shaver
for Face, Neck, or Bald Head and Fades Hairstyle
A Close and Smooth Shaving***

Image 5.4: A man using the professional triple foils shaver head for a close and smooth shave on his neck and face, suitable for achieving a clean-shaven look or fading hairstyles.

5.4 Using the Body Hair Trimmer Head

This head is designed for safely and effectively trimming hair on the body, including the chest, abdomen, back, legs, arms, and pubic area.

- Attach the Body Hair Trimmer Head to the main unit.
- Turn on the appliance.
- Move the trimmer gently over the desired area, ensuring even contact with the skin.



Body Hair Trimmer

Skin Friendly Circular Toothed Blades Design

Safely & effectively shave hair on the abdomen, chest, back, legs, arms and pubic area

Image 5.5: A man using the body hair trimmer head on his chest, demonstrating its skin-friendly circular toothed blades design for safe and effective hair removal on various body areas.

5.5 Using the Nose & Ear Hair Trimmer Head

This specialized head is for safely and efficiently trimming unwanted hair from the nose and ears.

- Attach the Nose & Ear Hair Trimmer Head to the main unit.
- Turn on the appliance.
- Gently insert the trimmer tip into the nostril or ear canal. Do not insert too deeply.
- Move the trimmer in a circular motion to cut the hair.



Nose & Ear Hair Trimmer

Safe and Efficient Curved Stainless Steel Cutter Head

Image 5.6: A man using the nose and ear hair trimmer head, illustrating its safe and efficient curved stainless steel cutter head for removing unwanted hair.

5.6 Wet & Dry Use

The Aesfee grooming kit is 100% waterproof, allowing for both wet and dry use. You can use it in the shower for convenience.

- For dry use, ensure skin is clean and dry.
- For wet use, apply shaving foam or gel to the skin before trimming.
- Always ensure the charging port is completely dry before connecting the charging cable or placing it on the dock.

6. Maintenance

6.1 Cleaning the Trimmer Heads

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the appliance and detach the trimmer head.
2. Use the provided cleaning brush to remove any loose hairs from the blades and inside the head.
3. Rinse the trimmer head under running water. For thorough cleaning, you can also rinse the main unit

(ensure the charging port cover is securely closed if rinsing the main unit).

4. Allow all parts to air dry completely before reattaching or storing.
5. Periodically apply a small drop of lubricating oil (not included) to the blades to maintain smooth operation.

6.2 Storage

Store the grooming kit and its accessories in a cool, dry place, away from direct sunlight and moisture. Use the charging dock to keep all components organized and easily accessible.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is depleted.	Charge the appliance fully.
Trimmer not cutting effectively.	Blades are clogged with hair or dull.	Clean the trimmer head thoroughly. If blades are dull, consider replacement (contact support).
Appliance makes unusual noise.	Hair caught in the motor or head not properly attached.	Turn off, detach head, clean thoroughly. Reattach head securely. If problem persists, contact support.
Charging not working via dock.	Dock connection issue or faulty cable/adaptor.	Try charging directly via the USB-C port on the main unit. Ensure the USB-C cable and power adapter are functioning correctly and meet DC 5V 1A specification.

8. Specifications

Model: AF-8098

Brand: Aesfee

Power Input: DC 5V 1A (USB-C)

Battery Type: Lithium Ion (1 required, included)

Charging Time: Approximately 1.5 hours

Operating Time: Up to 100 minutes (cordless)

Waterproof Rating: 100% Washable (Wet/Dry use)

Product Dimensions: 8.27 x 1.77 x 1.18 inches

Item Weight: 0.61 Kilograms (1.34 Pounds)

Country of Origin: China

9. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please refer to the contact information provided with your purchase or visit the official Aesfee website. Keep your purchase receipt as proof of purchase for warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. *(Note: This disclaimer was present in the original product data under "Important Information" but seems out of place for a grooming product. Including it as per source, but noting its context.)*

