

[manuals.plus](#) /

› [Tefal](#) /

› [Tefal Express Steam+ Iron FV2882G0 User Manual](#)

## Tefal FV2882G0

# Tefal Express Steam+ Iron FV2882G0 User Manual

Model: FV2882G0

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using your Tefal Express Steam+ Iron and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the voltage indicated on the iron's rating plate corresponds to your mains voltage.
- Always plug the iron into an earthed socket.
- Do not leave the iron unattended while it is switched on or cooling down.
- Keep the iron and its cord out of reach of children and persons with reduced physical, sensory, or mental capabilities.
- Never immerse the iron, power cord, or plug in water or any other liquid.
- Do not operate the iron if it has been dropped, has visible damage, or if the power cord or plug is damaged. Contact authorized service for repair.
- Always place the iron on a stable, heat-resistant surface when resting.
- Exercise caution when filling or emptying the water tank, as hot water or steam may be present.
- This appliance is intended for domestic use only.

## 2. PRODUCT OVERVIEW

The Tefal Express Steam+ Iron FV2882G0 is designed for efficient and effortless ironing. Familiarize yourself with its components:

- **A. Water Tank:** For filling with water for steam generation.
- **B. Filling Inlet:** Opening for adding water to the tank.
- **C. Spray Nozzle:** Emits a fine mist of water.
- **D. Spray Button:** Activates the spray function.
- **E. Steam Trigger/Boost Button:** Releases a powerful burst of steam.
- **F. Steam Control Selector:** Adjusts continuous steam output.
- **G. Temperature Control Dial:** Selects the appropriate ironing temperature for different fabrics.
- **H. Indicator Light:** Illuminates when the iron is heating and turns off when the set temperature is reached.
- **I. Durilium Airglide Ceramic Soleplate:** Provides smooth gliding and even heat distribution.

- **J. Power Cord:** Connects the iron to the electrical outlet.



Image 1: Overview of the Tefal Express Steam+ Iron FV2882G0, showcasing its ergonomic design and key controls.

**Tefal**

# DURILIUM AIRGLIDE CERAMIC SOLEPLATE

Experience Smoother Ironing with **Ultra-Durable Ceramic Coating** for Faster, Even Results Every Time



Image 2: Close-up view of the Durilium Airglide Ceramic Soleplate, highlighting its smooth surface and steam vents.

## 3. BEFORE FIRST USE

1. Remove any stickers or protective film from the soleplate.
2. Clean the soleplate with a soft, damp cloth.
3. For the first use, iron an old piece of fabric (e.g., an old towel) for a few minutes to remove any manufacturing residues from the soleplate and steam vents. This may produce a slight odor or light smoke, which is normal and will dissipate.

## 4. FILLING THE WATER TANK

The iron features a 270ml water tank for extended ironing sessions.

1. Ensure the iron is unplugged from the mains socket.
2. Set the steam control selector to the 'Dry Ironing' position (no steam).

3. Hold the iron in a horizontal position.
4. Open the filling inlet cover.
5. Carefully pour tap water into the water tank up to the 'MAX' level indicator. Do not overfill.
6. Close the filling inlet cover securely.

**Note:** While tap water is generally suitable, in areas with very hard water, it is recommended to mix 50% tap water with 50% distilled water to prolong the life of your iron. Do not use 100% distilled water as it can cause the iron to spit. Never use perfumed water, water from tumble dryers, or chemically descaled water, as these can damage the iron.

**Tefal**

# Enjoy Longer, Safer, and Effortless Ironing with Express Steam.



**270ML**  
**Water Tank**  
for Extended Ironing Sessions



**AUTOMATIC**  
**Safety Shut-Off**  
for Ultimate Convenience



Image 3: The iron highlighting the 270ml water tank capacity and the automatic safety shut-off feature.

## 5. OPERATING THE IRON

### 5.1. Setting the Temperature

The iron features 5 precision temperature settings to tailor the heat for every fabric type.

1. Plug the iron into an earthed mains socket.

2. Turn the temperature control dial to the desired setting according to the fabric care label. Start with lower temperatures for delicate fabrics and increase for heavier materials.
3. The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.

## 5.2. Steam Ironing

Ensure the water tank is filled (refer to Section 4).

1. Set the temperature control dial to the steam zone (usually indicated by steam symbols on the dial).
2. Once the indicator light turns off, indicating the iron is at temperature, you can select your desired steam level using the steam control selector.
3. For a powerful steam boost of up to 190 g/min, press the steam trigger/boost button. This is effective for stubborn creases.

## 5.3. Vertical Steaming

This feature allows you to remove creases from hanging garments, curtains, or upholstery.

1. Hang the garment on a hanger.
2. Set the temperature control dial to the maximum setting.
3. Hold the iron vertically, a few centimeters away from the fabric.
4. Press the steam trigger/boost button repeatedly to release bursts of steam.

## 5.4. Dry Ironing

For fabrics that require dry ironing, or when the water tank is empty:

1. Set the steam control selector to the 'Dry Ironing' position (no steam symbol).
2. Select the desired temperature using the temperature control dial.
3. Wait for the indicator light to turn off before ironing.

## 5.5. Spray Function

The spray function helps to dampen stubborn creases.

- Press the spray button to emit a fine mist of water onto the fabric.

## 5.6. Automatic Safety Shut-Off

For enhanced safety, the iron is equipped with an auto shut-off feature:

- If left motionless on its soleplate or side, the iron will automatically switch off after approximately 30 seconds.
- If left motionless on its heel rest, it will switch off after approximately 8 minutes.
- To restart the iron, simply move it. The indicator light will illuminate, and the iron will reheat to the set temperature.

**Tefal**

# Elevate Your Ironing Experience



**5 PRECISION**  
Temperature Settings  
Tailor the Heat for Every Fabric

Up to  
**+25% More**

Steam

Up to  
**190 g/min**

Powerful Steam Shot



Image 4: The iron's control panel showing the temperature dial and steam settings, including the 190 g/min powerful steam shot.

# Perfect for Delicate Fabrics & Detailed Ironing

Effortless Steaming  
for **Delicate** and **Hanging**  
**Garments Vertical steaming**



Image 5: The iron demonstrating vertical steaming for hanging garments, ideal for delicate fabrics and quick touch-ups.

## 6. MAINTENANCE AND CARE

### 6.1. Cleaning the Soleplate

The Durilium Airglide ceramic soleplate is designed to be scratch-resistant and easy to clean.

1. Ensure the iron is unplugged and completely cool.
2. Wipe the soleplate with a damp cloth and a non-abrasive cleaner, if necessary.
3. Do not use abrasive pads, metal scouring pads, or harsh chemicals, as these can damage the soleplate coating.

### 6.2. Descaling

Regular descaling helps maintain steam performance, especially in hard water areas. The iron features an anti-calc system.

- Refer to the specific descaling instructions in the full product manual for detailed steps on using the anti-calc system.

- Generally, this involves filling the tank, heating the iron, and then flushing out mineral deposits.

### 6.3. Storage

1. Unplug the iron and allow it to cool completely.
2. Empty any remaining water from the tank to prevent water stains and mineral buildup.
3. Wrap the power cord loosely around the heel rest.
4. Store the iron upright on its heel rest in a safe, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your iron, consult the following table before contacting service.

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; auto shut-off activated.	Check power connection; test outlet with another appliance; move the iron to reactivate.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam vents blocked.	Fill water tank; set temperature to steam zone; perform descaling.
Water leakage from soleplate.	Temperature too low for steam; steam control set too high for temperature; overfilled water tank.	Ensure iron is at correct temperature for steam; reduce steam setting; do not overfill water tank.
Iron trips circuit breaker.	High wattage appliance on a low-amp circuit; faulty iron.	Ensure iron is plugged into a 16-amp socket (if applicable for your region); if problem persists, contact service.
Brown stains coming from soleplate.	Mineral deposits in water; residues from fabric.	Perform descaling; clean soleplate; use recommended water type.

## 8. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Tefal
Model Number	FV2882G0
Power	2600 Watts
Voltage	230 Volts
Soleplate Material	Durilium Airglide Ceramic
Continuous Steam Output	+25% More Steam (compared to previous models)
Steam Boost	Up to 190 g/min
Water Tank Capacity	270 ml

Feature	Specification
Special Features	Anti-Drip, Scratch Resistant, Temperature Control, Vertical Steam, Auto Shut-Off
Product Dimensions	10.5L x 8.2W Centimeters
Item Weight	1 kg 290 g
Country of Origin	India

## 9. WARRANTY AND SUPPORT

### 9.1. Warranty Information

The Tefal Express Steam+ Iron FV2882G0 comes with a 2-year warranty from the date of purchase. This warranty covers manufacturing defects under normal domestic use. Please retain your purchase receipt as proof of purchase.


The warranty does not cover damage resulting from misuse, neglect, accidental damage, or unauthorized repairs.

### 9.2. Customer Support

For any questions, service requests, or warranty claims, please contact the manufacturer's customer support:

- Manufacturer:** GROUPE SEB INDIA [P] LTD
- Address:** C-67, 3rd Floor, DDA SHEDS, OKHLA PHASE1, NEW DELHI-110020, INDIA
- Please refer to the warranty card included with your product for specific contact details and service center locations.

### Related Documents - FV2882G0

	<p><a href="#">Tefal Express Protect Steam Iron User Guide</a></p> <p>Comprehensive user guide for the Tefal Express Protect steam iron (Model 1820003088), detailing operation, features like Steam Boost, Anti-Calc, Auto-Off, and maintenance. Includes safety warnings and usage tips.</p>
	<p><a href="#">Tefal Easygliss Plus FV5718 Steam Iron: Features and Specifications</a></p> <p>Explore the Tefal Easygliss Plus FV5718 steam iron, highlighting its Durilium Airglide soleplate, 2500W power, 45 g/min continuous steam, 195 g/min steam boost, anti-drip system, and precision tip for efficient and effortless garment care.</p>
	<p><a href="#">Tefal Express Anti-Calc Steam Generator Iron User Guide</a></p> <p>Comprehensive user guide for the Tefal Express Anti-Calc Steam Generator Iron, covering setup, operation, maintenance, and safety instructions.</p>
	<p><a href="#">Tefal Ultragliss Anti-Calc FV49xxxx Steam Iron User Manual</a></p> <p>Comprehensive user guide for the Tefal Ultragliss Anti-Calc FV49xxxx steam iron. Learn about operation, features like Auto-Off and Anti-Calc, maintenance, and safety instructions.</p>

	<p><a href="#"><u>Tefal Express Optimal/Easy Steam Iron User Guide - SV4110E0</u></a></p> <p>Comprehensive user guide for the Tefal Express Optimal/Easy steam iron (SV4110E0). Learn about features like SteamBoost, temperature control, AUTO OFF, and ANTI CALC system. Includes ironing tips and maintenance instructions.</p>
	<p><a href="#"><u>Tefal FV49xxxx Smart Protect Steam Iron User Guide and Safety Instructions</u></a></p> <p>User guide for the Tefal FV49xxxx Smart Protect steam iron, covering safe operation, fabric settings (normal/eco), steam functions, Auto-Off safety, anti-calc, and maintenance. Includes detailed instructions and tips for optimal ironing.</p>