

## Ninco NH93193

# Ninco Acrobatic RC Stunt Car User Manual

Model: NH93193

## 1. INTRODUCTION

---

Thank you for choosing the Ninco Acrobatic RC Stunt Car. This remote-controlled vehicle is designed for dynamic play, featuring 360-degree rotations, vibrant lights, and engaging sounds. It comes with three interchangeable helmets for customization and operates on a reliable 2.4 GHz frequency for interference-free fun. Please read this manual carefully before operating the product to ensure safe and optimal performance.

## 2. SAFETY INFORMATION

---

**WARNING:** Not recommended for children under 3 years of age. Contains a toy. Adult supervision is recommended during play.

- Keep hands, hair, and loose clothing away from the moving wheels of the vehicle.
- Do not operate the vehicle near water or in wet conditions.
- Avoid operating the vehicle in crowded areas or near obstacles that could cause damage or injury.
- Do not attempt to modify or disassemble the vehicle or remote control.
- Use only the specified batteries and ensure correct polarity during installation.
- Remove batteries from the vehicle and remote control when not in use for extended periods.

## 3. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- 1x Ninco Acrobatic RC Stunt Car
- 1x Remote Control (2.4 GHz)
- 3x Interchangeable Helmets
- 1x 3.7V 500mAh Lithium-Ion Battery (pre-installed or included separately)
- 1x USB Charging Cable (for car battery)



Image 3.1: Contents of the Ninco Acrobatic RC Stunt Car package, including the car, remote, and helmets.

## 4. SETUP

---

### 4.1. Charging the Car Battery

1. Locate the battery compartment on the underside of the Ninco Acrobatic RC Stunt Car.
2. If the battery is not pre-installed, connect the 3.7V 500mAh Lithium-Ion battery to the car's connector.
3. Connect the USB charging cable to the car's charging port.
4. Plug the other end of the USB charging cable into a standard USB power adapter (not included) or a computer USB port.
5. The charging indicator light will illuminate during charging and turn off or change color when fully charged. Charging typically takes approximately 60-90 minutes.

### 4.2. Installing Remote Control Batteries

1. Open the battery compartment on the back of the remote control.
2. Insert 2 x LR03 (AAA) batteries (not included) into the compartment, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

### 4.3. Attaching Interchangeable Helmets

1. Select your desired helmet from the three included options.
2. Align the helmet with the designated slot on top of the car.
3. Gently press down until the helmet clicks securely into place. To change, simply pull the helmet off and replace with another.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Powering On and Pairing

1. Ensure the car battery is fully charged and batteries are installed in the remote control.
2. Turn on the power switch on the Ninco Acrobatic RC Stunt Car. The car's lights may flash.
3. Turn on the power switch on the remote control. The remote control and car will automatically pair using 2.4 GHz technology. A successful pairing is indicated by the car's lights becoming solid or a confirmation sound.

### 5.2. Driving Controls

Use the joysticks on the remote control to maneuver the car:

- **Left Joystick (Forward/Backward):** Push forward to move the car forward, pull backward to move the car backward.
- **Right Joystick (Left/Right):** Push left to turn the car left, push right to turn the car right.



Image 5.1: The Ninco Acrobatic RC Stunt Car in action, demonstrating its maneuverability.

### 5.3. Stunt Features

- **360° Rotations:** Experiment with simultaneous joystick movements (e.g., one forward, one backward) to perform impressive 360-degree spins and flips.
- **Demo Function:** Press the dedicated demo button on the remote control (if available) to activate a pre-programmed sequence of stunts and movements.

## 5.4. Lights and Sounds

The Ninco Acrobatic RC Stunt Car features integrated lights and sounds that activate during operation, enhancing the play experience. These features are typically automatic and do not require separate controls.

## 6. MAINTENANCE

---

### 6.1. Cleaning

- Wipe the car and remote control with a soft, dry cloth.
- Do not use water or chemical cleaners, as they may damage the electronic components.
- Remove any debris or hair that may get caught in the wheels or axles.

### 6.2. Battery Care

- Always fully charge the car's lithium-ion battery before first use and after each play session.
- Do not overcharge the battery. Disconnect the charger once charging is complete.
- If the car will not be used for an extended period, remove all batteries from both the car and the remote control.

### 6.3. Storage

- Store the Ninco Acrobatic RC Stunt Car and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the product in its original packaging or a protective container to prevent damage.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Car does not respond to remote control.	Low batteries in car or remote; Not paired; Interference.	Charge car battery; Replace remote batteries; Re-pair car and remote; Move to an area with less interference.
Short playtime.	Battery not fully charged; Old or worn-out battery.	Ensure battery is fully charged before use; Consider replacing the car battery if it's old.
Car moves slowly or erratically.	Low battery; Obstruction in wheels.	Charge car battery; Check wheels for debris and clear them.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	NH93193
Product Dimensions	35 x 27 x 9.5 cm
Product Weight	1 kg
Car Battery	3.7V 500mAh Lithium-Ion (included)
Remote Control Batteries	2 x LR03 (AAA) (not included)
Operating Frequency	2.4 GHz

Feature	Detail
Playtime	More than 15 minutes
Recommended Age	6 years and up
Material	Plastic
Color	Multicolor
Educational Objectives	Development of motor skills and creativity
Assembly Required	No

## 9. WARRANTY AND SUPPORT

---

Ninco products are manufactured to high-quality standards. For any questions, technical support, or warranty claims, please contact Ninco customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty purposes.

Visit the official Ninco store for more information: [Ninco Amazon Store](#)