

[Manuals.plus](#) /

› [LivePure](#) /

› LivePure Bladeless Oscillating Fan User Manual

LivePure LP1800-PARENT

LivePure Bladeless Oscillating Fan User Manual

Model: LP1800-PARENT | Brand: LivePure

1. INTRODUCTION

Thank you for choosing the LivePure Bladeless Oscillating Fan with Filter and Aroma Tray. This innovative fan is designed to provide a safe, quiet, and efficient cooling experience while also improving air quality and ambiance in your home or office. Its bladeless design ensures safety around children and pets, and the integrated filter and aroma tray offer additional benefits for a healthier and more pleasant environment.





Figure 1: Front view of the LivePure Bladeless Oscillating Fan.

Your browser does not support the video tag.

Video 1: An overview of LivePure products, including the bladeless fan, highlighting features like air purification, humidification, and filter systems. This video demonstrates the brand's commitment to clean air solutions.

2. PRODUCT FEATURES

- **Bladeless Construction:** Innovative bladeless design for safe use around kids and pets. This unique technology allows for safe and efficient airflow, eliminating the risk of dust build-up spreading throughout the room. This fan produces a steady, smooth, and fresh airflow which is gentler and more comfortable compared to traditional fans.
- **Coconut Carbon Filter and Aroma Tray:** This sleek personal fan from LivePure features a Coconut Carbon Filter to remove dust, pet hair, and dander from the air in your home. Coconut carbon technology also helps to eliminate VOC's (Volatile Organic Compounds) and reduce odors that can contaminate your air. It also features an essential oil tray to help spread the fragrance of your choice throughout the room.
- **45-Degree Oscillation and 3 Wind Speeds:** The LP1800 oscillating fan quickly cools any bedroom, kitchen,

bathroom, or office space with a powerful stream of airflow. Perfect desk fan and standing fan for comfortable room temperature on hot summer days.

- **Quiet Operation:** Perfect as a bedroom fan, our bladeless fan operates with minimal noise, ensuring your sleep isn't disturbed. The quiet function of this fan makes it an ideal personal fan for tranquil nights, with only 45-60 decibels noise level and a sleep timer up to 8 hours.
- **Remote Control and Touch Control:** Easily adjust fan settings from anywhere in the room with the wireless remote. Adjust oscillation, fan speed, and timer from up to 20 feet away, whether you're in the bedroom, office, or on the couch.

Bladeless design creates a strong stream of airflow, makes it easier to clean, and is safer for pets and children.



Figure 2: Bladeless design ensures strong, safe airflow and easy cleaning.



Whisper-Quiet Operation



Easy Maintenance



Essential Oil Tray



Multiple Speeds



45-Degree Oscillation



Safe for Kids and Pets



Figure 3: Key features of the LivePure Bladeless Fan, including quiet operation, essential oil tray, oscillation, easy maintenance, multiple speeds, and safety for kids and pets.

3. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, please contact customer support.

- LivePure Bladeless Oscillating Fan (LP1800-PARENT)
- Remote Control
- Coconut Carbon Filter (pre-installed or separate)
- User Manual

4. SETUP

1. **Unpacking:** Carefully remove the fan and all accessories from the packaging. Retain packaging for future storage or transport.

2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for optimal airflow and oscillation (e.g., not directly against a wall). The fan dimensions are approximately 6.73"D x 11.5"W x 24.75"H.
3. **Power Connection:** Plug the power cord into a standard electrical outlet (AC power source).
4. **Filter Installation (if not pre-installed):** Refer to the "Maintenance" section for instructions on how to install the Coconut Carbon Filter.




Figure 4: Fan dimensions for proper placement.

5. OPERATING INSTRUCTIONS

The LivePure Bladeless Oscillating Fan can be operated using either the touch control panel on the unit or the included wireless remote control.

Powerful and Smooth

Bladeless design provides a powerful, smooth stream of air



Figure 5: Control panel layout and button functions.

Control Panel / Remote Functions:

Button/Function	Description
On/Off	Powers the fan on or off.
Speed	Cycles through 3 wind speeds: Low, Medium, Turbo.
Rotate	Activates or deactivates 45-degree oscillation.
Timer	Sets the auto-off timer for 1, 2, 4, or 8 hours.
Light	Controls the accent light feature.

Using the Aroma Tray:

1. Locate the aroma tray on the fan unit.
2. Open the tray and add a few drops of your preferred essential oil onto the aroma pad (not included).
3. Close the tray securely. The fan's airflow will gently diffuse the fragrance into the room.

6. MAINTENANCE

Coconut Carbon Filter Care:

The Coconut Carbon Filter helps remove dust, pet hair, dander, VOCs, and odors. Regular maintenance ensures optimal performance.

Coconut Carbon Filter



Pet Hair
& Dander



Household
Dust



Smoke
& Odors



VOCs



- Helps remove dust, pet hair, and dander
- Eliminates VOCs (volatile organic compounds)
- Reduces odors that contaminate your air



Figure 6: Benefits of the Coconut Carbon Filter.



Figure 7: Accessing the Coconut Carbon Filter for maintenance.

1. **Filter Cleaning:** The Coconut Carbon Filter is designed for long-term use. Periodically, gently vacuum the filter to remove accumulated dust and debris. Do not wash the filter with water.
2. **Filter Replacement:** The filter life depends on usage and air quality. Replace the filter when you notice a decrease in airflow or an increase in odors. Replacement filters can be purchased from authorized LivePure retailers or the manufacturer's website.

General Cleaning:

- Always unplug the fan before cleaning.
- Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- The bladeless design makes it easier to clean inside the air outlet. Use a soft brush or a vacuum cleaner with a brush attachment to remove any dust from the air outlet.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Weak or no airflow.	Filter is dirty or blocked.	Clean or replace the Coconut Carbon Filter. Ensure air intake and outlet are not obstructed.
Fan is making unusual noise (e.g., grinding).	Internal obstruction or component issue.	Unplug the fan immediately. Check for any visible obstructions. If the noise persists, contact customer support.
Remote control not working.	Dead batteries or obstruction.	Replace the remote control batteries. Ensure there is no obstruction between the remote and the fan's sensor.
Oscillation not working.	Mechanism obstructed or malfunction.	Ensure the fan is on a level surface and nothing is blocking its rotation. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	LivePure
Model Name	LivePure Bladeless Oscillating Fan w/Filter and Aroma Tray
Item Model Number	LP1800-PARENT
Color	Black
Product Dimensions	6.73"D x 11.5"W x 24.75"H
Item Weight	9.23 pounds
Power Source	AC
Control Method	Remote, Touch
Special Feature	Oscillating, Bladeless, Filter, Aroma Tray
Noise Level	45-60 decibels (Quiet Operation)
UPC	810067451161

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact LivePure customer service. Keep your purchase receipt as proof of purchase.

You can visit the official LivePure store for more information and support:[LivePure Store on Amazon](#).

Manufacturer: LivePure

Seller: Filter Monster

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question