## NIXON A1370-5301

# Nixon Corporal SS A346 Watch User Manual

Model: A1370-5301 | Brand: NIXON

## Introduction

Welcome to the user manual for your new Nixon Corporal SS A346. This timepiece, featuring a 48mm watch face and a 24mm stainless steel band in Desert Gold/Arles Blue, is designed for durability and style. With 100m water resistance, it is suitable for various activities. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and optimal performance.

## Key Features

- **Miyota Japanese Quartz 3-Hand Movement:** Ensures precise and reliable timekeeping.
- **Military-Inspired Design:** Features bold printed indices and numbers with custom molded hands for clear readability and a distinctive aesthetic.
- **10 ATM / 100m Water Resistance:** Suitable for swimming, snorkeling, and other water sports, but not for diving.
- **3-Link Stainless Steel Band:** Provides durability and a comfortable fit.

## Product Overview




Figure 1: Front view of the Nixon Corporal SS A346 watch, showcasing the Desert Gold case and band with the Arles Blue dial.




Figure 2: Detailed front view highlighting the military-inspired indices and custom molded hands.



Figure 3: Side profile of the watch, showing the crown and the thickness of the case.




Figure 4: Rear view of the watch, displaying the stainless steel band and the secure clasp mechanism.




Figure 5: Close-up of the watch case back, showing "NIXON", "TAKE CHARGE", "THE CORPORAL", "100 M STAINLESS STEEL", and "JAPAN MOVEMENT" engravings.




Figure 6: The watch face in low light, demonstrating the luminous properties of the hands and hour markers for visibility in the dark.

## Setup

### Setting the Time

1. Gently pull the crown (the small knob on the side of the watch case) outwards to the first click position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

### Adjusting the Band

The stainless steel band may require adjustment to fit your wrist comfortably. This typically involves removing or adding links. It is recommended to have this procedure performed by a professional jeweler or watch repair service to avoid damaging the band or watch. If you have the appropriate tools and experience, you can adjust the links by carefully pushing out the pins that connect them.

## Operating Instructions

Your Nixon Corporal SS A346 watch is designed for straightforward operation. Once the time is set, the Miyota Japanese quartz movement will accurately keep time.

### Water Resistance

This watch is rated for 10 ATM (100 meters) water resistance. This means it is suitable for recreational surfing, swimming, snorkeling, sailing, and water sports. It is **not** suitable for diving. Always ensure the crown is fully pushed in before exposing the watch to water. Avoid operating the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance.

## Maintenance

### Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and band with a soft, damp cloth. For the stainless steel band, a mild soap solution can be used, followed by thorough rinsing and drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

### Battery Replacement

The watch is powered by a product-specific battery (included). When the watch stops or the second hand begins to jump in irregular intervals (indicating a low battery), it is time for a battery replacement. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

### Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Watch not running | Depleted battery | Replace battery (professional service recommended). |
| Time is inaccurate | Crown not fully pushed in; strong magnetic field exposure | Ensure crown is fully pushed in. Keep watch away from strong magnets. If issue persists, seek professional service. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Condensation inside crystal | Compromised water resistance; extreme temperature change | Immediately seek professional service to prevent further damage. Avoid extreme temperature changes. |

## Specifications

**Model Number:** A1370-5301

**Brand:** Nixon

**Movement:** Miyota Japanese Quartz 3-Hand

**Water Resistance:** 10 ATM / 100m

**Watch Face Diameter:** 48mm

**Band Width:** 24mm

**Band Material:** Stainless Steel

**Color:** Desert Gold/Arles Blue

**Package Dimensions:** 4.61 x 3.78 x 3.07 inches

**Item Weight:** 12.31 ounces

**Batteries:** 1 Product Specific battery required (included)

**Department:** Mens

**ASIN:** B0D7N1FL5Q

**Date First Available:** June 20, 2024

## Warranty and Support

For information regarding warranty coverage, service, or technical support for your Nixon Corporal SS A346 watch, please refer to the official Nixon website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
**Nixon Official Website:** www.nixon.com

© 2024 NIXON. All rights reserved.