

Mont Alpi MAi805-DBEV

Mont Alpi MAi805-DBEV Deluxe Outdoor Kitchen Island

Instruction Manual

	Introduction	Product Overview	Setup & Installation	Operating	
Instructions	Maintenance	Troubleshooting	Specifications	Warranty	Support

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Mont Alpi MAi805-DBEV Deluxe Outdoor Kitchen Island. Please read all instructions carefully before assembly, installation, and operation. Retain this manual for future reference.

Safety Information

WARNING: For outdoor use only. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

Always ensure adequate ventilation when operating the grill. Keep children and pets away from the appliance during operation. Do not attempt to modify the appliance. Use only Mont Alpi approved accessories and replacement parts.

2. PRODUCT OVERVIEW

The Mont Alpi MAi805-DBEV Deluxe Outdoor Kitchen Island is a comprehensive outdoor cooking solution featuring a 6-burner gas grill, an infrared side burner, an infrared rear rotisserie burner, a refrigerator, and a sink with faucet. It is constructed from heavy-duty 304 stainless steel and includes elegant waterfall granite countertops.

Key Components & Features

- **6 Tubular Stainless Steel Burners:** High-efficiency main burners for versatile grilling.
- **Infrared Side Burner:** 16" x 14" ceramic infrared burner for searing, pan frying, and boiling.
- **Infrared Rear Rotisserie Burner:** Height-adjustable ceramic burner for rotisserie cooking.
- **MAF Refrigerator:** Outdoor-rated 110-can capacity refrigerator with glass door, blue LED lighting, temperature control, adjustable shelves, and lockable door.

- **Faucet & Sink Combo:** Built-in stainless steel faucet and 12.25"D x 14.5"W x 8.5"D sink with access door/cabinet underneath.
- **Granite Countertops:** White waterfall granite extending down the sides for easy cleaning and aesthetics.
- **LED Knob Lights:** Blue when off, red when on for clear status indication.
- **Internal Cooking Lights:** Bright halogen lights for improved visibility.
- **Electronic Ignition:** For quick and reliable startup.
- **Full Front Pull-Out Grease Tray:** For easy cleaning.
- **Included Accessories:** Heavy-duty rotisserie kit (110V, 4-watt motor, holds up to 25 lbs), propane hose and regulator, white granite chopping board, and a water-resistant outdoor rated black full weather cover.


Product Views



Overall view of the Mont Alpi MAi805-DBEV Deluxe Outdoor Kitchen Island, showcasing the 6-burner grill, sink, and refrigerator modules.



Detailed dimensions of the MAi805-DBEV series, including depth, width, countertop height, and hood closed height.



Close-up view highlighting key grill features such as the infrared rear burner, Accu-Temp thermometer, sear plates, LED illuminated control knobs, and heavy-duty burners.



Detailed view of the outdoor refrigerator, showing its large capacity, lockable door, temperature settings (35F to 67F), and adjustable shelves for various beverage sizes.

Product Video

Your browser does not support the video tag.

This video provides a visual overview of the Mont Alpi 6-Burner 805 Deluxe Series Outdoor Kitchen, showcasing its features and modular design.

3. SETUP & INSTALLATION

The Mont Alpi MAi805-DBEV Outdoor Kitchen Island arrives largely pre-assembled, requiring modular attachment and connection of utilities. Professional installation is recommended for gas and electrical connections.

3.1 Unpacking and Placement

- Carefully unpack all components and inspect for any shipping damage.
- Choose a level, stable outdoor location away from combustible materials. Ensure adequate clearance around the grill for safety and ventilation.
- Position the modular units (grill, side burner, refrigerator/sink) as desired and secure them together according to the provided hardware.

3.2 Gas Connection

- The grill comes ready for propane (LP) use with a hose and regulator. Connect the regulator to a standard 20 lb (or larger) propane tank.
- **Natural Gas Conversion:** The grill is convertible to natural gas (NG). All necessary orifices are pre-installed. To convert, remove the propane orifices from each burner and use the natural gas hose and regulator from the optional Mont Alpi Natural Gas Conversion Kit (sold separately). This conversion should be performed by a qualified gas technician.
- Perform a leak test on all gas connections using a soap and water solution before initial use.

3.3 Electrical Connections

- The grill and refrigerator require 110V power. Utilize the strategically placed access holes at the back of the island for power cords.
- Connect the grill's power cord for the rotisserie motor, internal lights, and LED knob lights.
- Connect the refrigerator's power cord.
- Ensure all electrical connections are to a grounded outlet and protected by a Ground Fault Circuit Interrupter (GFCI).

3.4 Water Connection (Sink)

- Connect the faucet to a cold water supply line using appropriate plumbing fittings.
- Connect the sink drain to a suitable drainage system.
- Check for leaks after connecting water lines.

4. OPERATING INSTRUCTIONS

4.1 Grill Operation

- **Pre-heating:** Open the grill hood. Turn on the gas supply. Push and turn a control knob to the HIGH position. Press the electronic ignition button until the burner ignites. Repeat for desired burners. Close the hood and allow the grill to preheat for 10-15 minutes.
- **Temperature Control:** Adjust burner knobs between HIGH and LOW settings to achieve desired cooking temperature. The integrated thermometer in the hood provides temperature readings.
- **Internal Lights:** Activate the internal halogen cooking lights for better visibility during evening use.
- **LED Knobs:** Knobs illuminate blue when off and red when on, indicating active burners.

4.2 Infrared Side Burner

- Open the side burner lid. Turn the side burner control knob to HIGH and press the ignition button.
- Use for searing, pan frying, or boiling. The side burner features two grate settings for different cooking needs.
- When not in use, ensure the cover is flush with the side shelf for a usable flat surface.

4.3 Rotisserie System

- Attach the rotisserie rod and forks to the motor. Secure meat onto the rotisserie rod.
- Position the rotisserie assembly over the grill.
- Turn on the rear infrared rotisserie burner and activate the rotisserie motor.
- Ensure a drip pan is placed underneath the meat to catch juices and prevent flare-ups.

4.4 Refrigerator

- Plug in the refrigerator to a 110V GFCI outlet.
- Adjust the temperature control knob inside the unit to your desired cooling level (35°F to 67°F).
- Utilize the adjustable shelves for optimal storage of beverages.
- The door can be locked for security.

4.5 Sink and Faucet

- Turn on the water supply to the faucet.
- Use the sink for washing hands, cleaning utensils, or preparing food.
- Ensure the drain is clear to prevent blockages.

5. MAINTENANCE & CLEANING

Regular maintenance ensures the longevity and optimal performance of your outdoor kitchen.

5.1 General Cleaning

- **Stainless Steel Surfaces:** Clean with a soft cloth and a stainless steel cleaner. Always wipe in the direction of the grain to prevent scratching. Avoid abrasive cleaners or scouring pads.
- **Granite Countertops:** Wipe with a damp cloth and mild soap. Avoid harsh chemicals or acidic cleaners that can damage the granite.
- **Cooking Grids:** Clean after each use with a grill brush while the grill is still warm. For stubborn residue, soak in warm, soapy water and scrub.
- **Grease Tray:** Regularly remove and empty the full front pull-out grease tray. Clean with warm, soapy water.
- **Sink:** Clean with mild dish soap and water. Rinse thoroughly.

5.2 Seasonal Maintenance

- **Burners:** Periodically inspect burner ports for blockages (e.g., spider webs, food debris). Clean with a wire brush or pipe cleaner.
- **Gas Hoses & Connections:** Inspect hoses for cracks, cuts, or excessive wear. Check all gas connections for leaks annually.
- **Weather Cover:** Use the provided weather-resistant cover when the outdoor kitchen is not in use, especially during inclement weather or off-season storage, to protect it from the elements.

6. TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, contact Mont Alpi customer support.

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply; clogged burner port; faulty igniter.	Check propane tank/natural gas supply; clean burner ports; check igniter electrode and wire connections.
Low flame or uneven heat	Low gas pressure; clogged burner ports; regulator issue.	Check gas supply; clean burner ports; reset regulator (if applicable) or replace if faulty.
Refrigerator not cooling	Power issue; temperature setting too high; door not sealed.	Check power connection and GFCI; adjust temperature setting; ensure door is fully closed and seal is intact.
Water leak from sink/faucet	Loose connection; damaged seal.	Tighten connections; inspect and replace seals if necessary.

7. SPECIFICATIONS

Feature	Detail
Model Name	Mont Alpi 805 Deluxe Series with Beverage Center
Model Number	MAi805-DBEV
Product Dimensions (D x W x H)	23" x 132" x 46"
Countertop Height	35"

Feature	Detail
Main Burner Count	6
Side Burner Count	1 (Infrared)
Rear Burner	1 (Infrared Rotisserie)
Total BTU Output	115,000 BTUs (Grill)
Cooking Surface Area	990 Square Inches (38" x 18" main grill)
Fuel Type	Propane (LP) ready, Natural Gas (NG) convertible
Material	304 Stainless Steel, Granite
Refrigerator Capacity	110 Cans
Refrigerator Voltage	110 Volts
Item Weight	990 Pounds
Required Assembly	Yes (Modular attachment)
Indoor/Outdoor Usage	Outdoor

8. WARRANTY INFORMATION

Mont Alpi offers a **15 Year Limited Warranty** on the MAi805-DBEV Deluxe Outdoor Kitchen Island. This warranty covers defects in materials and workmanship under normal use and service. Specific limitations and conditions apply. Please refer to the official Mont Alpi warranty documentation or contact customer support for full details regarding coverage, terms, and how to make a claim.

9. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims regarding your Mont Alpi MAi805-DBEV Deluxe Outdoor Kitchen Island, please contact Mont Alpi customer support.

- **Website:** Visit the official Mont Alpi website for support resources and contact information.
- **Phone/Email:** Refer to your purchase documentation or the Mont Alpi website for the most current contact details.

When contacting support, please have your model number (MAi805-DBEV) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D7N5ZN3B>

More documents and user manuals: <https://manuals.plus/>