

[Manuals.plus](#) /

› [Homedics](#) /

› Homedics SereneScent Waterless Home Fragrance Diffuser Instruction Manual

Homedics ARMH-970CA

Homedics SereneScent Waterless Home Fragrance Diffuser Instruction Manual

MODEL: ARMH-970CA

Product Overview

The Homedics SereneScent Waterless Home Fragrance Diffuser is designed to deliver a clean and natural fragrance experience throughout your home. It uses patented air diffusion technology to create a fine mist of fragrance without requiring water, ensuring a pure scent. This diffuser is compatible with Homedics SereneScent fragrance oils, which are sold separately.

Key features include:

- **Waterless Operation:** Utilizes patented air diffusion technology for an ultra-fine mist without water.
- **Wide Coverage:** Effectively scents rooms up to 1000 sq. ft.
- **Long-lasting Fragrance:** Disperses fragrance for up to 30 days without needing to replenish oil (based on 8 hours/day at middle intensity setting 5).
- **Customizable Settings:** Offers multiple scent intensity options and mist timer settings.
- **Sleek Design:** Constructed from premium aluminum with whisper-quiet, energy-efficient operation.
- **Convenient Control:** Operable via an included remote control or integrated base controls.



The Homedics SereneScent Waterless Home Fragrance Diffuser in Champagne color, shown with its remote control.



Detailed dimensions of the diffuser: 2.79 inches diameter, 11.49 inches height, with a 120ml oil bottle for scale.

Safety Information

Please read and adhere to the following safety guidelines to ensure safe operation and prevent damage to the product or personal injury:

- Avoid direct skin contact with undiluted essential oils.
- Keep the diffuser and fragrance oils out of reach of children and pets.
- Ensure proper ventilation in the area where the diffuser is used.
- Do not immerse the unit in water or any other liquid.
- Use only the provided power adapter.
- Do not attempt to disassemble or repair the unit yourself. Contact qualified service personnel if needed.

Setup

Unpacking

Carefully remove all components from the packaging. Verify that all items listed in the 'What's in the Box' section are present: (1) Homedics SereneScent Waterless Home Fragrance Diffuser, (1) Remote Control, (1) Adapter.

Installing Fragrance Oil

To install the fragrance oil bottle:

1. Gently twist and lift the top section of the diffuser to remove the diffuser head.
2. Twist off the cap from your Homedics SereneScent 120ml oil bottle (sold separately).
3. Carefully twist the oil bottle onto the diffuser head until secure.
4. Insert the diffuser head with the attached oil bottle back into the main unit, ensuring it is properly seated and aligned.



Image demonstrating the waterless design and how to install the fragrance oil bottle into the diffuser.

Video demonstrating the setup and operation of the Homedics SereneScent Waterless Home Fragrance Diffuser.


Operating Instructions

Powering On/Off

To power on the diffuser, press the power button on the integrated base controls or the remote control. Press the power button again to turn the diffuser off.

Adjusting Scent Intensity

The diffuser offers 9 intermittent mist and pause intensity settings. Use the '+' and '-' buttons on the base or remote to increase or decrease the scent intensity. The intensity level display light will illuminate for 60 seconds when adjusted, then turn off while the diffuser continues to operate.



The diffuser's base controls for power, intensity adjustment, and runtime selection.



**1,000 sq ft full
room coverage**





Diagram illustrating the 9 different mist and pause duration settings for scent intensity control.

Setting the Timer

The diffuser features an auto-off timer. You can select runtimes of 1, 2, 4, or 8 hours using the corresponding buttons on the base or remote control. The diffuser will automatically shut off after the selected duration.

getting to know your SereneScent™ diffuser

When left untouched, the LED display light powers off after 60 seconds. Your diffuser is still working even when display is not illuminated. To illuminate, press any button on the diffuser or remote.



The remote control for the Homedics SereneScent Diffuser, featuring power, intensity, and timer buttons.

Maintenance

Cleaning the Diffuser

To maintain optimal performance and prevent residue buildup, it is recommended to clean your diffuser periodically, especially when changing fragrance oils or if you notice a decrease in mist output.

- Unplug the diffuser from the power outlet.
- Remove the fragrance oil bottle and diffuser head.
- Wipe the exterior of the diffuser with a soft, damp cloth.
- For the diffuser head, gently wipe any visible oil residue with a clean, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure all parts are completely dry before reassembling and using the diffuser.

Oil Bottle Replacement

When the fragrance oil bottle is empty, simply twist it off the diffuser head and dispose of it according to local regulations. Replace with a new Homedics SereneScent 120ml oil bottle by twisting it onto the diffuser head until secure.

Troubleshooting

If you encounter issues with your Homedics SereneScent Diffuser, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Diffuser does not turn on.	No power connection; Power button not pressed.	Ensure the power adapter is securely plugged into the diffuser and a working electrical outlet. Press the power button firmly.
No mist or weak mist output.	Oil bottle empty or not properly installed; Diffuser head clogged; Intensity setting too low.	Check if the oil bottle is empty and replace if necessary. Ensure the oil bottle is twisted securely onto the diffuser head. Clean the diffuser head as per maintenance instructions. Increase the intensity setting.

Problem	Possible Cause	Solution
Diffuser shuts off unexpectedly.	Timer setting reached; Loose power connection.	Check the selected timer setting. Ensure the power adapter is securely connected.
Oil residue on surface around diffuser.	Overfilling or improper installation of oil bottle; Unit moved while operating.	Ensure the oil bottle is securely attached and not overfilled. Avoid moving the diffuser while it is operating. Clean any residue immediately.

Specifications

Feature	Detail
Brand	Homedics
Model Name	SereneScent
Item Model Number	ARMH-970CA
Color	Champagne
Product Dimensions	4.41"L x 4.41"W x 11.69"H
Item Weight	3.54 pounds
Power Source	Corded Electric
Capacity	120 Milliliters (oil bottle)
Floor Area Coverage	Up to 1000 Square Feet
Runtime	Up to 30 days (at 8 hours/day, middle intensity)
Auto Shutoff	Yes (Timer-based)
Included Components	Diffuser, Remote Control, Adapter

Warranty and Support

Warranty Information

Homedics products are manufactured with the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official Homedics website. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

If you have any questions, require assistance, or need to report an issue with your Homedics SereneScent Waterless Home Fragrance Diffuser, please contact Homedics Customer Service. Contact details can typically be found on the product packaging, the official Homedics website, or within the warranty documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question