

[Manuals.plus](#) /

› [MCombo](#) /

› MCombo Zero Gravity Power Loveseat Recliner with Console, Heat and Vibration Massage, Reclining Loveseat Sofa with USB Ports, Cup Holders for Living Room, Faux Leather PR622Sets (Light Grey) Light Grey Loveseat with Console Instruction Manual

MCombo PR622Sets

MCombo Zero Gravity Power Loveseat Recliner Instruction Manual

Model: PR622Sets

1. INTRODUCTION

Thank you for choosing the MCombo Zero Gravity Power Loveseat Recliner. This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your new loveseat. Please read it thoroughly before use and retain it for future reference.

This power loveseat features a zero-gravity reclining position, heat and vibration massage functions, USB charging ports, and integrated cup holders for enhanced comfort and convenience.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Always supervise children and pets when using the sofa to prevent entrapment.
- Keep the sofa away from open flames or high heat sources.
- Be cautious when using the heat and vibration functions to avoid burns or discomfort.
- Ensure the sofa is placed at least 8.7 inches away from walls to prevent overheating and potential fire hazards.
- Do not allow children to play on or around the recliner mechanism.
- Avoid placing heavy objects on the footrest when it is extended.
- Unplug the loveseat from the power outlet before cleaning or maintenance.
- Do not attempt to disassemble or repair the electrical components yourself. Contact qualified personnel for service.

3. ASSEMBLY INSTRUCTIONS

The MCombo Zero Gravity Power Loveseat Recliner is designed for easy assembly. All necessary hardware is included. It is recommended to have two people for assembly.

3.1 Unpacking

The product is packed in 4 boxes for easier handling. Carefully unpack all components and verify against the packing list. Ensure no parts are missing or damaged before proceeding.

3.2 Step-by-Step Assembly

- 1. Connect the two base sections of the loveseat. Ensure they are securely latched.
- 2. Attach both armrests to the corresponding sides of the base. Listen for a click to confirm they are locked into place.
- 3. Secure the backrests onto the base. Align the metal brackets on the backrest with the receivers on the base and push down firmly until they click.
- 4. Connect all wiring. Ensure all electrical connections for power, massage, and heat functions are properly plugged in. Refer to the diagram for correct connections.
- 5. Plug the power cord into a grounded electrical outlet.



Dimension

Required Wall Clearance: 8.7"



Figure 3.2.1: Assembly Diagram. This image illustrates the process of connecting the various components of the loveseat during assembly.



3 Positions





Figure 3.2.2: Control Panel and USB Port. This image highlights the location of the control buttons and USB charging port on the side of the loveseat.

4. OPERATING INSTRUCTIONS

Your MCombo loveseat offers multiple comfort features controlled by integrated buttons.

4.1 Reclining Function

Each seat is controlled independently. Locate the two-button control panel on the side of each seat.

- Press and hold the **forward arrow button** to recline the seat and extend the footrest.
- Press and hold the **backward arrow button** to return the seat to the upright position and retract the footrest.
- The loveseat can recline to a 155° zero gravity position, which elevates your legs to be in line with your heart for optimal relaxation.



Recline More, Relax More

Deeper reclining angle makes the chair ideal for napping

Figure 4.1.1: Reclining Positions. This diagram illustrates the various reclining angles, including the zero-gravity position.



12 Vibration Nodes



2 Lumbar Heat

Figure 4.1.2: Zero Gravity Recline. This image demonstrates the full 155-degree recline, ideal for deep relaxation.

4.2 Heat and Vibration Massage

The loveseat features 6 vibrating massage nodes and 2 lumbar heating elements. Controls for these functions are typically integrated into the side control panel or a separate remote (if included).

- Activate the massage function by pressing the designated massage button. Cycle through modes and intensities as desired.
- Activate the heat function by pressing the designated heat button.
- Some models may include a timer function for massage and heat.



Figure 4.2.1: Massage and Heat Zones. This diagram illustrates the distribution of vibration nodes and heating elements within the loveseat.

4.3 USB Charging Ports

The integrated USB ports allow you to charge your devices conveniently while relaxing. Simply plug your USB cable into the port located on the control panel.

4.4 Console and Cup Holders

The center console provides storage space. Lift the lid to access the compartment. The console also includes two cup holders for beverages.



Figure 4.4.1: Center Console Storage. This image shows the internal storage compartment of the loveseat's console.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your loveseat.

- **Cleaning Faux Leather:** Wipe clean with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **General Cleaning:** Regularly vacuum the loveseat to remove dust and debris.
- **Mechanism Care:** The reclining mechanism is designed for durability. Avoid forcing the mechanism. Periodically check for loose screws and tighten if necessary.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.

6. TROUBLESHOOTING

If you encounter issues with your loveseat, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Loveseat does not recline.	Power cord unplugged; loose connection; power outage.	Check power cord connection to outlet and loveseat. Ensure power outlet is functional. Verify all internal wiring connections are secure.
Massage/Heat function not working.	Loose wiring; function not activated; internal fault.	Check all wiring connections. Ensure the correct buttons are pressed. If problem persists, contact customer support.
Footrest does not extend/retract smoothly.	Obstruction; mechanism needs lubrication; damaged mechanism.	Check for any objects obstructing the footrest. Apply silicone-based lubricant to moving parts if needed. If damaged, contact customer support.
Unusual noises during operation.	Loose hardware; foreign object in mechanism.	Inspect for loose screws and tighten. Check for any foreign objects. If noise persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model	PR622Sets
Type	Power Loveseat Recliner with Console
Color	Light Grey
Material	Faux Leather (Artificial Leather)
Product Dimensions (D x W x H)	29.1"D x 69.9"W x 42.1"H
Item Weight	194.7 Pounds
Weight Limit	640 Pounds
Seat Height	18.92 Inches
Seat Depth	21.7 inches
Reclined Length	72.4 Inches
Reclining Angle	Up to 155° (Zero Gravity)
Massage Nodes	6 Vibration Points
Heat Zones	2 Lumbar Heat
USB Ports	Included
Cup Holders	4 (2 on each armrest, 2 in console)
Frame Material	Reinforced Steel + FSC-certified Wood
Assembly Required	Yes
Wall Clearance Required	8.7 Inches



Figure 7.1: Product Dimensions. This image provides a comprehensive overview of the loveseat's measurements and required space.

8. WARRANTY AND SUPPORT

MCombo stands behind the quality of its products.

8.1 2-Year Limited Warranty

Your MCombo Zero Gravity Power Loveseat Recliner is covered by a 2-Year Limited Warranty. This warranty protects your investment with free replacements for:

- Reclining mechanisms
- Electrical systems
- Upholstery & cushions
- Frame structures (wood/metal)

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, concerns, or warranty claims, please contact MCombo Customer Support. Contact information can typically be found on the MCombo official website or through your purchase platform.

You can also visit the [MCombo Store on Amazon](#) for more information and support resources.