

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hot Wheels](#) /

› [Hot Wheels Barbie RC Toy Car Instruction Manual](#)

Hot Wheels JBH05

Hot Wheels Barbie RC Toy Car Instruction Manual

Model: JBH05 | Brand: Hot Wheels

INTRODUCTION

Welcome to the world of remote-control fun with your new Hot Wheels Barbie RC Toy Car. This pink convertible is designed to provide an engaging play experience, allowing two Barbie dolls to ride in style. It features two distinct driving modes and comes with a sticker sheet for personalized customization. Please read this manual thoroughly before use to ensure proper operation and maintenance.

WHAT'S INCLUDED

Your Hot Wheels Barbie RC Toy Car package includes the following components:

- 1 Hot Wheels RC Barbie Convertible
- 1 Remote Controller
- 1 Sticker Sheet for Customization



Image: The Hot Wheels Barbie RC Convertible, its remote controller, and the included sticker sheet.



Image: The Hot Wheels Barbie RC Convertible displayed within its retail packaging.

SETUP

Battery Installation

The RC car and remote controller require batteries for operation. Please ensure you have the correct type and quantity of batteries as specified below:

- **Remote Controller:** Requires 2 AAA batteries (not included).
 - **RC Car:** Requires batteries (type and quantity not specified in provided data, typically AA or rechargeable pack for RC cars. User should refer to product packaging for exact details).
1. Locate the battery compartment on the back of the remote controller.
 2. Open the battery compartment cover.
 3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
 4. Close the battery compartment cover securely.
 5. For the RC car, locate its battery compartment (usually on the underside).
 6. Open the car's battery compartment and insert the required batteries, observing polarity.
 7. Close the car's battery compartment securely.

Important: Always use fresh batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.

OPERATING INSTRUCTIONS

Pairing the Remote Controller

Before first use, ensure the RC car and remote controller are paired. Turn on both the car and the remote. The indicator light on the remote should confirm a successful connection. If not, turn both off and on again, or refer to the specific pairing instructions on the product packaging if available.

Driving Modes

The Hot Wheels Barbie RC Toy Car features two distinct driving modes:

- **Story Mode:** Designed for imaginative play and slower, controlled movements, ideal for indoor adventures.
- **Speeder Mode:** Provides increased speed for more dynamic driving, suitable for open spaces.

Refer to the remote controller's markings or the product packaging for instructions on how to switch between these modes.

Basic Controls

Use the joysticks or buttons on the remote controller to maneuver the RC car:

- **Forward/Backward:** Typically controlled by one joystick (push forward/pull back).
- **Left/Right:** Typically controlled by the other joystick (push left/right) or by turning the forward/backward joystick while moving.



*FITS 2 BARBIE DOLLS
(DOLLS SOLD SEPARATELY.)*

Image: The RC car with two Barbie dolls seated comfortably, demonstrating its capacity.



Image: A rear view of the pink RC car, highlighting its design and trunk area.

Trunk Storage

The RC car features an opening trunk for storing small accessories. Gently lift the trunk lid to access the storage compartment. Ensure the trunk is closed before operating the car at high speeds.



***STORE ACCESSORIES IN THE TRUNK
(ACCESSORIES SOLD SEPARATELY.)***

Image: A hand demonstrating how to open the trunk of the RC car for accessory storage.

CUSTOMIZATION

Personalize your RC car with the included sticker sheet. Carefully peel off the desired stickers and apply them to the car's surface. Ensure the surface is clean and dry for best adhesion. You can arrange them in any pattern you like to create a unique look.



Image: A child engaged in applying stickers to the RC car, showcasing the customization feature.



INCLUDES STICKERS FOR CUSTOMIZATION

Image: A close-up view of a child's hand carefully placing a sticker on the front of the RC car.

MAINTENANCE

Cleaning

To clean the RC car, wipe it with a soft, damp cloth. Do not immerse the car or remote controller in water. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish or electronic components.

Storage

When not in use, store the RC car and remote controller in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries from both the car and the remote if storing for extended periods to prevent battery leakage and corrosion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
----------------	-----------------------	-----------------

Problem	Possible Cause	Solution
Car does not respond to remote.	Batteries are low or incorrectly installed. Car and remote are not paired. Out of range.	Replace batteries in both car and remote; check polarity. Turn both car and remote off, then on again to re-pair. Move closer to the car.
Car moves slowly or erratically.	Low batteries. Obstruction in wheels.	Replace batteries. Check and clear any debris from the wheels.
Trunk is difficult to open.	New product stiffness.	Gently apply pressure to open. It may loosen with use.

SPECIFICATIONS

- **Model:** JBH05
- **Product Dimensions:** 12.99 x 5.98 x 3.5 inches
- **Item Weight:** 1.91 pounds
- **Manufacturer Recommended Age:** 4 years and up
- **Batteries (Remote):** 2 AAA batteries (not included)
- **Manufacturer:** Mattel

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Mattel website. Keep your purchase receipt as proof of purchase.

You can visit the official Hot Wheels store for more information on products: [Hot Wheels Store](#)