

[Manuals.plus](#) /

› [Potlimepan](#) /

› Potlimepan 1500W Deep Steam Cleaner User Manual

Potlimepan WJ528(NK-0697)

Potlimepan 1500W Deep Steam Cleaner Instruction Manual

Model: WJ528(NK-0697)

1. INTRODUCTION

The Potlimepan 1500W Deep Steam Cleaner is a versatile and chemical-free cleaning solution designed for various surfaces in your home, including floors, upholstery, carpets, countertops, tiles, and windows. Its powerful 4-bar steam pressure and 1500W heating element provide effective cleaning for stubborn stains and general sanitization.

This portable steam cleaner features a lightweight design and wheels for easy maneuverability. It also includes convenient on-board storage for many of its accessories, ensuring a tidy and organized cleaning experience.

Safety Information

- Always ensure the steam cleaner is cold and depressurized before opening the water tank or refilling.
- Do not open the safety valve when the steam cleaner is hot.
- Keep out of reach of children and pets.
- Refer to the troubleshooting section for common issues and safety tips.



Figure 1: The Potlimepan Steam Cleaner showcasing its portable design with on-board storage, easy-carry handle, wheels, and extended reach with its long cord and tube.

2. PRODUCT COMPONENTS

Your Potlimepan Steam Cleaner comes with 14 essential accessories to tackle various cleaning tasks. Please ensure all parts are present upon unboxing. Some smaller parts are stored within the on-board compartment.

14 ACCESSORIES

- | | |
|---|----------------------------------|
| ① Floor Brush | ⑧ Floor Brush Connector |
| ② Window Brush | ⑨ Straight Adaptor |
| ③ Window brush can be detachable to be a fabric steamer | ⑩ Extra Attachment: Mirror Cloth |
| ④ Extension Tube X2 | ⑪ Floor Brush Cloth X2 |
| ⑤ Big Nylon Utility Round Brush | ⑫ Fabric Steamer Cloth |
| ⑥ Small Nylon Utility Round Brush | ⑬ Measuring Cup |
| ⑦ Nozzle | ⑭ Funnel |



Figure 2: Overview of the 14 accessories included with your steam cleaner, designed for comprehensive cleaning.

Included Accessories List:

1. Floor Brush
2. Window Brush (detachable for fabric steaming)
3. Extension Tube (x2)
4. Big Nylon Utility Round Brush
5. Small Nylon Utility Round Brush
6. Nozzle
7. Floor Brush Connector
8. Straight Adaptor
9. Extra Attachment: Mirror Cloth
10. Floor Brush Cloth (x2)
11. Fabric Steamer Cloth
12. Measuring Cup

13. Funnel

Note: The adaptor & floor brush connector, 2 round brushes, and nozzle are stored within the built-in storage compartment. Please open the on-board storage to locate these parts.

3. SETUP

Follow these steps for initial setup and preparing your steam cleaner for use:

1. Ensure the steam cleaner is cold and depressurized.
2. Open the large black knob on the top of the unit.
3. Using the included funnel and measuring cup, carefully pour up to 2 cups (1.5L) of cool water into the tank. Do not overfill.
4. Securely close the black knob.
5. Plug the steam cleaner into a power outlet.
6. Press the large black rubber button on top to power on the unit. The red and orange indicator lights will illuminate.
7. Allow approximately 9 minutes for the unit to preheat to 212°F (100°C). The orange light will turn off when it's ready for the first use.

1500W Steam Cleaner

1.5L

Large Capacity
Water Tank

Preheats in

9 mins

40 mins

of Steam

Only water
chemicals Free

Figure 3: Filling the steam cleaner's 1.5L water tank. The unit preheats in 9 minutes and provides up to 40 minutes of steam.



Figure 4: Indicator lights for power and heating status. The unit can continue to be used even if the heating light cycles on and off during operation.

4. OPERATING INSTRUCTIONS

Once the steam cleaner is ready, you can begin your cleaning tasks. The unit provides approximately 40 minutes of continuous steam from a full tank.

Continuous Steaming

For extended cleaning without constantly holding the trigger, you can lock the steam gun. Press the safety lock during use, and the unit will continue to emit steam.

Steam Cleaner Emit Steam Continuously Without Keep Pressing



Figure 5: The steam gun features a safety lock for continuous steam emission, reducing hand fatigue during prolonged use.

Cleaning Applications

Attach the appropriate accessory for your cleaning needs. The steam cleaner is effective on a wide range of surfaces:

- **Floors:** Use the Floor Brush with a Floor Brush Cloth.
- **Upholstery & Carpets:** Utilize the Fabric Steamer Cloth or appropriate brushes.
- **Windows & Mirrors:** The Window Brush is ideal. For streak-free results, use the Extra Attachment Mirror Cloth (see special instructions below).
- **Tile & Grout:** Nylon Utility Round Brushes and the Nozzle are effective for deep cleaning grout lines.
- **Stubborn Stains:** The high-pressure steam combined with the appropriate brush can help lift tough stains from various surfaces.
- **Wallpaper Removal:** The Wall Scraper attachment softens adhesive for easy removal.

Deep Steam Cleaner



Floor Brush
to clean floor




Window Brush
to clean window/mirror



Nylon Brush
to remove stains



Nozzle
to clean corner



Mirror Cloth
to clean mirror/
window



Window Brush
can be detachable
to be a fabric steamer

Figure 6: Examples of the steam cleaner's versatility across different surfaces and cleaning tasks.

Special Instructions for Mirror Cloth

The included mirror cloth is designed for streak-free cleaning on glass, mirrors, and stainless steel appliances. For optimal performance, it is crucial to get this cloth wet before use. When dry, it may appear flat and stiff. Once wet and wrung out, it becomes soft and effective.

Your browser does not support the video tag.

Video 1: Demonstration of how to properly wet and use the mirror cloth for streak-free cleaning on various surfaces like faucets and mirrors.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your steam cleaner.

Refilling the Water Tank

If the water tank needs refilling during use, always ensure the unit is completely cool and depressurized before attempting to open the safety valve. This is a critical safety measure.



Figure 7: The safety valve on the steam cleaner. Always allow the unit to cool down and depressurize before refilling the water tank.

Cleaning Accessories

- Mop pads and fabric steamer cloths are machine washable or can be easily hand washed in a sink.
- Rinse other accessories with clean water after each use to remove any residue.
- Store all accessories in the on-board storage compartment or a dry place when not in use.

6. TROUBLESHOOTING

This section addresses common questions and safety tips for your steam cleaner.

- **Orange Heating Light Cycles On/Off:** It is normal for the orange heating indicator light to go on and off during use. This indicates the unit is maintaining its optimal temperature. You do not need to stop cleaning; you can continue using the steam cleaner.
- **Cannot Open Safety Valve:** The safety valve is designed not to open when the steam cleaner is hot or pressurized for safety purposes. Ensure the unit is completely cool and has zero pressure before attempting to open the valve for refilling.
- **Missing Parts:** Please check the on-board storage compartment for the adaptor & floor brush connector, 2 round brushes, and nozzle. These parts are designed to be stored there.

7. SPECIFICATIONS

Feature	Detail
Brand	Potlimepan
Model Name	WJ528(NK-0697)
Wattage	1500W
Tank Volume	1.5 Liters (approx. 51 oz)
Maximum Temperature	212°F (100°C)
Preheat Time	Approx. 9 minutes
Continuous Steam Time	Approx. 40 minutes
Steam Pressure	4 bar
Power Source	AC
Voltage	120 Volts
Item Weight	12.38 pounds
Dimensions (Package)	21.61 x 13.58 x 11.89 inches
Special Features	Child Lock, Steam Control, Steam Ready Indicator, Swivel Head, Lightweight, Carry Handle, Portable, Onboard Storage, Compact Design, Removable Nozzle
Surface Recommendation	Floor, Upholstery, Carpet, Counter Top, Tile, Window

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact information provided with your product packaging or visit the official Potlimepan website. Keep your purchase receipt for warranty claims.

© 2024 Potlimepan. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D7Q3VP5K>

More documents and user manuals: <https://manuals.plus/>