

[manuals.plus](#) /› [Xgody](#) /› [XGODY S200 Flip Phone User Manual](#)

Xgody S200

XGODY S200 Flip Phone User Manual

1. INTRODUCTION

Welcome to the user manual for your new XGODY S200 Flip Phone. This device is designed for ease of use, featuring large buttons, a clear display, and essential functions for reliable communication. Please read this manual carefully to understand how to operate your phone safely and efficiently.

2. PACKAGE CONTENTS

Please check the box for the following items:

- XGODY S200 Flip Phone
- Rechargeable Battery
- USB Type-C Charging Cable
- Power Adapter
- User Manual

3. DEVICE OVERVIEW

Familiarize yourself with the key components of your XGODY S200 Flip Phone.



Figure 3.1: Front view of the XGODY S200 flip phone in its open position, displaying the screen and large keypad.

1300mAh Akku mit großer Kapazität

Super lange Standby-Zeit, kein häufiges Aufladen erforderlich



1300mAh




Figure 3.2: Detail of the XGODY S200's side, showing the USB Type-C charging port, 3.5mm headphone jack, and a flashlight.

3.1. Keypad Layout

- **Navigation Keys:** Up, Down, Left, Right, and OK/Confirm button in the center.
- **Call Key:** Green button to make or answer calls.
- **End/Power Key:** Red button to end calls or power the phone on/off.
- **SOS Key:** Dedicated button for emergency calls (often on the back or side).
- **Numeric Keypad:** Large, easy-to-read buttons for dialing numbers and text input.

4. SETUP

4.1. Installing the Battery

1. Open the back cover of the phone by gently prying it from the notch.

2. Align the battery contacts with the terminals inside the phone.
3. Press the battery down firmly until it is securely in place.
4. Replace the back cover, ensuring it clicks into position.

4.2. Installing the SIM Card(s)

The XGODY S200 supports dual SIM cards.

1. With the battery removed, locate the SIM card slot(s).
2. Insert your SIM card(s) into the slot(s) with the gold contacts facing down and the cut corner aligned as indicated.
3. Ensure the SIM card(s) are fully inserted.
4. Reinstall the battery and back cover.

4.3. Charging the Phone

1. Connect the USB Type-C cable to the charging port on the side of the phone.
2. Plug the other end of the cable into the power adapter, then plug the adapter into a wall outlet.
3. The battery icon on the screen will indicate charging status.
4. Charge the phone fully before first use (approximately 2-3 hours).

5. OPERATING YOUR PHONE

5.1. Power On/Off

- **To Power On:** Press and hold the Red End/Power Key until the screen lights up.
- **To Power Off:** Press and hold the Red End/Power Key until the power-off options appear, then select 'Power Off'.

5.2. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Green Call Key.
- **Answering a Call:** When the phone rings, press the Green Call Key.
- **Ending a Call:** Press the Red End/Power Key.




Figure 5.1: The XGODY S200 features loud and clear call volume, beneficial for users with hearing impairments.

5.3. Contacts (Phonebook)

1. From the main screen, navigate to 'Contacts' or 'Phonebook' using the navigation keys and press the OK key.
2. Select 'Add New Contact' to save a number.
3. Enter the name and phone number, then save.

5.4. SOS Emergency Function

The SOS function allows you to quickly contact pre-set emergency numbers.

SOS-Notrufe

Unterstützen Sie 5 Familiennummern

- Garantieren Sie die Sicherheit
älterer Menschen




Figure 5.2: Illustration of the SOS emergency call feature, allowing users to quickly contact up to five pre-set family members or emergency services.

- Setting up SOS Numbers:** Go to 'Settings' > 'SOS Settings' and add up to 5 emergency contacts.
- Activating SOS:** Press and hold the dedicated SOS button (usually on the back or side of the phone) for a few seconds. The phone will automatically dial the pre-set numbers in sequence until one is answered. It may also send an emergency SMS.

5.5. FM Radio

To use the FM Radio, you may need to connect headphones (not always included) as they often act as an antenna.

1. Navigate to 'FM Radio' from the main menu.
2. Use the navigation keys to scan for stations or manually tune.

5.6. Flashlight

The phone includes a built-in flashlight for convenience.



**3 Sekunden lang drücken, um das
Licht sofort einzuschalten**



Figure 5.3: An image demonstrating the built-in flashlight feature of the XGODY S200, activated by a long press, providing convenience in low-light conditions.

- **To Turn On/Off:** Press and hold the dedicated flashlight button (if available) or a specific key combination as indicated in the phone's quick guide.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid liquid cleaners.
- **Battery Care:** Do not expose the battery to extreme temperatures. If the phone will not be used for an extended period, charge it partially before storing.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.

7. TROUBLESHOOTING

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly installed and fully charged. Try charging the phone for at least 30 minutes.
Cannot make or receive calls	Check if the SIM card is properly inserted. Ensure you have network signal. Contact your service provider if the issue persists.
Poor call quality	Move to an area with better network reception. Ensure the microphone and speaker are not obstructed.
Battery drains quickly	Reduce screen brightness. Close unused applications. If the battery is old, consider replacing it.
SOS function not working	Verify that emergency numbers are correctly set in the SOS settings. Ensure the phone has network signal.

8. SPECIFICATIONS

Feature	Detail
Brand	Xgody
Model Name	S200
Operating System	Basic OS
Screen Size	2.4 Inches
Resolution	240 x 320
RAM Size	32 MB
Memory Storage Capacity	32 MB
Wireless Carrier	All carriers (unlocked)
Cellular Technology	2G
Connectivity Technology	2G (GSM)
Battery	1 Lithium-polymer (included)
Charging Port	USB Type-C

9. WARRANTY AND SUPPORT

Specific warranty details for the XGODY S200 Flip Phone are not provided within this manual. For warranty information, technical support, or service inquiries, please refer to the documentation included with your purchase or visit the official XGODY website. Keep your proof of purchase for any warranty claims.

Related Documents - S200

 X31 Mobile Phone User Manual	<p>XGODY X31 Mobile Phone User Manual</p> <p>User manual for the XGODY X31 mobile phone, covering product overview, getting started, settings, and troubleshooting.</p>
 X32 Mobile Phone User Manual	<p>XGODY X32 Mobile Phone User Manual</p> <p>Comprehensive user guide for the XGODY X32 smartphone, covering product overview, setup, settings, and troubleshooting. Available in English, German, Spanish, French, and Italian.</p>
 X36 Mobile Phone User Manual	<p>XGODY X36 Mobile Phone User Manual</p> <p>Comprehensive user manual for the XGODY X36 mobile phone, covering setup, features, and troubleshooting. Includes manufacturer details and support links.</p>
 ANDROID TABLET QUICK START GUIDE Model: N01	<p>XGODY N01 Android Tablet Quick Start Guide</p> <p>Get started with your XGODY N01 Android Tablet. This guide provides essential setup, operational, and connectivity information for users.</p>

 XGODY Linking People X60 Mobile Phone User Manual	<p><u>X60 Mobile Phone User Manual - Getting Started and Troubleshooting</u></p> <p>Comprehensive user manual for the X60 Mobile Phone, covering setup, basic operations, troubleshooting common issues, and FCC compliance information. Learn how to install SIM cards, power on/off, manage battery, take screenshots, and resolve connectivity or performance problems.</p>
	<p><u>XGODY Tablet User Manual - Setup, Features, and Troubleshooting Guide</u></p> <p>Comprehensive user guide for the XGODY Tablet, covering setup, basic operations, connectivity, app management, troubleshooting, and technical specifications. Learn how to maximize your XGODY tablet experience.</p>


Documents - Xgody – S200



EU Declaration of Conformity for XGODY Cell Phones

This EU Declaration of Conformity certifies that XGODY cell phone models X17, X18, S21, S22, S23, Mate 60, Mate 70, A54, X31, S200, and Y13 Pro comply with the RED Directive 2014/53/EU and relevant harmonized standards for safety and performance.

lang:en score:20 filesize: 938.33 K page_count: 1 document date: 2024-07-04



Elenco di Compatibilità Periferiche TIM I love games

Scopri l'elenco completo dei dispositivi e periferiche compatibili con i servizi TIM I love games, inclusi smartphone, tablet e altri modelli di Acer, Alcatel, e molti altri marchi.