Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC SPPA7BT

JVC SPPA7BT Illuminated Portable Wireless Speaker

User Manual

Introduction

Thank you for purchasing the JVC SPPA7BT Illuminated Portable Wireless Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.
This speaker combines dynamic sound with portability, offering features such as Bluetooth 5.0 connectivity, True Wireless Stereo (TWS) capability for pairing two speakers, USB-C charging, AUX input, and multi-color illumination. Its IPX5 water resistance makes it suitable for various environments.

Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Keep the speaker away from medical devices.
- Dispose of batteries and electronic components according to local regulations.
- Ensure the charging port is dry before connecting the USB-C cable.

Package Contents

Verify that all items are present in the package:

- JVC SPPA7BT Portable Wireless Speaker
- User Manual
- USB Charging Cable
- Detachable Shoulder Strap

Product Overview

Familiarize yourself with the speaker's components and controls.



Figure 1: Front view of the JVC SPPA7BT speaker, showing the control panel on top and the JVC logo on the grille.

Control Panel and Ports:

- **Power Button:** Press and hold to turn on/off.
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Up/Next Track Button:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track Button:** Short press for volume down, long press for previous track.

- **Light Mode Button:** Press to cycle through illumination modes.
- **TWS Button:** Press to initiate True Wireless Stereo pairing.
- **USB-C Charging Port:** For charging the speaker.
- **AUX Input:** 3.5mm jack for wired audio connection.

Setup

1. Charging the Speaker

1. Connect the provided USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a compatible USB power adapter (not included).
3. The charging indicator light will illuminate. It will turn off or change color when fully charged.
4. A full charge provides up to 6 hours of playtime.

2. Powering On/Off

- To power on, press and hold the Power Button until you hear an audible prompt and the indicator lights turn on.
- To power off, press and hold the Power Button again until you hear an audible prompt and the indicator lights turn off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicator light will flash).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "JVC SPPA7BT" from the list of devices.
4. Once paired, the speaker will emit an audible confirmation, and the indicator light will remain solid.

4. True Wireless Stereo (TWS) Pairing

TWS allows you to connect two JVC SPPA7BT speakers for a stereo sound experience.



Figure 2: Two JVC SPPA7BT speakers paired for True Wireless Stereo (TWS) playback.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS Button. The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for and connect to the second speaker.
4. Once connected, both speakers will emit an audible confirmation, and their indicator lights will synchronize.
5. Now, pair your mobile device to the primary speaker via Bluetooth as described in step 3.

Operating

1. Basic Audio Controls

- **Play/Pause:** Press the Play/Pause Button.
- **Volume Up:** Short press the Volume Up/Next Track Button.
- **Volume Down:** Short press the Volume Down/Previous Track Button.

- **Next Track:** Long press the Volume Up/Next Track Button.
- **Previous Track:** Long press the Volume Down/Previous Track Button.

2. Illumination Modes

The speaker features multiple illumination modes to enhance your listening experience.



Figure 3: Examples of the multi-color illumination modes available on the speaker.

- Press the Light Mode Button to cycle through the available illumination patterns.
- Continue pressing until you find your desired mode or to turn the lights off.

3. AUX Input

To connect an audio device via a 3.5mm audio cable (not included):

1. Connect one end of the 3.5mm audio cable to the speaker's AUX input port.
2. Connect the other end to the audio output jack of your device.

3. The speaker will automatically switch to AUX mode.

4. Hands-Free Calling and Voice Assistant

- When connected via Bluetooth, incoming calls will pause music playback. Press the Play/Pause Button to answer or end a call.
- To activate your device's voice assistant (e.g., Siri), long press the Play/Pause Button.

Maintenance

1. Cleaning

- Wipe the speaker with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

2. Water Resistance (IPX5)

The JVC SPPA7BT speaker is rated IPX5, meaning it is protected against low-pressure water jets from any direction. This makes it suitable for use near pools or in light rain.



Figure 4: The speaker is designed to withstand splashes and light rain.

- Do not submerge the speaker in water.
- Ensure the USB-C charging port and AUX input are securely covered or dry before exposure to water.

3. Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its lifespan.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; speaker is already connected to another device.	Ensure speaker is in pairing mode (flashing indicator). Turn Bluetooth off/on on your device. Disconnect from other devices.
No sound.	Volume is too low; device is not playing audio; incorrect input mode.	Increase speaker and device volume. Ensure audio is playing on your device. Check if AUX cable is connected and switch to AUX mode if necessary.
TWS pairing fails.	Speakers are too far apart; one speaker is already paired to a device.	Ensure speakers are within close proximity. Disconnect both speakers from any Bluetooth devices before initiating TWS pairing.
Illumination lights are off or not changing.	Lights are turned off; a specific mode is selected.	Press the Light Mode Button repeatedly to cycle through modes or turn lights on.

Specifications

Feature	Detail
Model Number	SPPA7BT
Speaker Maximum Output Power	30 Watts
Connectivity Technology	Bluetooth 5.0, USB, AUX
Bluetooth Range	Up to 10 Meters (33 Feet)
Battery Type	2 Lithium Ion batteries (included)
Battery Capacity	3000 Milliamp Hours
Battery Life	Up to 6 hours
Water Resistance Level	IPX5 (Water Resistant)
Product Dimensions	6.5"D x 12.68"W x 5.75"H
Item Weight	3.96 pounds
Material	Acrylonitrile Butadiene Styrene (ABS)
Audio Output Mode	Stereo (with TWS)
Special Features	LED Light, Portable, Stereo Pairing (TWS), USB Port, Waterproof
UPC	046838503818

Warranty Information

This product is covered by a Limited Warranty provided by JVC. Please refer to the warranty card included in your package or visit the official JVC website for detailed terms and conditions regarding warranty coverage, duration, and claims procedures.

Support Information

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact JVC customer support. Contact information can typically be found on the official JVC website or on the product packaging.
You may also visit the JVC Brand Store on Amazon for additional product information and resources.

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7QZL2HM

More documents and user manuals: **https://manuals.plus/**