Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweiko jw7976

Sweiko Telescopic Bar Table Instruction Manual

Model: jw7976

Introduction

Thank you for purchasing the Sweiko Telescopic Bar Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

Important Note:

Your purchase will be delivered in two separate packages. These packages may not arrive simultaneously on the same day. Please allow 2-3 days for the second package to arrive after receiving the first. If you have any questions, please contact customer service immediately.

Safety Information

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws or bolts.
- Keep children and pets away during assembly.
- Do not stand or climb on the product.
- Place the product on a level surface.
- Maximum weight capacity for the tabletop is 50 kg. Do not exceed this limit.

Package Contents

Before assembly, verify that all components are included in your packages. The product includes:

- 1 x Telescopic Bar Table unit
- Assembly instructions
- Mounting hardware (screws, bolts, etc.)

Note: This product is shipped in 2 packages.

Setup and Assembly

Assembly is required for this product. It is recommended that 2 people assemble this unit.

Required Tools (Not included unless specified):

- Hammer
- Wrench
- Screwdriver

All necessary mounting tools are included in the package.

Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface.
2. Identify all parts using the provided parts list in the separate assembly instructions.
3. Follow the step-by-step diagrams and instructions in the included assembly manual to connect the frame components.
4. Attach the tabletop to the assembled frame, ensuring all connections are secure.
5. Install the storage shelves and cabinet doors as per the instructions.
6. Connect the LED light strip according to the electrical connection guide.
7. Ensure all screws and fasteners are tightened securely, but do not overtighten.




Figure 1: Product Dimensions. The table measures 39 cm deep, 193 cm wide (extended), and 105 cm high. The storage unit is 102 cm high, and the bar section is 105 cm high.



Figure 2: Various configurations of the telescopic bar table, demonstrating its flexibility and space-saving design. The bar can be rotated and extended to suit different spatial needs.

Operating Instructions

Telescopic and Rotational Function:

The bar table features a 360-degree free rotation and an extendable design. To adjust the table, gently slide the movable section to extend or retract it. For rotation, carefully pivot the bar section to your desired angle. Ensure the table is stable after adjustment.

Storage Compartments:

The table includes three levels of storage integrated into the side bar and additional cabinet storage. Use these compartments for organizing items such as bottles, glassware, or other dining essentials.



Figure 3: Key features of the bar table, including the durable MDF desktop, 360-degree rotation mechanism, integrated side storage, and stylish Changhong glass cabinet doors.

LED Light Strip Operation:

The integrated colorful LED strip can be controlled via a button or a smartphone application. To use the smartphone control, scan the QR code located on the light strip's switch. This allows you to change light colors and create various ambient settings.



Figure 4: LED light strip operation. The image shows the light strip, its control button, and instructions to scan a QR code for smartphone control to adjust colors and effects.

Maintenance

Proper care will ensure the longevity and appearance of your Sweiko Telescopic Bar Table.

- **Cleaning:** Wipe the surface with a damp cloth and dry immediately with a clean, soft cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Clean spills immediately to prevent staining, especially on the wooden surfaces.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Placement:** Avoid placing the table in direct sunlight or near heat sources to prevent material damage or discoloration.

Troubleshooting

Problem	Possible Cause	Solution
Table is wobbly after assembly.	Loose fasteners or uneven floor.	Check and tighten all screws and bolts. Ensure the table is on a level surface.
Telescopic mechanism is stiff.	Dust accumulation or lack of lubrication.	Clean the sliding tracks. Apply a small amount of silicone-based lubricant if necessary (avoid oil-based lubricants).
LED light strip not working.	Power connection issue or faulty strip.	Check if the power adapter is securely plugged in. Ensure the light strip is correctly connected. If issues persist, contact customer support.
Cabinet doors do not close properly.	Misaligned hinges or obstruction.	Adjust the hinges as per assembly instructions. Remove any obstructions.

Specifications

Brand: Sweiko

Model Name: table de salle (Model Number: jw7976)

Product Dimensions (D x W x H): 39D x 193B x 105H cm (Extended)

Minimum Length (Folded): 138 cm

Item Weight: 50 Kilograms

Recommended Maximum Weight Capacity: 50 Kilograms

Material: Composite Wood (Particleboard)

Color: White

Style: Modern

Special Features: Extendable, 360-degree Swivel Base, LED Light Strip, Multiple Storage Levels

Assembly Required: Yes (Recommended 2 people)

Included Components: Bar Table, Assembly Instructions, Mounting Hardware

Care Instructions: Wipe with a damp cloth and dry with a clean cloth.

Recommended Use: Dining, Bar, Storage

Indoor/Outdoor Use: Indoor

Warranty and Support

Warranty:

This product comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. The warranty covers manufacturing defects under normal use.

Customer Support:

If you encounter any issues, have questions about assembly, or require replacement parts, please contact Sweiko customer service. Provide your model number (jw7976) and purchase date for faster assistance.
For support, please visit the official Sweiko website or contact your retailer.

© 2024 Sweiko. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7S7HNV3

More documents and user manuals: **https://manuals.plus/**