

[Manuals.plus](#) /

› [Portronics](#) /

› Portronics Talk Four 2W Wearable Bluetooth Speaker User Manual

Portronics POR-2463

Portronics Talk Four 2W Wearable Bluetooth Speaker User Manual

Model: POR-2463

INTRODUCTION

Thank you for choosing the Portronics Talk Four 2W Wearable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use to ensure optimal performance and longevity.



Image: The Portronics Talk Four 2W Wearable Bluetooth Speaker, a compact black device with a speaker grille and control buttons, shown from an angled perspective.


PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x Portronics Talk Four Wearable Bluetooth Speaker
- 1 x Charging Cable
- 1 x Documentation (User Manual)

PRODUCT OVERVIEW

The Portronics Talk Four is a lightweight and portable 2W wearable Bluetooth speaker designed for hands-free audio and calls. It features a built-in microphone, magnetic and spring clip-on attachments, and IPX5 water and dust resistance.



Instant Connectivity



Bluetooth V5.3

Big Buttons For Easy Operation



Image: The Portronics Talk Four speaker highlighting its large, easy-to-use buttons and Bluetooth 5.3 connectivity, shown alongside a smartphone displaying Bluetooth settings.

Key Features:

- **Ultra-Portable Design:** Weighs only 64 grams, making it ideal for on-the-go use.
- **IPX5 Water & Dust Resistant:** Protected against splashes and dust, suitable for outdoor activities.
- **Bluetooth 5.3 Connectivity:** Ensures stable, fast pairing and a wide range for uninterrupted audio.
- **Versatile Wearing Options:** Features double-sided magnets and a universal spring clip for secure attachment to clothing or other surfaces.
- **Easy Control:** Equipped with large, intuitive buttons for managing playback, volume, and calls.
- **Built-in Microphone:** Provides clear audio capture for hands-free phone calls.
- **Long Playtime:** Up to 10 hours of continuous audio playback.

SETUP

Charging the Speaker:

1. Connect the provided charging cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge typically takes approximately 2-3 hours.

Powering On/Off:

- **To Power On:** Press and hold the Power button for a few seconds until the LED indicator lights up and you hear a power-on prompt.
- **To Power Off:** Press and hold the Power button again for a few seconds until the LED indicator turns off and you hear a power-off prompt.

OPERATING INSTRUCTIONS

Bluetooth Pairing:

1. Ensure the speaker is powered on and in pairing mode (the LED indicator will typically flash rapidly).
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Portronics Talk Four" in the list of available Bluetooth devices.
4. Select "Portronics Talk Four" to connect. Once connected, the LED indicator will turn solid, and you will hear a confirmation sound.

Wearing the Speaker:


The Portronics Talk Four offers multiple ways to wear it:

- **Spring Clip:** Use the integrated spring clip to attach the speaker securely to your t-shirt, shirt collar, bag strap, or other thin fabrics.
- **Double-Sided Magnet:** For thicker materials or more secure placement, utilize the double-sided magnets. Place one part of the magnet inside your clothing and the speaker on the outside, allowing them to snap together.

Styles to Wear



Spring Clip
Does not Bounce



Double Sided Magnet
Maintain Situation Awareness



Image: Illustrations demonstrating how to wear the Portronics Talk Four speaker using its spring clip on a shirt collar and its double-sided magnet for secure attachment.

Button Functions:

Button	Function
Power Button	Press and hold to Power On/Off. Short press for play/pause (music) or answer/end call.
"+" Button	Short press to increase volume. Long press for next track.
"-" Button	Short press to decrease volume. Long press for previous track.

Making/Receiving Calls:

With the built-in microphone, you can manage calls hands-free:

- **Answer Call:** Short press the Power button when a call comes in.

- **End Call:** Short press the Power button during a call.
- **Reject Call:** Press and hold the Power button for 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Power button.

Built-In Mic For Phone Calls

Crystal-Clear Audio Capture for Effortless Calling On the Go.



Image: The Portronics Talk Four speaker emphasizing its built-in microphone for crystal-clear phone calls, with illustrations of people running, cycling, and bodybuilding, indicating its use during various activities.

MAINTENANCE

Cleaning:

- Wipe the speaker with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

Storage:

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- If storing for an extended period, charge the battery periodically (e.g., every 3 months) to maintain battery health.

Water and Dust Resistance (IPX5):

The speaker is IPX5 rated, meaning it is protected against low-pressure water jets from any direction and is dust resistant. However, it is not designed for submersion in water.

- Do not submerge the speaker in water.
- Ensure the charging port cover is securely closed before exposure to water or dust.
- If the speaker gets wet, wipe it dry thoroughly before charging.

IPX5 Water Resistant & Dustproof



 Sweatproof

 Splashproof

 Rainproof

Image: The Portronics Talk Four speaker with water splashing around it, illustrating its IPX5 water and dust resistance, indicating it is sweatproof, splashproof, and rainproof.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Speaker does not power on.	Battery is low. Charge the speaker fully.
Cannot pair with device.	• Ensure speaker is in pairing mode. • Bluetooth is not enabled on your device. • Speaker is too far from the device. Keep within 10 meters. • Clear previous Bluetooth connections on your device and try again.
No sound or low volume.	• Volume on speaker or connected device is too low. Increase volume. • Speaker is not properly connected to the device. Re-pair. • Audio source is paused or not playing.
Call quality is poor.	• Ensure the speaker's microphone is not obstructed. • Move closer to your connected device. • Check network signal on your phone.

SPECIFICATIONS

Feature	Detail
Model Name	Talk Four
Model Number	POR-2463
Speaker Type	Wearable Speaker
Audio Output Power	2 Watts
Connectivity	Bluetooth 5.3
Battery Life	Up to 10 Hours
Water Resistance	IPX5 (Water & Dust Resistant)
Material	ABS Plastic
Dimensions (LxWxH)	73D x 42W x 29H Millimeters
Item Weight	64 Grams
Power Source	Battery Powered (1 Lithium Polymer battery included)
Control Method	Button
Mounting Type	Clip-on, Magnetic Mount

WARRANTY INFORMATION

The Portronics Talk Four 2W Wearable Bluetooth Speaker comes with a**Limited Warranty**. Please refer to the documentation included in your package for specific terms and conditions, including warranty period and coverage details. Keep your purchase receipt as proof of purchase for warranty claims.

SUPPORT

For technical assistance, troubleshooting, or warranty inquiries, please contact Portronics customer support:

- **Email:** help@portronics.com
- **Phone:** +91 9555-245-245
- **Manufacturer Address:** Portronics Digital Pvt Ltd, First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301, India

You can also visit the official Portronics website for more information and FAQs.

© 2024 Portronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question