

MCombo RS6314

MCombo Power Loveseat Recliner RS6314 User Manual

Model: RS6314 | Brand: MCombo

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Keep this manual for future reference.

- All fabric and upholstered surfaces meet flammability standards.
- Keep away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks.
- Always unplug the power cord when not in use.
- Follow the manufacturer's instructions for safe handling and installation.

2. PACKAGE CONTENTS

Ensure all components are present before beginning assembly. If any parts are missing or damaged, please contact MCombo customer support.

- Right Armrest (1)
- Left Armrest (1)
- Right Base (1)
- Left Base (1)
- Right Backrest (1)
- Left Backrest (1)

- Cylindrical Pin (2)
- Power Adapter (2)
- Protective Gloves (2)
- Instruction Manual (1)
- Parts Box (1)

Video: MCombo Wall Hugger Recliner Loveseat (Product Assembly)

This video demonstrates the assembly process for a MCombo Wall Hugger Recliner Loveseat, showing the various components and steps involved.

3. ASSEMBLY INSTRUCTIONS

Assembly of your MCombo Power Loveseat Recliner is designed to be straightforward. Follow these steps carefully:

1. **Connect the Bases:** Place the two base sections on the floor with the metal frames facing upwards. Align the connecting points and insert the cylindrical pins to secure them together.
2. **Attach Armrests:** Remove any protective packaging from the armrests. Align the brackets on each armrest with the corresponding clips on the base sections and press firmly until they click into place.
3. **Install Backrests:** Carefully slide each backrest onto its respective base, ensuring the metal brackets engage securely. Press down firmly until you hear a click, confirming the backrest is properly locked.
4. **Connect Wiring:** Locate the wiring harnesses for the power reclining, massage, and heating functions. Connect all corresponding wires, ensuring a snug fit. Connect the power adapter to the designated port on the loveseat and then plug it into a wall outlet.
5. **Secure Dust Cover:** Attach the dust cover to the Velcro straps located underneath the loveseat to conceal the wiring and mechanism.



Image: Assembled MCombo Power Loveseat Recliner

A view of the fully assembled MCombo Power Loveseat Recliner, ready for use.

4. OPERATING INSTRUCTIONS

Your MCombo Power Loveseat Recliner offers multiple features for enhanced comfort. Each seat can be controlled independently.

4.1. Electric Reclining Function

To recline, press and hold the button located on the armrest. The footrest will extend, and the backrest will smoothly adjust to your preferred reclining position. Release the button to stop at any desired angle. To return to the upright position, press and hold the opposite button.

4.2. Full-Body Vibration & Lumbar Heat

The loveseat features 12 built-in vibrating points and 2 lumbar heating points. Use the remote control to select from 4 vibration modes and 3 intensity levels. The heating function works independently of vibration. Both functions can be set with a timer for 10, 20, or 30 minutes.

4.3. USB Charge Ports, Side Pockets, and Cupholders

The integrated USB ports allow you to charge low-power devices such as mobile phones. Convenient side pockets are available for storing small items or magazines. Use the built-in cupholders to keep your beverages secure.



Video: Power Loveseat Recliner Sofa with 2 Reclining Seats PR648

This video showcases the power reclining, heat, vibration, USB charging, and cupholder features of a MCombo loveseat recliner.



Video: MCombo Wall Hugger Power Loveseat Recliner PR635M1

This video highlights the power reclining, USB charging, and cupholder functionalities of a MCombo Wall Hugger Power Loveseat Recliner.

5. FEATURES OVERVIEW

- **Power Reclining:** Smooth electric adjustment of footrest and backrest.
- **Heat & Vibration:** 12 vibrating points, 2 lumbar heating points with multiple modes and intensities, and timer settings.
- **Convenience Features:** Dual USB charge ports (for low-power devices), side storage pockets, and integrated cupholders.
- **Wall Hugger Design:** Requires minimal wall clearance (9.8 inches) for full recline.
- **Durable Fabric:** Made with OEKO-TEX® STANDARD 100 certified fabric for skin-friendliness and durability.
- **Sturdy Construction:** Features a frame made from FSC® Certified Wood.



Image: Dimensions and Wall Clearance

This image illustrates the overall dimensions of the loveseat and the required wall clearance for reclining.



Image: Zero Gravity Position

A person relaxing in the recliner's zero gravity position, highlighting the 155° recline and tension relief.



Image: Customizable 6-Point Massage and Gentle Lumbar Heat

An overhead view of the loveseat showing the locations of the massage and lumbar heat elements.



Image: Certified Materials & Premium Frame

A cutaway view of the loveseat's construction, highlighting the CertiPUR-US certified foam and FSC certified wood frame.



Image: Armrest with Integrated Controls

A close-up of the armrest showing the power reclining buttons, USB ports, and side pocket.



Video: Ultra-Soft & Durable: Plush Fabric for 6079 & RS6234 series

This short video demonstrates the soft and durable plush fabric used on MCombo recliners.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your loveseat.

- **Regular Cleaning:** Vacuum regularly to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner according to the product instructions, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these can damage the fabric.
- **Electrical Components:** Ensure all electrical connections are secure. If any electrical component malfunctions, unplug the unit and contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your MCombo Power Loveseat Recliner, refer to the following common problems and solutions:

- **Recliner Not Operating:**
 - Check if the power cord is securely plugged into both the loveseat and the wall outlet.
 - Ensure the power switch (if present) is in the 'ON' position.
 - Verify all internal wiring connections are properly seated.
- **Massage/Heat Not Working:**
 - Confirm the remote control is properly connected and has power.
 - Check if the timer function has expired.
- **USB Ports Not Charging:**

- Ensure the loveseat is powered on.
- Confirm the device being charged is a low-power device (e.g., mobile phone).
- Try a different USB cable.

If the problem persists after attempting these solutions, please contact MCombo customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	MCombo
Model Number	6160-RS6314
Colour	Brown
Product Dimensions	72.9 x 144.78 x 109.98 cm
Item Weight	78.83 kg
Maximum Weight Capacity	320 Pounds
Material	Fabric
Special Features	Armrest, Cup Holder, Easy to Assemble, Recliner, USB Charging Ports
Max Reclining Angle	155°
Wall Clearance Needed	9.8 inches
Seating Capacity	2.0

9. WARRANTY AND SUPPORT

MCombo is committed to providing high-quality products and customer satisfaction. For any questions, concerns, or warranty claims, please refer to the contact information provided with your purchase or visit the official MCombo website.

This product is eligible for return or refund within 30 days of receipt. Please retain your proof of purchase for all warranty and support inquiries.

For direct assistance, you can reach MCombo Customer Support via the contact details provided on the product packaging or the MCombo store page on Amazon.

MCombo Store: [Visit MCombo Store on Amazon](#)

