

[Manuals.plus](#) /

› [BOUNTECH](#) /

› BOUNTECH Inflatable Water Slide & Bounce House User Manual

BOUNTECH NP11331/BT060

BOUNTECH Inflatable Water Slide & Bounce House User Manual

Model: NP11331/BT060

Brand: BOUNTECH

1. INTRODUCTION

Thank you for choosing the BOUNTECH Inflatable Water Slide and Bounce House. This 9-in-1 kids' water park is designed to provide a safe and engaging play environment for children, featuring dual slides, a soccer gate, a climbing wall, a splash pool, and a jumping area. This manual provides essential information for proper setup, operation, maintenance, and safety to ensure a fun and secure experience.



Figure 1.1: Overview of the BOUNTECH Inflatable Water Slide and Bounce House in use.

2. IMPORTANT SAFETY WARNINGS

WARNING: Failure to follow these instructions may result in serious injury or death.

- **Adult Supervision Required:** Always ensure constant, direct adult supervision while children are playing on the inflatable. Never leave children unattended.
- **Anchoring:** Always stake down the bounce house and air blower securely to the ground using the provided stakes to prevent tipping or being blown away by wind. Children pinned under a bounce house can suffocate.
- **Inflation:** Ensure the inflatable is fully inflated before allowing children to play. Do not allow play on a partially deflated unit. The air blower must run continuously during use.
- **Weight Limits:** The maximum weight on the inflatable part is 200 lbs. Individual weight limit for inflatable parts is 100 lbs. Suitable for 3-4 children playing together. Recommended age: 36 months - 10 years.
- **Clearance:** Ensure adequate clear space around the inflatable. Keep the air blower away from anything that could catch fire or get wet.
- **Surface:** Set up on a flat, soft surface (e.g., grass). If used on concrete, remove any sharp objects that could puncture the unit.
- **Footwear:** Children must remove shoes before entering the bounce house.

- **Water Use:** If using as a water park, ensure the water is drained completely after use and the unit is thoroughly dried before storage to prevent mold and mildew.
- **Electrical Safety:** Keep the air blower and electrical connections dry. Do not operate in wet conditions unless specifically designed for it and all electrical components are waterproof.
- **No Rough Play:** Prohibit roughhousing, flipping, or climbing on walls not designed for climbing.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Inflatable Water Slide & Bounce House
- 8 x Ground Stakes (for inflatable)
- 1 x Repair Patches Kit
- 1 x Water Hose Assembly Kit
- 1 x Inflatable Basketball
- 1 x Inflatable Football
- 1 x Hand Pump (for balls)
- 1 x Convenient Carrying Bag
- 6 x Colorful Rings (for ring toss game)
- 50 x Ocean Balls

Note: An air blower (recommended 680W-735W) is required for operation and is **NOT** included with this model.



Figure 3.1: Complete accessories included with the BOUNTECH Inflatable Water Slide and Bounce House.

4. SPECIFICATIONS

Feature	Detail
Model Number	NP11331/BT060
Product Dimensions (L x W x H)	183 x 156 x 99 inches (approx. 15.25 x 13 x 8.25 feet)
Maximum Overall Weight Recommendation	200 lbs
Individual Weight Limit (on inflatable parts)	100 lbs
Number of Players	3-4 children
Recommended Age Range	36 months - 10 years

Material	Puncture-proof and wear-resistant 420D + 840D Oxford cloth (PVC-coated Oxford for bouncing area)
Safety Features	4-sided breathable mesh wall, 12.5" heightened guardrails on slides, inflatable buffer zone at climbing wall base.



Figure 4.1: Detailed dimensions of the BOUNTECH Inflatable Water Slide and Bounce House.



Suitable Age:
3-10 Years Old



Individual Weight Limit
of Inflatable Parts:
100 lbs



Overall Weight Limit
of Inflatable Parts:
200 lbs



Figure 4.2: Suitable age and weight limits for safe play.

5. SETUP INSTRUCTIONS

Follow these steps for quick and easy setup:

1. **Choose Location:** Select a flat, clear, and soft surface (e.g., grass) in your backyard. Ensure there are no sharp objects, debris, or obstructions in the area.
2. **Unfold:** Unfold the deflated bounce house completely on the chosen surface.
3. **Connect Blower:** Locate the air intake tube on the bounce house and securely attach it to the outlet of your air blower (not included). Ensure the connection is tight and free of kinks.
4. **Secure Blower:** Use the provided stakes to secure the air blower to the ground, preventing it from tipping over during operation.
5. **Inflate:** Plug in the air blower and turn it on. The bounce house will inflate rapidly, typically within 30-60 seconds. Ensure the air blower runs continuously throughout play.
6. **Stake Down Inflatable:** Once fully inflated, use the remaining ground stakes to secure the corners and other designated

points of the bounce house to the ground. This is crucial for stability and safety.

7. **Water Hose (Optional):** If using as a water slide, connect the water hose assembly kit to a garden hose and attach it to the designated water spray nozzles on the inflatable.
8. **Final Check:** Before allowing children to play, perform a final check to ensure the inflatable is fully firm, all stakes are secure, and there are no hazards in the play area.



Figure 5.1: Visual guide for easy installation.

6. OPERATING INSTRUCTIONS

The BOUNTECH Inflatable Water Slide and Bounce House offers versatile play options:

6.1. Dry Play (Bounce House Mode)

For dry play, ensure the water hose is disconnected and any water from previous use is completely drained and dried. Children can enjoy the jumping area, climbing wall, and dry slides. The soccer goal and ring toss game can also be used in this mode.

6.2. Wet Play (Water Park Mode)

Connect the water hose to the designated nozzles to activate the water slide and splash pool features. The water cannon and top sprinkler will provide continuous water spray for a refreshing experience. Ensure the splash pool area is adequately filled with water for safe play.



Figure 6.1: The inflatable can be used for both wet and dry play.

6.3. Play Features

- **Jumping Zone:** A spacious area for bouncing.
- **Curved Water Slide:** An exciting slide for wet play.
- **Short Slide:** An additional slide for varied fun.
- **Climbing Wall:** Helps develop coordination and agility.
- **Soccer Goal:** For football enthusiasts.
- **Basketball Hoop:** Practice shooting hoops with the included basketball.
- **Large Splash Pool:** A cool area for water play.
- **Water Cannon & Top Sprinkler:** Provides continuous water spray for the water slide.

- **Ring Toss Game:** Engage in a fun ring toss activity with the included rings.

Let's Party with Jumper Kids

Extra Long Curved Slide



Long & Short Slides



Basketball Rim



Pitching Game



Splash Pool



Water Cannon



Soccer Goal



Ring Toss Game



Climbing Wall



Jumping Zone

Figure 6.2: Explore the 9-in-1 play features.

7. MAINTENANCE AND STORAGE

7.1. Cleaning

Clean the inflatable with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.

7.2. Drying After Wet Use

Thorough drying is crucial to prevent mold and mildew. Make sure all water is drained from the splash pool and other areas. Open any small vents on the inflatable to facilitate air circulation. Reconnect the blower and allow it to run until the entire unit is completely dry, both inside and out. You may need to tilt the unit to help water drain from specific areas.

7.3. Deflation and Storage

Ensure no children are inside the bounce house before deflating. Turn off and unplug the air blower. The unit will deflate on its own within minutes. Once deflated, fold the bounce house lengthwise, squeezing out any remaining air. Roll it tightly to make it

compact enough to fit into the provided carrying bag. Store in a dry, cool place indoors, away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Inflatable does not fully inflate or loses air quickly.	Blower not running, air intake tube not securely attached, large puncture/tear, zipper/velcro opening.	Ensure blower is on and plugged in. Check air intake tube connection. Inspect for damage and use repair kit for small holes. Ensure all zippers/velcro closures are sealed.
Inflatable tips over during use.	Not properly staked down, excessive weight, strong winds.	Always use all provided stakes to secure the unit and blower. Adhere to weight limits. Do not use in strong winds.
Water does not spray from nozzles.	Water hose not connected, water supply off, clogged nozzles.	Ensure water hose is properly connected and water supply is on. Check for kinks in the hose. Clear any blockages in the nozzles.
Difficulty drying the unit.	Insufficient drainage, not enough air circulation.	Ensure all water is drained. Run the blower for an extended period. Open all vents. Tilt the unit to help water evaporate or drain.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact BOUNTECH customer service through the retailer where you purchased the product or visit the official BOUNTECH website. Please retain your proof of purchase for warranty claims.

10. VIDEO DEMONSTRATIONS

Currently, there are no official seller-provided video demonstrations available for this specific product model. Please refer to the detailed instructions and diagrams provided in this manual for setup and operation.

