Jgstkcity OEUP051

Jgstkcity Pop-Up Countertop Outlet with Wireless Charger and USB Ports

Model: OEUP051

1. Product Overview

The Jgstkcity Pop-Up Countertop Outlet (Model OEUP051) is a versatile power solution designed for modern spaces. It features a retractable design that allows it to be hidden when not in use, providing a clean and minimalist aesthetic. This unit integrates multiple charging options to power a variety of devices efficiently.

Key Features:

- 4 Tamper-Resistant AC Outlets (15A/125V, 1875W)
- 2 PD20W USB-C Ports
- 2 USB-A Ports
- 15W Fast Wireless Charging Pad
- ETL Listed for safety
- 800 Joules Surge Protection
- Fire-resistant material



Figure 1: Overview of the Jgstkcity Pop-Up Countertop Outlet's 9-in-1 functionality.

2. Safety Information

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not exceed the maximum power rating of 15A/125V (1875W).
- This product is intended for indoor use only.
- Ensure proper grounding during installation.
- Do not disassemble or modify the unit.
- Keep away from water and excessive moisture. While splash-resistant, it is not waterproof.
- Do not use if the power cord or unit is damaged.
- Keep children away from the unit, especially when extended.

3. Setup and Installation

The Jgstkcity Pop-Up Countertop Outlet is designed for easy installation in a standard 3.15-inch (80mm) round hole. It can be installed in countertops or desks with a thickness between 0.5 inches and 3 inches.

3.1 Installation Requirements

- **Counter Cutout Size:** 3.15-inch (80mm) Round Hole
- **Depth Under Counter:** Approximately 9.5 inches (when concealed)
- **Desktop Thickness Compatibility:** 0.5 to 3 inches thick
- **Flange Width Needed Under Counter:** 3.5 inches




Figure 2: Installation dimensions and requirements.

3.2 Installation Steps

1. Ensure the power is off at the circuit breaker before beginning installation.
2. Cut a 3.15-inch (80mm) round hole in your desired countertop or desk surface.
3. Insert the pop-up outlet unit into the hole from the top.
4. From underneath the counter, secure the unit by tightening the locking ring until it is firm.
5. Connect the power cord to a grounded 125V AC outlet.
6. Restore power at the circuit breaker.

Your browser does not support the video tag.

Video 1: Demonstration of the Jgstkcity Pop-Up Countertop Outlet's installation and operation.



Figure 3: The pop-up outlet shown in its retracted (left) and extended (right) states on a desk.

4. Operating Instructions

4.1 Extending and Retracting the Outlet

- To extend the outlet: Gently press down on the top surface of the unit. The unit will slowly rise, revealing the AC

outlets and USB ports.

- To retract the outlet: Once extended, gently press down on the top surface again. The unit will slowly retract and sit flush with the countertop.



Figure 4: The pop-up mechanism in action, showing extension and retraction.

4.2 Using AC Outlets

Plug your devices directly into the 4 tamper-resistant AC outlets. These outlets provide standard 125V AC power for appliances and electronics.

4.3 Using USB Charging Ports

The unit includes 2 PD20W USB-C ports and 2 USB-A ports for charging mobile devices. Connect your USB-compatible devices using appropriate cables.



Figure 5: Fast charging a smartphone via the 20W USB-C port.

4.4 Using the Wireless Charging Pad

Place your Qi-compatible device (e.g., smartphone) on the 15W wireless charging pad located on the top surface of the unit. Ensure the device is centered for optimal charging. The charging indicator light will illuminate when charging is active.



Figure 6: Wireless charging a smartphone on the integrated 15W pad.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your pop-up outlet.

- **Cleaning:** Wipe the surface with a soft, dry cloth. For spills, wipe off water immediately. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check the power cord and the unit for any signs of damage. If damage is found, discontinue use and contact support.
- **Splash Resistance:** The unit is designed to be splash-resistant. In case of accidental water spills on the surface, wipe it dry promptly. Do not immerse the unit in water.



Figure 7: The unit's splash-resistant design allows for normal use after wiping off accidental spills.

6. Troubleshooting

If you encounter issues with your Jgstkcity Pop-Up Countertop Outlet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not pop up/down smoothly.	Obstruction or mechanism issue.	Check for any debris around the unit. Ensure the installation is not too tight. If the issue persists, contact support.
No power from AC outlets or USB ports.	No power supply; Overload protection triggered.	Verify the power cord is securely plugged into a live outlet. Check your circuit breaker. Reduce the number of connected devices to prevent overload.

Problem	Possible Cause	Solution
Wireless charging not working.	Device not Qi-compatible; Misalignment; Foreign objects.	Ensure your device supports Qi wireless charging. Reposition the device on the charging pad. Remove any metal objects or thick cases between the device and the pad.

7. Specifications

Feature	Detail
Brand	Jgstkcity
Model Number	OEUP051
Color	Black
Total Power Outlets	4 AC Outlets
Voltage	125 Volts
Maximum Current	15 Amps
Power Rating	1875 Watts
Total USB Ports	4 (2 USB-C, 2 USB-A)
USB-C Output	PD 20W Max
USB-A Output	QC 18W Max
Wireless Charging	15W Pad
Surge Protection Rating	800 Joules
Hole Size for Installation	3.15 inches (80mm)
Enclosure Material	Acrylonitrile Butadiene Styrene, Polycarbonate
Certifications	ETL Listed

8. Warranty

This Jgstkcity product is covered by a **1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation. Please retain your proof of purchase for warranty claims.

9. Support

For technical assistance, warranty claims, or any questions regarding your Jgstkcity Pop-Up Countertop Outlet, please contact our customer support team. Refer to the contact information provided with your product packaging or visit the official Jgstkcity website for further details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the Jgstkcity OEUP051 Pop-Up Countertop Outlet constantly blinking?

Based on the manual for the Jgstkcity OEUP051 Pop-Up Countertop Outlet, a blinking or flashing light is most commonly associated with the wireless charging pad on the top surface. While the manual states the...

Read full answer