

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pawfly](#) /
- › [Pawfly Outdoor Live Bait Aerator \(Model CW0079\) Instruction Manual](#)

## Pawfly CW0079

# Pawfly Outdoor Live Bait Aerator Instruction Manual

Model: CW0079

[Contents](#)   [Setup](#)   [Introduction](#)   [Safety Information](#)   [Package](#)  
[Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for choosing the Pawfly Outdoor Live Bait Aerator. This battery-powered air pump is designed to provide essential oxygen to live bait or fish in buckets up to 30 gallons, ensuring they remain fresh and active during fishing trips or transportation. Its portable and quiet design makes it suitable for various outdoor applications.

## 2. SAFETY INFORMATION

- Read all instructions before use.
- Do not immerse the pump body in water. This product is water-resistant, not waterproof.
- Ensure correct battery polarity when installing batteries.
- Remove batteries if the pump will not be used for an extended period.
- Keep out of reach of children.
- Use only D-size alkaline batteries. Do not mix old and new batteries or different battery types.

## 3. PACKAGE CONTENTS

The Pawfly Outdoor Live Bait Aerator package includes:

- 1 x Pawfly Live Bait Aerator (Model CW0079)
- 1 x Air Stone (located inside the pump body)
- 1 x 1.5-foot Silicone Airline Tubing (located inside the pump body)

*Note: 2 D batteries are required and are not included in the package.*

## 4. SETUP INSTRUCTIONS

## 4.1. Battery Installation and Accessory Retrieval

1. **Remove the Cover:** Locate the screw on the back of the pump. Rotate the screw counter-clockwise to loosen it, then carefully remove the back cover.
2. **Retrieve Accessories:** Inside the pump body, you will find the air stone and 1.5-foot silicone airline tubing. Carefully remove these accessories.
3. **Install Batteries:** Insert two (2) D-size batteries (not included) into the battery compartment, ensuring correct polarity (+/-) as indicated inside the compartment.
4. **Restore Cover:** Place the back cover back onto the pump and rotate the screw clockwise to secure it. Do not overtighten.



Image: Steps for opening the pump, retrieving accessories, installing batteries, and closing the pump.

## Convenient to Use



1. Take the accessories out of the pump



2. Install 2 D batteries



3. Connect the accessories



4. Press the switch button to start it

Image: A close-up view of two D-size batteries correctly installed in the aerator's battery compartment.

### 4.2. Connecting Accessories

1. **Connect Tubing:** Firmly attach one end of the silicone airline tubing to the air outlet nozzle on the side of the pump.
2. **Attach Air Stone:** Connect the other end of the airline tubing to the air stone.
3. **Placement:** Place the air stone into your bait bucket or container. Ensure the air stone is fully submerged for optimal aeration.

## 40 GPH

Perfect for 30-gallon  
bait buckets

## Less than 50 dB

Never scare fish away  
during fishing

## Small Size

Easy to carry and  
use outdoors



Image: The air stone and airline tubing, which are included and stored inside the pump.

## 5. OPERATING INSTRUCTIONS

## 5.1. Turning On/Off

Locate the switch button on the top of the pump. Press the button once to turn the aerator ON. Press it again to turn the aerator OFF.




Image: A close-up view highlighting the switch button and the air outlet on the aerator.

## 5.2. Usage Tips

- For best results, ensure the air stone is at the bottom of the bait bucket.
- The pump is designed for bait buckets up to 30 gallons.
- The integrated metal clip allows for easy attachment to the rim of your bait bucket or other suitable surfaces.
- The pump operates quietly (less than 50 dB) to avoid disturbing fish.

## 6. MAINTENANCE

### 6.1. Cleaning the Air Stone

Over time, the air stone may become clogged with debris or algae, reducing airflow. To clean:

1. Disconnect the air stone from the airline tubing.
2. Soak the air stone in a solution of warm water and a mild cleaner (e.g., vinegar or a diluted bleach solution) for several hours.
3. Rinse thoroughly with clean water before reattaching and using.

### 6.2. Battery Replacement

When the airflow weakens significantly or stops, it is likely time to replace the batteries. Follow the steps in Section 4.1 to replace the two D-size batteries.

### 6.3. Storage

When not in use, store the aerator in a dry, cool place. Remove batteries if storing for extended periods to

prevent leakage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace batteries with new D-size batteries.
Weak or no airflow.	Clogged air stone or kinked tubing. Low battery power.	Clean the air stone (Section 6.1). Check tubing for kinks. Replace batteries.
Excessive noise.	Pump not placed on a stable surface. Internal component issue.	Ensure pump is on a flat, stable surface. If noise persists, contact support.

## 8. SPECIFICATIONS

- **Model Name:** CW0079
- **Brand:** Pawfly
- **Material:** Plastic
- **Product Dimensions:** 6" L x 3" W x 1.8" H (15.2 cm L x 7.6 cm W x 4.6 cm H)
- **Power Source:** 2 x D Batteries (Not Included)
- **Maximum Flow Rate:** 40 GPH (Gallons Per Hour)
- **Maximum Pressure:**  $\geq 0.012$  MPa (12000 Pascal)
- **Operation Mode:** Automatic
- **Hose Length:** 1.5 Feet (Silicone Airline Tubing)
- **Noise Level:** Less than 50 dB
- **Color:** Black

## 9. WARRANTY & SUPPORT

### 9.1. Manufacturer's Warranty

This Pawfly product is covered by a **1 Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

### 9.2. Customer Support

For technical assistance, warranty claims, or any questions regarding your Pawfly Outdoor Live Bait Aerator, please contact Pawfly customer support through the retailer's platform where the product was purchased. Please have your purchase details and model number (CW0079) ready when contacting support.

