Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM BEC5DRSC-NO

User Manual

T4TREAM 5-Drawer Mid-Century Modern Dresser

Model: BEC5DRSC-NO

1. Introduction and Overview

Thank you for choosing the T4TREAM 5-Drawer Mid-Century Modern Dresser. This dresser is designed to provide elegant storage solutions for various rooms in your home, including bedrooms, living rooms, hallways, and entryways. Its timeless design features a natural oak finish, beveled profile, and splayed legs, complementing a wide range of interior styles.

This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new furniture.



Image: The T4TREAM 5-Drawer Mid-Century Modern Dresser, featuring a natural oak finish and gold-colored knobs, positioned in a bright bedroom with a bed and other furniture.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Device:** This dresser includes an anti-tilting device for enhanced stability and safety. It is crucial to install this device as instructed to prevent the dresser from tipping over, especially in households with children or pets.
- **Weight Capacity:** Do not overload drawers. Distribute weight evenly. The top surface has a maximum recommended weight capacity of 100 lbs.
- **Assembly:** Assembly should be performed by two adults. Ensure all hardware is securely tightened before use. Periodically check and re-tighten hardware as needed.
- **Placement:** Place the dresser on a flat, level surface. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.

- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep small parts and assembly hardware out of reach of children.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the included parts list in your physical assembly manual. If any parts are missing or damaged, contact customer support immediately.

- All wooden panels (labeled with serial numbers)
- Metal drawer slides
- Metal handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tilting device kit
- Assembly instructions manual
- Pack of spare parts

4. Setup and Assembly Instructions

Assembly typically requires two adults and takes approximately 40-50 minutes. Follow the step-by-step instructions provided in the physical assembly manual included with your product. Each component is meticulously labeled with serial numbers to simplify the process.

1. **Unpack and Organize:** Lay out all components on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Group similar hardware together.
2. **Assemble Frame:** Follow the diagrams to connect the main frame panels using the provided hardware. Ensure all connections are snug but do not overtighten until instructed.
3. **Install Drawer Slides:** Attach the metal drawer slides to the inner sides of the dresser frame and to the drawer boxes as per the instructions. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawers:** Construct the five drawer boxes. Attach the metal handles to the front panels of each drawer.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots on the dresser frame.
6. **Attach Anti-Tipping Device:** Securely attach the anti-tilting device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.

Product Dimensions

32"W × 16"D × 48"H




Image: A technical diagram illustrating the dimensions of the dresser: 32"W x 16"D x 48"H, with a note indicating a 100 lbs weight capacity on top. A detailed view of a drawer's internal dimensions is also shown.



Image: A close-up view of an open drawer, highlighting the smooth metal sliding rails and the natural oak finish of the wood.

5. Operating Instructions

The T4TREAM 5-Drawer Dresser is designed for straightforward use.

- **Opening/Closing Drawers:** Gently pull the metal handles to open the drawers. Push them back in until they are fully closed. The metal rails ensure smooth operation.
- **Storage:** Utilize the five spacious drawers to organize clothing, linens, accessories, or other household essentials. Distribute items evenly within each drawer to maintain balance and prevent strain on the slides.
- **Top Surface Use:** The top surface can be used for decorative items, lamps, or other light objects. Adhere to the maximum weight capacity of 100 lbs.



Image: An overhead view of an open dresser drawer, revealing its storage capacity with folded textiles inside. The image also highlights the beveled profile design of the dresser.

6. Maintenance and Care

Proper care will extend the life and maintain the appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** In case of spills, wipe them immediately with a dry cloth to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause fading or discoloration of the wood finish. Position the dresser away from direct sunlight if possible.

7. Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides, loose screws, debris in tracks.	Check that drawer slides are correctly installed and aligned. Tighten any loose screws on the slides or drawer boxes. Clean tracks of any dust or debris.
Dresser feels wobbly or unstable.	Uneven floor, loose assembly hardware, anti-tipping device not installed.	Ensure the dresser is on a level surface. Re-tighten all assembly hardware. Verify that the anti-tipping device is securely installed to the wall.
Missing parts or damaged components upon arrival.	Shipping damage or packing error.	Do not proceed with assembly. Contact T4TREAM customer support immediately with your purchase details.

8. Specifications

Brand	T4TREAM
Model Name	BEC5DRSC-NO
Product Dimensions (W x D x H)	32" x 16" x 48"
Number of Drawers	5
Material	FSC-Certified P2 Engineered Wood, Metal Handles
Finish	Natural Oak
Item Weight	120 Pounds
Assembly Required	Yes (Approx. 40-50 minutes for two adults)
Special Features	Beveled Profile Design, Smooth Sliding Drawers, Anti-Tilting Device

9. Warranty and Support

T4TREAM is committed to providing high-quality products. While specific warranty details are typically provided with your purchase documentation, we stand behind the craftsmanship of our furniture.

If you encounter any issues, have questions regarding assembly, or require replacement parts, please do not hesitate to contact T4TREAM customer support. Our team is ready to assist you.

For assistance, please refer to the contact information provided on your purchase receipt or visit the official T4TREAM website.

Note: Keep your purchase receipt and model number (BEC5DRSC-NO) handy when contacting support.

© 2025 T4TREAM. All rights reserved.
For more information, visit T4TREAM Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7VMPM5T

More documents and user manuals: **https://manuals.plus/**