

[Manuals.plus](#) /

› [Fastrack](#) /

› Fastrack Tick Tock Quartz Multifunction Watch NT3287KM06 User Manual

Fastrack NT3287KM06

Fastrack Tick Tock Quartz Multifunction Watch NT3287KM06 User Manual

Model: NT3287KM06 | Brand: Fastrack

1. INTRODUCTION

This manual provides instructions for the Fastrack Tick Tock Quartz Multifunction Watch, model NT3287KM06. Please read this manual carefully to understand the proper operation and care of your watch.



Image 1: Front view of the Fastrack Tick Tock Quartz Multifunction Watch NT3287KM06.

2. PRODUCT FEATURES

- **All-Black Dial & Case:** Features a matte black face and case for a modern aesthetic.
- **Triple Subdial Display:** Includes subdials for day, date, and 24-hour time tracking.
- **Rose Gold Accents:** Subtle rose gold details on hands and push button.
- **Black Stainless Steel Strap:** Durable metal bracelet for secure wear.
- **Water Resistance:** Rated for 50 meters (5 ATM).

3. WATCH COMPONENTS

Familiarize yourself with the main components of your watch:

- **Crown:** Used for setting time and date.

- **Pushers:** Buttons located on the side of the case, used for adjusting subdial functions.
- **Subdials:** Small dials on the main watch face indicating day, date, and 24-hour time.
- **Stainless Steel Strap:** The metal band securing the watch to your wrist.
- **Push Button Clasp:** Mechanism for securing and releasing the strap.



Image 2: Side view of the watch, highlighting the crown and pushers.



Image 3: Back view of the watch, showing the stainless steel strap and push button clasp.

4. SETUP AND INITIAL ADJUSTMENT

4.1 Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to move the hour and minute hands to the desired time. Pay attention to the 24-hour subdial to distinguish AM/PM if applicable.
3. Push the crown back into the normal position to start the watch.

4.2 Setting the Date and Day

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date and day subdials. The direction of rotation may vary for each subdial.
3. Once the correct date and day are set, push the crown back into the normal position.

4.3 Strap Adjustment

The stainless steel strap can be adjusted by removing or adding links. This procedure typically requires specialized tools and is best performed by a qualified watch technician or jeweler to avoid damage. Ensure the strap fits comfortably, not too tight or too loose.



Image 4: The watch worn on a wrist, demonstrating fit.



Image 5: Side view of the watch on a wrist, showing how it sits.

For optimal comfort, measure your wrist and ensure the watch strap is adjusted to allow slight movement without being loose enough to rotate freely.

5. OPERATING THE MULTIFUNCTION DIALS

Your Fastrack Tick Tock watch features three functional subdials:

- **Day Subdial:** Displays the current day of the week.
- **Date Subdial:** Displays the current day of the month.
- **24-Hour Subdial:** Indicates the current hour in a 24-hour format, useful for tracking AM/PM.

These subdials are synchronized with the main time setting and are adjusted using the crown as described in the "Setting the Date and Day" section.

6. CARE AND MAINTENANCE

- **Water Resistance:** This watch is water resistant up to 50 meters (5 ATM). It is suitable for short periods of recreational swimming but not for diving or snorkeling. Avoid operating the crown or pushers when the watch is wet.
- **Cleaning:** Wipe the watch case and strap with a soft, dry cloth regularly to remove dirt and moisture. For the stainless steel strap, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose the watch to solvents, detergents, perfumes, or cosmetics, as these can damage the case, strap, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect its accuracy and water resistance.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as they can interfere with the quartz movement.

7. TROUBLESHOOTING

If you encounter issues with your watch, consider the following common solutions:

- **Watch has stopped:** The battery may need replacement. Contact an authorized service center.
- **Incorrect time/date:** Refer to the "Setting the Time" and "Setting the Date and Day" sections to re-adjust.
- **Condensation inside the crystal:** This may indicate a loss of water resistance. Avoid further exposure to water and seek professional service immediately.
- **Strap discomfort:** Ensure the strap is properly adjusted. If links need to be added or removed, consult a professional.

For issues not covered here, please contact Fastrack customer support.

8. SPECIFICATIONS

Model Name	Tick Tock
Model Number	NT3287KM06
Display Type	Analog
Movement Type	Quartz
Power Source	Battery Powered
Case Material	Brass
Case Diameter	43 Millimetres
Case Thickness	10 Millimetres
Crystal Material	Mineral Glass
Band Material	Stainless Steel
Band Colour	Black
Band Width	20 Millimetres
Band Length	28 Centimetres

Clasp Type	Push Button Clasp (Foldover Clasp With Push Button)
Water Resistance Depth	50 Metres (5 ATM)
Item Weight	205.15 Grams
Special Features	Second Hand, Day, Date, 24-hour display

9. WARRANTY AND SUPPORT

9.1 Manufacturer's Warranty

Your Fastrack Tick Tock watch comes with a **12-month manufacturer warranty** covering manufacturing defects from the date of purchase.

To avail warranty service, present your original purchase invoice at any authorized Titan Service Center. A physical warranty card is not required.

9.2 Customer Support

For further assistance, service-related queries, or warranty claims, please contact Fastrack (Titan India) customer support:

- **Toll-Free Number:** 1800-266-0123 (Available 10 AM to 7 PM, all days of the week)
- **Email:** customercare@titan.co.in
- **Manufacturer Address:** 3, Sipcot Industrial Complex, Hosur - 635126, India

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question