

[Manuals.plus](#) /

> [ChooChoo](#) /

> ChooChoo Tall Bathroom Storage Cabinet with Light (Model SC2403-WH) - Instruction Manual

ChooChoo SC2403-WH

ChooChoo Tall Bathroom Storage Cabinet with Light

Model: SC2403-WH

Brand: ChooChoo

1. INTRODUCTION

Thank you for choosing the ChooChoo Tall Bathroom Storage Cabinet with Light. This freestanding cabinet is designed to provide efficient storage in various spaces, featuring adjustable shelves and a convenient door-activated lighting system. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

Safety Information

WARNING: To prevent serious injury, this product must be securely attached to the wall using the anti-tip kit provided. Children can be seriously injured by furniture tipping over. Always install the anti-tip device. Never allow children to climb or hang on drawers, doors, or shelves.

Always ensure all connections are secure before use. Do not overload shelves. Keep small parts away from children during assembly.



Image 1.1: ChooChoo Tall Bathroom Storage Cabinet in a bathroom setting.

2. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts and hardware are present and undamaged. Refer to the included assembly guide for a detailed list of components. If any parts are missing or damaged, please contact customer support.

3. ASSEMBLY INSTRUCTIONS

The cabinet comes with a comprehensive assembly guide. Follow the step-by-step instructions provided in the separate manual for proper construction. Below are general steps and key considerations:

1. **Prepare the Area:** Clear a spacious, clean, and flat surface for assembly.
2. **Identify Parts:** Unpack all components and identify them using the parts list in your assembly guide.
3. **Assemble the Frame:** Connect the side panels, top, and bottom panels according to the instructions. Ensure all screws and fasteners are tightened securely.

4. **Install Shelves:** Insert the adjustable shelf pins into the desired holes and place the shelves.
5. **Attach Doors:** Mount the cabinet doors. Note that the doors can be installed to open from either the left or right side, depending on your preference.
6. **Install Door-Activated Light:** Follow the specific instructions for installing the door-activated light strip inside the cabinet. Ensure proper wiring and battery installation (if applicable).
7. **Secure Anti-Tip Kit:** This is a critical safety step. Attach the anti-tip kit to the back of the cabinet and then to a wall stud using the provided hardware.



Image 3.1: Cabinet dimensions and internal layout.

Anti-Tip Kit



Farmhouse Door



Glass Door

Image 3.2: Different door setup options (left or right opening).





Image 3.3: Details of the anti-tip kit and door styles.

4. OPERATING INSTRUCTIONS

Door-Activated Lighting

The cabinet is equipped with a convenient door-activated light. This feature automatically turns the light on when the cabinet door is opened and turns it off when the door is closed. This provides illumination for easy access to items inside

the cabinet.

Energy Saver

Turn-Light Switch

Auto on when open the door
Off when the door closed.



Image 4.1: Door-activated light mechanism.

Adjustable Shelves

The cabinet features adjustable shelves, allowing you to customize the storage space to fit items of various sizes. To adjust a shelf, carefully remove the shelf and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted before placing the shelf back.



Image 4.2: Example of personalized storage with adjustable shelves.

5. MAINTENANCE

To maintain the appearance and longevity of your ChooChoo storage cabinet, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.

6. TROUBLESHOOTING

- **Cabinet Wobbles:** Ensure the cabinet is placed on a level surface. Check that all assembly screws are tightened. Verify the anti-tip kit is securely installed to the wall.
- **Door Not Closing Properly:** Check the hinge alignment. Adjust hinges as needed according to the assembly guide.

Ensure no items inside the cabinet are obstructing the door.

- **Light Not Activating:** Check the battery installation for the light strip. Ensure the sensor is not obstructed and is properly aligned with the door mechanism.
- **Missing Parts:** If any parts were missing upon delivery, please contact customer support for replacements.

7. SPECIFICATIONS

Feature	Detail
Model Number	SC2403-WH
Dimensions (D x W x H)	11.8" x 11.8" x 66.53"
Material	Engineered Wood
Color	White
Number of Shelves	6 (Adjustable)
Number of Doors	2
Installation Type	Freestanding
Special Features	Door-activated light, Anti-tip kit included
Recommended Uses	Bathroom, Living Room, Kitchen

3 USAGE SCENARIOS



living room



Kitchen



Bathroom

Image 7.1: Cabinet in various usage scenarios.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the contact details provided in your original purchase documentation or visit the official ChooChoo website. Please have your model number (SC2403-WH) ready when contacting support.

