

[Manuals.plus](#) /

> [COMFEE'](#) /

> COMFEE' Freestanding Dishwasher CDWEF1034BW-UK User Manual

## COMFEE' CDWEF1034BW-UK

# COMFEE' Freestanding Dishwasher User Manual

Model: CDWEF1034BW-UK

## 1. PRODUCT OVERVIEW

The COMFEE' CDWEF1034BW-UK is a slimline freestanding dishwasher designed for efficient and hygienic dish cleaning. It features a 10 place setting capacity, multiple wash programs, and energy-saving functions.





Figure 1.1: Front view of the COMFEE' CDWEF1034BW-UK Freestanding Dishwasher.



Figure 1.2: Interior view of the dishwasher with the door open, showcasing the racks.

### Key Features:

- **10 Place Settings:** Slim design accommodating larger plates and pots up to 300mm.
- **30-minute Quick Wash:** For fast cleaning when time is limited.
- **72°C Hygiene Wash:** Awarded the Golden Virus Hygiene Seal for thorough cleaning and sanitization.
- **Half Load Function:** Reduces energy consumption by 30% for smaller loads.
- **Extra Drying:** Ensures dishes are thoroughly dry, reducing the need for towel drying.
- **Adjustable Basket:** Upper basket can be adjusted for flexible loading.
- **Delay Start:** Option to delay wash cycle by 3, 6, or 9 hours.

## 2. INSTALLATION AND SETUP

The COMFEE' CDWEF1034BW-UK dishwasher offers both freestanding and built-in installation options. Ensure proper water and electrical connections are made by a qualified professional.

### Dimensions and Placement:

The appliance dimensions are 60 cm (Depth) x 45 cm (Width) x 85 cm (Height). For built-in installation, refer to the detailed measurements below to ensure proper fit within your cabinetry.

## 2 Installation Options



Figure 2.1: Installation dimensions for freestanding and built-in configurations.

### Initial Use:

1. Before first use, ensure all packaging materials are removed from inside the dishwasher.
2. Fill the salt dispenser with dishwasher salt (if applicable for your water hardness).
3. Add rinse aid to the dispenser.
4. Run an empty cycle with detergent to clean the interior.

### 3. OPERATING INSTRUCTIONS

This section details how to operate your COMFEE' dishwasher, including program selection and loading tips.


#### Wash Programs:

The dishwasher offers 6 wash programs to suit various cleaning needs:



Figure 3.1: Overview of available wash programs.

- **Intensive Care+:** For heavily soiled dishes, pots, and pans.
- **ECO:** Standard program for normally soiled daily use, optimized for energy and water consumption.
- **90 min:** For normally soiled dishes requiring a quicker wash than ECO.
- **Rapid (30 min):** Quick wash for lightly soiled dishes without drying.
- **Glass:** Gentle wash for delicate glassware at a lower temperature (45°C).
- **Hygiene (72°C):** High-temperature wash for sanitization and stubborn stains.



## 1/2 Half Load

The half load function gets smaller loads washed, using **30% less** energy than a full load cycle, leaving your dishes sparkling clean without having to wait for full loads worth of dirty dishes.  
(It can be used with Intensive, ECO, 90 min, Glass, Hygiene)

Figure 3.2: The 30-minute Quick Wash cycle for fast cleaning.



## 72°C Hygiene Wash

meticulously cleans and sterilizes all your dishes



Figure 3.3: The 72°C Hygiene Wash in action, providing thorough sanitization.

## Hygiene Wash

Powerful cleaning that removes stubborn stains and sanitizes your dishes and glassware.




Figure 3.4: Delicate Glass Care for crystal-clear results.

## Delicate Glass Care

Get crystal-clear results with the delicate glass cycle which meticulously cleans your glasses at a lower temperature (45°C), using the softened water from the added dishwasher salt.



Figure 3.5: Intensive Care+ for tackling heavily soiled dishes.

### Loading the Dishwasher:

Proper loading ensures optimal cleaning performance. The dishwasher is designed to accommodate 10 place settings.

# 10 Sets Capacity Loading





Figure 3.6: Example of a 10 place setting capacity loading.

Utilize the adjustable upper basket, versatile cup shelves, cutlery basket, and foldable flip tines for flexible loading of various dish sizes and shapes.



**Adjustable Upper Basket**



**Versatile Cup Shelves**



**Cutlery Basket**



**Foldable Flip Tines**

Figure 3.7: Features for flexible loading: adjustable upper basket, cup shelves, cutlery basket, and foldable tines.

### Special Functions:

- **Half Load:** Use this function for smaller loads to save energy and water. It can be used with Intensive, ECO, 90 min, Glass, and Hygiene programs.



Figure 3.8: Half Load function for efficient washing of smaller quantities.

- **Extra Drying:** Enhances drying performance for most cycles (except Rapid).




Figure 3.9: Extra Drying function for improved drying results.

- **Delay Start:** Postpone the start of a wash cycle by 3, 6, or 9 hours to take advantage of off-peak power rates.




Figure 3.10: Delay Start options for flexible scheduling.

## 4. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and optimal performance of your dishwasher.

### Cleaning the Filters:

The filter system should be checked and cleaned regularly to prevent blockages and ensure efficient washing. Refer to the full manual for detailed instructions on removing and cleaning the coarse, fine, and micro filters.

### Adding Salt and Rinse Aid:

Monitor the salt and rinse aid indicators on your dishwasher. Refill as necessary to ensure proper water softening and streak-free drying results.

### Exterior and Interior Cleaning:

- Wipe the exterior with a damp cloth.
- Clean the door seal regularly to remove food residue.
- Run a dishwasher cleaner cycle periodically to maintain interior hygiene.

## 5. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Dishwasher does not start	Power cord not plugged in; Door not closed properly; Fuse blown.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse/circuit breaker.
Dishes are not clean	Improper loading; Insufficient detergent; Clogged spray arms; Clogged filters.	Reload dishes correctly; Use appropriate amount of detergent; Clean spray arm nozzles; Clean filters.
Dishes are not dry	No rinse aid; Program without drying selected; Overloading.	Refill rinse aid dispenser; Select a program with drying or use Extra Drying function; Do not overload.
Unpleasant odor	Food residue in filters or drain; Infrequent cleaning.	Clean filters and drain area; Run a self-clean cycle or a hot wash with dishwasher cleaner.

## 6. SPECIFICATIONS

Detailed technical specifications for the COMFEE' CDWEF1034BW-UK dishwasher.

Parameter	Value
Model Name	CDWEF1034BW-UK
Form Factor	Freestanding


<b>Parameter</b>	<b>Value</b>
Dimensions (H x W x D)	85 x 45 x 60 cm
Item Weight	37.7 kg
Rated Capacity	10 Place Settings
Energy Efficiency Class	E
Annual Energy Consumption	76 kWh per 100 cycles
Water Consumption (ECO program)	9.0 litres per cycle
Noise Level	49 dB
Number of Programs	6
Voltage	220 Volts
Material Type	Stainless Steel
Included Components	Machine Body



Comfee

CDWEF1034BW-UK



**76 kWh** / 



**10 x**



**9.0 L**



**3:55**



**49dB**  
ABCD

2019/2017

Figure 6.1: Energy Efficiency Label for the dishwasher.

## Product information sheet (EN60436)

**Supplier's name or trade mark:** COMFEE'

**Supplier's address (b):** 5 New Street Square, London, United Kingdom, EC4A 3TW

**Model identifier:** CDWEF1034BW-UK, CDWEF1034BB-UK

### General product parameters:

Parameter	Value	Parameter	Value	
Rated capacity (a) (ps)	10	Dimensions in cm	Height	85
			Width	45
			Depth	61
EEI (a)	55,9	Energy efficiency class (a)	E (c)	
Cleaning performance index (a)	1,125	Drying performance index (a)	1,065	
Energy consumption in kWh [per cycle], based on the eco programme using cold water fill. Actual energy consumption will depend on how the appliance is used.	0,755	Water consumption in litres [per cycle], based on the eco program. Actual water consumption will depend on how the appliance is used and on the hardness of the water.	9,0	
Program duration (a) (h:min)	3:53	Type	Free standing	
Airborne acoustical noise emissions (a) (dB(A) re 1 pW)	49	Airborne acoustical noise emission class (a)	C (c)	
Off-mode (W)	N/A	Standby mode (W)	0,49	
Delay start (W) (if applicable)	1,00	Networked standby (W) (if applicable)	N/A	

**Minimum duration of the guarantee offered by the supplier (b):** 12 months

### Additional information:

Weblink to the supplier's website, where the information in point 6 of Annex II to Commission Regulation (EU) 2019/2022 (1) (b) is found: <https://www.comfee-appliances.com/global>

(a) for the eco program.

(b) changes to these items shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.

(c) if the product database automatically generates the definitive content of this cell the supplier shall not enter these data.

(1) Commission Regulation (EU) 2019/2022 of 1 October 2019 laying down eco design requirements for household dishwashers pursuant to Directive 2009/125/EC of the European Parliament and of the Council amending Commission Regulation (EC) No 1275/2008 and repealing Commission Regulation (EU) No 1016/2010 (see page 267 of this Official Journal).

Figure 6.2: Product Information Sheet with detailed technical data.

## 7. WARRANTY AND SUPPORT

Your COMFEE' dishwasher is covered by a manufacturer's guarantee and dedicated customer support.

### Warranty Information:

The minimum duration of the guarantee offered by the supplier is **12 months** from the date of purchase. Please retain your proof of purchase for warranty claims.

### Customer Support:

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact COMFEE' specialized customer support. You can find more information and contact details on the official COMFEE' website:

