

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Midea](#) /

> [Midea 60 cm 1800 m3/hr BLDC Filter-less Wi-Fi Kitchen Chimney User Manual \(Model MH60J63ET25BF-IN\)](#)

Midea MH60J63ET25BF-IN

Midea 60 cm 1800 m3/hr BLDC Filter-less Wi-Fi Kitchen Chimney User Manual

Model: MH60J63ET25BF-IN

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Midea 60 cm 1800 m3/hr BLDC Filter-less Wi-Fi Kitchen Chimney. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Midea kitchen chimney is designed to effectively remove smoke, grease, and odors from your cooking area, ensuring a cleaner and more comfortable kitchen environment. It features a powerful BLDC motor, filter-less technology, Wi-Fi connectivity for smart control, and an intelli-Autoclean function.



Image 1.1: The Midea kitchen chimney highlighting silent operation, automatic glass panel opening, and BLDC motor technology for cleaner air and a quieter kitchen.

Safety Information

- Ensure the appliance is installed by qualified personnel.
- Do not operate the chimney without proper ventilation.
- Regular cleaning is crucial to prevent fire hazards from grease buildup.
- Disconnect power before any maintenance or cleaning.
- This appliance is for domestic use only.

2. SETUP AND INSTALLATION

Your Midea kitchen chimney comes with a free installation kit. Professional installation is highly recommended to ensure correct setup and optimal performance.

2.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the chimney for any damage during transit. Contact your dealer immediately if damage is found.
- Ensure all components listed in the packing list are present. The package includes the chimney unit, installation kit, oil collector, and this user manual.

2.2 Installation Guidelines

The chimney is designed for wall-mount installation. Refer to the detailed instructions provided in the separate installation guide included with your installation kit for specific mounting procedures, ducting requirements, and electrical connections.

- **Mounting Height:** Maintain the recommended distance between the cooking surface and the bottom of the chimney for optimal suction and safety.
- **Ducting:** Ensure proper ducting is used to vent air outside. The chimney supports ducted ventilation.
- **Electrical Connection:** Connect the chimney to a grounded 220 Volt power supply.



Image 2.1: Dimensions of the Midea 60 cm kitchen chimney, showing a width of 600mm, height of 505mm, and depth of 395mm for seamless integration into your kitchen.

3. OPERATING INSTRUCTIONS

Your Midea chimney offers multiple control options for convenience and efficiency.

3.1 Control Panel Overview

The chimney features an intuitive control panel, gesture control, and can be operated via the SmartHome mobile app.




Image 3.1: The Midea kitchen chimney demonstrating its versatile control options, including touch, gesture, and smartphone app control.

3.2 Power On/Off

- **Touch Control:** Press the power icon on the control panel to turn the chimney on or off.
- **Gesture Control:** Wave your hand in front of the sensor to activate or deactivate the chimney.
- **App Control:** Use the Midea SmartHome app to remotely power the chimney on or off.

3.3 Speed Selection

The chimney offers 9 speed settings, including an 8+1 Turbo Speed for intense cooking fumes.

- **Touch Control:** Use the '+' and '-' buttons on the control panel to adjust the suction speed.
- **Gesture Control:** Specific hand gestures can be used to cycle through speed settings (refer to the detailed app or quick start guide for gesture patterns).
- **App Control:** Select desired speed levels directly from the SmartHome mobile application.

3.4 Wi-Fi Connectivity and SmartHome App

Connect your chimney to your home Wi-Fi network to unlock smart features via the Midea SmartHome mobile app.

1. Download the "Midea SmartHome" app from your device's app store.
2. Register an account and follow the in-app instructions to add your chimney.
3. Once connected, you can control the chimney, monitor usage, set timers, and receive Intelli-Auto Clean reminders.

3.5 Intelli-Auto Clean Function

The Intelli-Auto Clean feature automatically cleans the chimney's internal components, ensuring consistent performance. The system will remind you after every 15 hours of motor operation.

- When the reminder appears, activate the Auto Clean cycle via the control panel or the SmartHome app.
- The chimney will initiate a heating and cleaning process to melt and collect grease into the oil collector.

3.6 LED Lighting

Press the light icon on the control panel or use the app to turn the integrated LED lights on or off, illuminating your cooking area.

3.7 Delay Timer

The delay timer allows the chimney to continue operating for a set period after cooking, ensuring all residual fumes are cleared. Activate and set the timer via the control panel or the SmartHome app.

4. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your Midea chimney. Always disconnect the power supply before cleaning.

4.1 Filter-less Technology Cleaning

Your chimney utilizes filter-less technology, which means there are no mesh filters to manually clean or replace. The Intelli-Auto Clean system handles internal cleaning.



Image 4.1: The Midea kitchen chimney demonstrating its Intelli-Heat Auto Clean System and Filter-less Technology for efficient and easy cleaning.

- **Intelli-Auto Clean:** Run the Auto Clean cycle as prompted by the chimney (every 15 hours of operation) or manually when needed. This process uses heat to melt grease, which then flows into the oil collector.

4.2 Oil Collector Cleaning

The built-in oil collector gathers melted grease during the Auto Clean cycle. It needs to be emptied and cleaned regularly.

1. Ensure the chimney is off and cooled down.
2. Locate the oil collector, usually at the bottom or rear of the chimney.
3. Carefully remove the oil collector.
4. Empty the collected grease and wash the collector with warm, soapy water. Rinse thoroughly and dry before reinserting.

4.3 Exterior Cleaning

- Wipe the exterior surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.
- For the glass panel, use a glass cleaner and a soft cloth.

5. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Chimney does not turn on.	No power supply. Power cord not properly connected.	Check if the power plug is securely inserted and the circuit breaker is on.
Low suction power.	Oil collector full. Ducting obstruction. Incorrect mounting height.	Empty and clean the oil collector. Check ducting for blockages. Verify chimney is installed at the recommended height.
Unusual noise during operation.	Loose components. Motor issue.	Ensure all parts are securely fastened. If noise persists, contact customer service.
Wi-Fi connection issues.	Incorrect Wi-Fi password. Router too far. App not updated.	Re-enter Wi-Fi password. Ensure chimney is within Wi-Fi range. Update the Midea SmartHome app.
Intelli-Auto Clean not activating.	Cycle not initiated. Sensor malfunction.	Manually activate the cycle. If still unresponsive, contact customer service.

If the problem persists after following these steps, please contact Midea customer support.

6. SPECIFICATIONS

Key technical specifications for the Midea 60 cm BLDC Filter-less Wi-Fi Kitchen Chimney (Model: MH60J63ET25BF-IN).

Feature	Specification
---------	---------------

Feature	Specification
Model Number	MH60J63ET25BF-IN
Air Flow Capacity	1800 m ³ /hr
Motor Type	BLDC Motor
Filter Type	Filter-less Technology
Noise Level	58 Decibels
Number of Speeds	9 (8 + 1 Turbo Speed)
Control Method	Touch, Gesture, Remote, App (Wi-Fi enabled)
Special Features	Intelli-Auto Clean, Built-In Oil Collector, LED Lighting, Delay Timer
Mounting Type	Wall Mount
Material	Metal
Voltage	220 Volts
Wattage	267 Watts
Item Weight	19.5 kg
Product Dimensions (LxWxH)	50 x 60 x 44.5 Centimeters
Annual Energy Consumption	150 Kilowatt Hours Per Year

7. WARRANTY AND SUPPORT

7.1 Product Warranty

Your Midea kitchen chimney is covered by a comprehensive warranty:

- **Product Warranty:** 3 Years
- **Motor Warranty:** 12 Years

Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal use conditions. For detailed terms and conditions, refer to the warranty card included with your product or visit the official Midea website.

7.2 Customer Support

For any queries, technical assistance, or service requests, please contact Midea customer support:

- **Website:** www.midea.com/in (or relevant regional website)
- **Service Center:** Refer to the list of authorized service centers provided in your warranty documentation.

When contacting support, please have your model number (MH60J63ET25BF-IN) and purchase date ready.

