

COFI 1453 JR-PBM01

COFI 1453 JR-PBM01 Magnetic Power Bank 10000mAh 20W User Manual

Model: JR-PBM01

1. INTRODUCTION

Thank you for purchasing the COFI 1453 JR-PBM01 Magnetic Power Bank. This device is designed to provide portable charging for your mobile devices with convenience and efficiency. Featuring a 10000mAh capacity, 20W Power Delivery, integrated N52H magnets for secure attachment, and a foldable stand, it offers a versatile charging solution. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your power bank.

2. PRODUCT OVERVIEW

2.1 Key Features

- **High Capacity:** 10000mAh battery for extended power.
- **Fast Charging:** Supports up to 20W Power Delivery (PD) for rapid charging of compatible devices.
- **Magnetic Attachment:** Integrated N52H magnets ensure secure attachment to compatible devices.
- **Integrated Stand:** Foldable stand for convenient hands-free viewing while charging.
- **Universal Compatibility:** Includes built-in USB-C and Lightning cables for broad device support.
- **Digital Display:** Clear digital display to show remaining battery percentage.

2.2 Package Contents

- COFI 1453 JR-PBM01 Magnetic Power Bank (1 unit)
- User Manual (This document)

3. SETUP

3.1 Initial Charge

Before first use, fully charge your JR-PBM01 power bank. Connect the power bank to a suitable USB power adapter (not included) using the integrated USB-C cable or a separate USB-C cable. The digital display will show the charging progress. Once it reaches 100%, the power bank is fully charged and ready for use.



Image: Power bank ports and digital display showing 100% charge. The display indicates battery level, and the ports include USB-C and Lightning options for input/output.

4. OPERATING INSTRUCTIONS

4.1 Charging the Power Bank

To recharge the power bank, use the integrated USB-C cable or a separate USB-C cable connected to a wall adapter or computer USB port. The digital display will show the current battery percentage and flash during charging. A full charge typically takes several hours depending on the power adapter's output.

4.2 Charging Your Devices

The JR-PBM01 offers multiple ways to charge your devices:

- **Magnetic Wireless Charging:** Align your compatible device (e.g., iPhone with MagSafe) with the magnetic surface of the power bank. The N52H magnets will securely attach the device, and wireless charging will begin automatically.
- **Wired Charging (USB-C):** Use the integrated USB-C cable to connect to your USB-C compatible device.
- **Wired Charging (Lightning):** Use the integrated Lightning cable to connect to your Apple Lightning compatible device.

Press the power button once to activate charging if it does not start automatically. The digital display will show the remaining battery level.



Image: Integrated USB-C and Lightning cables. These cables are built into the power bank for convenient device charging.

4.3 Using the Foldable Stand

The power bank features a foldable stand for hands-free viewing. Gently pull out the stand from the back of the power bank until it clicks into place. You can then place your device on the stand while it charges, allowing for comfortable media consumption or video calls.



Image: Power bank with its foldable stand extended. The stand allows the power bank to prop up a device for viewing.

5. MAINTENANCE

- Keep the power bank away from water, moisture, and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the power bank in a cool, dry place when not in use for extended periods.
- For optimal battery life, fully charge the power bank at least once every three months if not used regularly.

6. TROUBLESHOOTING

Power bank not charging:

Ensure the charging cable is securely connected to both the power bank and the power adapter. Verify that the power adapter is functioning correctly and connected to a live power outlet.

Device not charging from power bank:

Press the power button on the power bank to activate charging. Check if the integrated cables are properly connected to your device. Ensure your device is compatible with the power bank's output specifications. If using wireless charging, ensure your device supports magnetic wireless charging and is correctly aligned.

Slow charging:

Ensure both the power bank and your device support fast charging protocols (e.g., Power Delivery). Using non-compatible cables or adapters may result in slower charging speeds.

Digital display not working:

Try charging the power bank for a short period. If the issue persists, contact customer support.

7. SPECIFICATIONS

Model:	JR-PBM01
Brand:	COFI 1453
Battery Capacity:	10000mAh
Max Output Power:	20W (Power Delivery)
Magnetic Feature:	Integrated N52H Magnets
Integrated Cables:	USB-C, Lightning
Weight:	250 Grams

8. SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the product or injury to yourself:

- Do not disassemble, modify, or repair the device yourself.
- Do not expose the power bank to fire, high temperatures, or direct sunlight.
- Do not use the power bank in wet environments or immerse it in water.
- Keep out of reach of children.
- Use only certified cables and adapters for charging the power bank and your devices.
- If the power bank swells, overheats, or shows any other abnormal behavior, discontinue use immediately and contact customer support.
- Dispose of the power bank responsibly according to local regulations for electronic waste.

9. WARRANTY AND SUPPORT

Information regarding warranty and customer support for the COFI 1453 JR-PBM01 Magnetic Power Bank is not available in this document. Please refer to the product packaging or the retailer's website for warranty details and contact information for support.