

[Manuals.plus](#) /

› [Faber](#) /

› Faber HOB PRIME HT784 CRS BR CI AI 4 Burner 78cm Gas Hob Instruction Manual

Faber HOB PRIME HT784 CRS BR CI AI

Faber HOB PRIME HT784 CRS BR CI AI 4 Burner 78cm Gas Hob

Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your new Faber HOB PRIME HT784 CRS BR CI AI 4 Burner 78cm Gas Hob. Please read these instructions carefully before installation and operation, and keep them for future reference. This appliance is designed for domestic cooking purposes.



Image 1.1: Overview of the Faber 4 Burner Gas Hob highlighting key features like easy cleaning, 8mm glass, brass burner caps, and metal knobs.

2. SAFETY INFORMATION

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- Ensure adequate ventilation in the kitchen area.
- Do not store flammable materials near the appliance.
- Keep children away from the appliance during operation.
- Always use appropriate cookware for the burner size.
- Do not leave cooking unattended.
- In case of a gas leak, turn off the gas supply immediately, open windows, and do not operate electrical switches.

3. PRODUCT OVERVIEW

The Faber HOB PRIME HT784 CRS BR CI AI is a versatile 4-burner gas hob designed for modern kitchens. It features a durable black glass finish and robust components for efficient cooking.

Key Features:

- **Elegant Black Glass Finish:** Toughened glass surface, heat-resistant, scratch-resistant, and easy to clean.
- **Dual Purpose Design:** Functions as a hob/hobtop hybrid, suitable for both built-in and freestanding use.
- **Versatile 4-Burner Configuration:** Includes jumbo, medium, and small burners for varied cooking needs.
- **Auto-Ignition Feature:** Built-in ignition system for quick and safe startup without external lighters.
- **Sturdy Metal Knobs:** Heat-resistant with a smooth grip for durable and user-friendly control.
- **Cast Iron Pan Support:** Provides stable support for cookware.



Image 3.1: Detailed view of burner components, including the 1.5V auto-ignition system and cast iron pan support.

4. SETUP & INSTALLATION

Your Faber hob offers flexible installation options: it can be used as a countertop appliance or integrated as a built-in unit.

4.1 Installation Type:

Choose between countertop use or built-in installation based on your kitchen design. For built-in installation, ensure the countertop cut-out dimensions match the appliance requirements.



Image 4.1: Illustration of the two available installation methods: countertop and built-in.

4.2 Dimensions:

Refer to the diagram below for the overall product dimensions and the required cut-out dimensions for built-in installation.



Image 4.2: Product and cut-out dimensions for installation.

- **Product Dimensions (D x W x H):** 52.5D x 78W x 13H Centimeters
- **Cut-Out Dimensions (W x D):** 685mm x 475mm

Note: Installation should be performed by a qualified technician to ensure safety and proper functioning. Connect the appliance to a suitable gas supply in accordance with local regulations.

5. OPERATING INSTRUCTIONS

5.1 Using the Burners:

1. Ensure the gas supply to the hob is open.
2. Push down and turn the desired control knob counter-clockwise to the maximum flame position. The auto-ignition system will spark, igniting the gas.
3. Hold the knob down for a few seconds after ignition to allow the thermocouple to heat up and activate the flame failure device.
4. Once the flame is stable, release the knob. You can then adjust the flame size by turning the knob between the maximum and minimum flame settings.
5. To turn off the burner, turn the control knob clockwise to the 'OFF' position.

5.2 Burner Wattage Configuration:

The hob features brass burners with different wattage configurations to suit various cooking requirements.

4 High-Performance Burners

Features 4 high-quality brass burners (2 medium + 2 small).

Premium Black Glass Finish

Elegant, **8 mm Toughened glass** top adds a stylish touch to modern kitchens while ensuring durability.



Image 5.1: Burner wattage configurations for efficient cooking.

6. MAINTENANCE & CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob.

6.1 Cleaning the Glass Surface:

- Allow the hob to cool completely before cleaning.

- Use a soft cloth or sponge with mild detergent and warm water.
- For stubborn stains, use a non-abrasive cleaner specifically designed for glass cooktops.
- Wipe dry with a clean, soft cloth to prevent water spots.

6.2 Cleaning Burner Components:

- Remove the pan supports, burner caps, and burner rings when cool.
- Wash these components with warm soapy water. For brass burner caps, avoid harsh chemicals that may tarnish the finish.
- Ensure all parts are thoroughly dry before reassembling. Blocked burner holes can affect flame quality.
- Clean the ignition pin gently with a dry cloth if it becomes dirty.

7. TROUBLESHOOTING

If you encounter issues with your hob, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply Ignition pin dirty/wet Burner parts incorrectly assembled Battery for auto-ignition low	Check gas valve Clean and dry ignition pin Reassemble burner parts correctly Replace 1.5V battery
Flame is uneven or yellow	Burner holes blocked Burner parts wet	Clean burner holes Ensure burner parts are dry before use
Gas smell detected	Gas leak	Turn off gas supply, open windows, do not operate electrical switches, contact service immediately.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Faber HOB PRIME HT784 CRS BR CI AI 4 Burner 78cm Gas Hob:

Feature	Detail
Model Number	106.0714.586
Colour	Black
Material	Glass
Special Feature	Automatic Ignition
Heating Elements	4 (Brass Burners: 2 x 2.5 kW, 2 x 1.5 kW)
Controls Type	Knob
Voltage (for Ignition)	1.5 Volts

Feature	Detail
Power Source Type	Gas Powered
Item Dimensions (D x W x H)	52.5D x 78W x 13H Centimeters
Item Weight	15280 Grams
Included Components	Hobtop
Manufacture Year	2024

9. WARRANTY & SUPPORT

Faber provides comprehensive warranty coverage for your hob:

- **5 Years Warranty:** On Glass and Valve components.
- **2 Years Warranty:** On Burner components.
- **1 Year Comprehensive Warranty:** On the entire appliance by Faber.

Additionally, you may opt for an extended warranty plan:

- **3 Years Faber Protect+ Extended Warranty:** Available for purchase.

Customer Support:

For any service, installation, or warranty-related queries, please contact Faber customer care:

Toll-Free Helpline: 1800-209-3484

Manufacturer Contact: Franke Faber India Pvt Ltd, 1086/1/2, SANASWADI, TAL - SHIRUR, PUNE - 412208, MAHARASHTRA, INDIA.



ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question