

ENJOY PET SE369

ENJOY PET RGB Laser Projector Light User Manual

Model: SE369 | Brand: ENJOY PET

1. INTRODUCTION

Thank you for choosing the ENJOY PET RGB Laser Projector Light. This device is designed to project vibrant red, green, and blue starry light shows, creating a festive atmosphere for various occasions. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.

2. SAFETY INFORMATION

- **Laser Safety:** This product uses laser light. Avoid direct eye exposure to the laser beam. Do not stare into the aperture.
- **Waterproof Rating:** The projector is IP65 waterproof, suitable for outdoor use in various weather conditions (operating temperature: -10°C to 40°C / -4°F to 104°F). Ensure the power adapter connection is secure and protected from direct water exposure.
- **Power Supply:** Use only the provided power adapter. Ensure the power source matches the adapter's requirements.
- **Placement:** Position the projector securely to prevent it from falling or being damaged. Keep out of reach of children.
- **Ventilation:** Ensure adequate ventilation around the projector to prevent overheating.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x ENJOY PET RGB Laser Projector Light
- 1 x Remote Control (with 1 Lithium Metal battery included)
- 1 x Power Adapter (with 16.4ft power cord)
- 1 x Ground Stake
- 1 x Mounting Plate
- Screws for mounting

4. SETUP

4.1 Installation Options

The projector offers versatile installation methods:

1. **Ground Stake Installation:** Attach the ground stake to the projector. Insert the stake firmly into soft ground (e.g., lawn, garden bed).
2. **Flat Base Installation:** Attach the mounting plate (flat base) to the projector. Place it on a flat surface such as a table or patio.
3. **Wall Mounting:** Use the provided screws to secure the mounting plate to a wall or other vertical surface.

3 Ways to Install for Indoor Outdoor Use



Image: Illustration of the three installation methods: ground stake, flat base, and wall mount.

4.2 Connecting Power

Connect the power adapter to the projector and then plug it into a standard electrical outlet. The 16.4ft power cord provides flexibility for placement.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions

The wireless remote control allows for convenient adjustment of the projector's settings:

- **Power On/Off:** Use the power button to turn the projector on or off.
- **Color Selection:** Choose individual colors (Red, Green, Blue) or combinations.
- **Flash Speed:** Adjust the speed at which the lights flash.
- **Motion Speed:** Control the movement speed of the projected patterns.
- **Timer Settings:** Set the projector to automatically turn off after 1H, 2H, 3H, 4H, 5H, or 6H. The default timer when powered on is 8H.

5.2 Projected Effects

The projector displays 7 effects of starry shows, projecting thousands of moving colorful spots like stars and fireflies. The lamp head is 180° rotatable to adjust the projection angle.



Image: The projector casting a colorful starry light show onto a house.

Outdoor Firefly Projector Light




Image: The projector casting a colorful starry light show onto a large tree.



Image: Various application scenarios for the projector, including Christmas, Halloween, and parties.

5.3 Official Product Video

Video: An official product video from RAKTIC Direct demonstrating the RGB Firefly Laser Projector Light in action, showcasing its various colors and effects.

6. MAINTENANCE

To ensure the longevity and optimal performance of your projector:

- **Cleaning:** Periodically wipe the lens and exterior with a soft, dry cloth to remove dust and debris. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Inspect the power cord regularly for any signs of damage. Do not use if the cord is frayed or damaged.

7. TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common solutions:

- **No Power:** Ensure the power adapter is securely plugged into both the projector and a working electrical outlet. Check if the outlet is functional.
- **No Light Projection:** Verify that the projector is powered on. Check the remote control battery and ensure it is pointed directly at the projector's sensor.
- **Remote Not Responding:** Replace the remote control battery. Ensure there are no obstructions between the remote and the projector.
- **Dim Projection:** Ensure the projector lens is clean. For optimal brightness, use the projector in dark environments.

8. SPECIFICATIONS

Model Number	SE369
Color	RGB Stars
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Corded Electric
Wattage	5 watts
Item Weight	15.2 ounces
Product Dimensions	4.13"L x 3.94"W x 7.1"H
Waterproof Rating	IP65
Operating Temperature	-10°C 40°C (-4°F 104°F)
Coverage Area	Up to 3200 sq ft (from 32.8ft distance)
Lamp Head Rotation	180°

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact ENJOY PET customer service through the retailer where the product was purchased. Please have your model number (SE369) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D7ZTLFY4>

More documents and user manuals: <https://manuals.plus/>