

Tronsmart T7 Lite

Tronsmart T7 Lite Portable Bluetooth Speaker User Manual

Model: T7 Lite | Brand: Tronsmart

INTRODUCTION

Thank you for choosing the Tronsmart T7 Lite Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read it thoroughly before use.

WHAT'S IN THE BOX

- 1 x T7 Lite Portable Outdoor Speaker
- 1 x Type-C Charging Cable
- 1 x User Manual
- 1 x Lanyard
- Warranty Card

PRODUCT OVERVIEW

Familiarize yourself with the Tronsmart T7 Lite speaker's components and controls.



Image: The Tronsmart T7 Lite speaker, highlighting its control panel and overall design. This image shows the speaker in a splash of water, emphasizing its waterproof feature.

Control Buttons & Ports

- **Power Button:** Press and hold to power on/off.
- **Bluetooth Button:** Press to enter Bluetooth pairing mode.
- **Volume Up (+):** Increase volume.
- **Volume Down (-):** Decrease volume.
- **Play/Pause Button:** Play or pause audio.
- **EQ Button:** Cycle through equalizer modes.
- **Type-C Charging Port:** For charging the speaker.
- **AUX-in Port:** For wired audio connection.
- **TF Card Slot:** For playing music directly from a TF card.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker using the provided Type-C charging cable and a compatible USB

power adapter (not included). The LED indicator will show charging status.

2. Power On/Off

Press and hold the Power button for 2 seconds to turn the speaker on or off. A sound prompt will indicate the power status.

3. Bluetooth Pairing

1. Turn on the speaker. The Bluetooth indicator will flash blue, indicating it's ready for pairing.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Select "Tronsmart T7 Lite" from the list of available Bluetooth devices.
4. Once connected, the Bluetooth indicator will remain solid blue, and you will hear a confirmation sound.

The speaker features Bluetooth 5.3, offering a stable wireless connection up to 49 feet (15 meters).



Image: A detailed view of the Tronsmart T7 Lite speaker's internal components, highlighting the Bluetooth 5.3 chip for fast and smooth streaming.

OPERATING THE SPEAKER

Basic Controls

- **Play/Pause:** Short press the Play/Pause button.
- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.
- **Answer/End Call:** Short press the Play/Pause button.
- **Reject Call:** Long press the Play/Pause button.

EQ and App Control

Customize your audio experience using the Tronsmart app. The app allows you to adjust the equalizer settings and control the light show. Download the Tronsmart app from your device's app store.




Image: The Tronsmart T7 Lite speaker shown with a smartphone displaying the Tronsmart app, illustrating the customizable EQ feature.

Rainbow Light Show

The speaker features a dynamic rainbow light show that moves to the beat of your music. Press the EQ button to cycle through different light modes or turn the lights off. You can also control the light show via

the Tronsmart app.

RAINBOW LIGHT SHOW

Shiny light creates a fantastic light show



Image: Multiple Tronsmart T7 Lite speakers showcasing their vibrant rainbow light show feature, with lights changing colors.

True Wireless Stereo (TWS) Pairing

For an immersive stereo sound experience, you can pair two Tronsmart T7 Lite speakers together.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the Bluetooth button for 3 seconds until you hear a prompt.
3. The two speakers will automatically connect to each other. Once connected, the primary speaker's Bluetooth indicator will flash blue, and the secondary speaker's indicator will be solid blue.
4. Connect your device to the primary speaker via Bluetooth.

STEREO PAIRING

Pair 2 speakers to amplify your listening



Image: Two Tronsmart T7 Lite speakers positioned on either side of a laptop, illustrating the True Wireless Stereo (TWS) pairing feature for amplified sound.

KEY FEATURES

- **Enhanced Bass & Versatility:** The T7 Lite features a cutout design that reduces obstructions to sound transmission, boosting bass output. It delivers powerful audio with a maximum volume of 90dB.
- **24 Hours Playtime:** Equipped with a built-in 4000mAh battery, the speaker can continuously play high-quality audio for up to 24 hours at 50% volume. Playtime may vary based on light display, audio content, and volume levels.

24 HOURS OF PLAYTIME

Keep powering your day with a built-in 4000mAh battery



*Varied by Light Display, Audio Contents & Volume Levels

Image: The Tronsmart T7 Lite speaker placed on a clock graphic, emphasizing its 24-hour playtime capability.

- **IPX7 Waterproof & Durable Fabric:** This wireless Bluetooth speaker is resistant to rain, splashes, and can be submerged in 3.3 feet of water for up to 30 minutes. Its durable fabric material and sturdy rubber cover provide protection for outdoor use.

IPX7 WATERPROOF



Image: The Tronsmart T7 Lite speaker partially submerged in water, visually confirming its IPX7 waterproof rating.

- **Vibrant Color Options:** The T7 Lite is available in various colors, allowing you to choose one that matches your style.

LISTEN ON YOUR WAY

Freely set to fit your space




Image: The Tronsmart T7 Lite speaker displayed in both horizontal and vertical orientations, illustrating its adaptable design for various settings.

SPECIFICATIONS

Brand	Tronsmart
Model Name	T7 Lite
Speaker Type	Outdoor
Special Features	LED Light, Lightweight, Portable, Stereo Pairing, Waterproof
Connectivity Technology	Bluetooth 5.3
Wireless Range	49 Feet (15 meters)
Maximum Output Power	24 Watts
Playtime	Up to 24 hours (at 50% volume)
Waterproof Rating	IPX7
Control Method	App, Buttons

Product Dimensions	2.83"D x 2.83"W x 7.68"H (7.2cm x 7.2cm x 19.5cm)
Item Weight	1.04 Pounds (0.47 kg)
Battery	1 Lithium Ion battery (included)

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker fully at least once every three months if not in regular use.
- **Water Exposure:** While IPX7 rated, ensure the charging port cover is securely closed before exposing the speaker to water. After exposure, dry the speaker thoroughly before charging.

TROUBLESHOOTING

Speaker does not power on:

Ensure the speaker is fully charged. Connect it to a power source and try again.

Cannot pair with Bluetooth device:

Make sure the speaker is in pairing mode (Bluetooth indicator flashing blue). Ensure your device's Bluetooth is enabled and within range. Forget previous pairings on your device and try reconnecting.

No sound or low volume:

Check the volume levels on both the speaker and your connected device. Ensure the speaker is not muted. If using AUX-in, check the cable connection.

TWS pairing failed:

Ensure both speakers are Tronsmart T7 Lite models and are not connected to any other Bluetooth devices. Try resetting both speakers and repeating the TWS pairing steps.

WARRANTY AND SUPPORT

The Tronsmart T7 Lite Portable Bluetooth Speaker comes with a limited warranty. Please refer to the included Warranty Card for detailed terms and conditions. For technical support, product inquiries, or warranty claims, please visit the official Tronsmart website or contact their customer service directly.

Official Tronsmart Store: [Tronsmart Store on Amazon](#)

PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the Tronsmart T7 Lite 24W Portable Bluetooth Speaker's features, including its design, sound quality, and light show. This video is provided by the Tronsmart Official Store.

