

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [AWEI](#) /
- › [AWEI Wireless Earbuds T56 Instruction Manual](#)

AWEI T56

AWEI Wireless Earbuds T56 Instruction Manual

Model: T56 | Brand: AWEI

PRODUCT OVERVIEW

The AWEI T56 Wireless Earbuds are designed for a superior audio experience, featuring Bluetooth 5.4 connectivity, a smart touch screen charging case, active noise cancellation (ANC), and an IPX6 waterproof rating. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.



Image: The AWEI T56 Wireless Earbuds, black in color, shown with their smart touch screen charging case. The earbuds are visible outside the case, highlighting their sleek design.

Your browser does not support the video tag.

Video: An official overview of the AWEI T56 Wireless Bluetooth Headset, demonstrating its features and design. This video highlights the product's key functionalities and aesthetic appeal.

PACKAGE CONTENTS

Upon opening the package, please verify that all components are present:

- Bluetooth headset (2 earbuds)
- USB charging cable
- User manual (this document)
- Large & small earplugs (pre-installed medium earplugs)



Image: A visual representation of the AWEI T56 earbuds, charging case, USB charging cable, and various sizes of ear tips included in the package.

SETUP GUIDE

1. Charging the Device

Before first use, fully charge the earbuds and the charging case. The charging case has a 500mAh battery capacity, and the earbuds have a 35mAh capacity each. A full charge for the earbuds takes approximately 1.5 hours, and the case takes about 2.5 hours. The earbuds can be used for up to 5 hours on a single charge.

1. Connect the provided USB charging cable to the charging port on the case.

2. Connect the other end of the cable to a compatible USB power source (e.g., computer, wall adapter).
3. The LED display on the charging case will indicate the charging status and battery levels for both the case and individual earbuds.

{Five sound effects collocation}

Balanced | Jazz | Bass | Stereo | Voice four



{Long battery life}

Stay with you all day



Name : LED color screen
bluetooth headset

Charging box capacity : 500mAh

Model : T56ANC

Headphone capacity : 35mAh

Color : black

Talk time : 4 hours

Bluetooth : 5.4

Music time : 5 hours

Image: Details on the battery life and charging specifications of the AWEI T56, showing the charging box capacity, headphone capacity, talk time, and music time.

2. Bluetooth Pairing

The AWEI T56 earbuds utilize Bluetooth 5.4 technology for a stable and fast connection. They are designed for automatic connection once initially paired.

1. Ensure the earbuds are in the charging case and the case has sufficient power.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop, etc.), navigate to the Bluetooth settings.
4. Select "AWEI T56" from the list of available devices.
5. Once connected, a confirmation sound will play, and the device will show "Connected".

For subsequent uses, simply open the charging case, and the earbuds will automatically connect to the last paired device.

【 Bluetooth 5.4 "Core" Upgrade 】

- Ultra-low power consumption
- Two-way transmission
- Synchronization technology
- Low sense delay



Ding....



【 Find Headphones 】

"Ding Ding Ding ~ Master, I am here!"

Image: Illustrates the Bluetooth 5.4 core upgrade for the AWEI T56 earbuds, emphasizing ultra-low power consumption and stable connection. It also shows the "Find Headphones" feature on the case screen.

OPERATING INSTRUCTIONS

The AWEI T56 features a smart touch screen on the charging case and touch controls on the earbuds for comprehensive functionality.

1. Smart Touch Screen Functions (Charging Case)

The full-color touch screen on the charging case provides access to 12 distinct functions:

- **Music Switching:** Navigate between tracks.
- **Volume Adjustment:** Control audio output level.
- **Ambient Sound Effect Switching:** Toggle between different sound modes (e.g., ANC, Transparency).
- **Equalizer Mode Switching:** Select various audio equalizer presets.
- **Screen Brightness Adjustment:** Modify the display brightness.
- **Lock Screen Wallpaper Switching:** Customize the case display.
- **Space Sound Effect Adjustment:** Adjust spatial audio settings.
- **Searching for Headphones:** Locate misplaced earbuds.

- **Torch:** Activate a flashlight function.
- **Stopwatch:** Use a built-in stopwatch.
- **Language Switching:** Change the display language.
- **Setting the Time:** Adjust the time displayed on the screen.



Image: A detailed view of the AWEI T56 charging case's touch screen, showcasing multiple functions like music control, volume adjustment, noise reduction control, lock screen wallpapers, screen intensity, flashlight, language switching, and headphone search.

2. Earbud Touch Controls

Specific touch gestures on the earbuds allow for quick control of audio and calls. Refer to the quick start guide included in the package for a detailed diagram of touch commands.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Toggle ANC/Transparency Mode:** Long press and hold on either earbud (duration may vary, refer to

quick start guide).

3. Active Noise Cancellation (ANC)

The AWEI T56 earbuds feature Active Noise Cancellation to reduce ambient noise, providing an immersive listening experience. This function can be controlled via the touch screen on the charging case or through specific earbud touch gestures.



Image: Highlights the ANC environmental noise reduction capability of the AWEI T56 earbuds, ensuring a quiet listening environment. Also shows the internal structure of an earbud speaker, indicating high sound quality with balanced treble and bass.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AWEI T56 Wireless Earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. For ear tips, remove them and clean with mild soap and water, ensuring they are completely dry before reattaching.
- **Water Resistance:** The earbuds have an IPX6 waterproof rating, meaning they are protected against powerful water jets. While suitable for sports and light rain, they are not designed for submersion in

water. Do not expose the charging case to water.

- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

ANC+ENC

EARBUDS WITH SCREEN



Bluetooth
Version V5.4



Waterproof
IPX6 Level



Smart
Touch



Built-in 500mAh
Charging Case



Image: Showcases the key features of the AWEI T56 earbuds, including Bluetooth Version V5.4, Waterproof IPX6 Level, Smart Touch, and a Built-in 500mAh Charging Case.

TROUBLESHOOTING

If you encounter issues with your AWEI T56 earbuds, refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Earbuds not in pairing mode, out of range, or previously paired to another device.	Ensure earbuds are in the case and open the lid to activate pairing. Turn off Bluetooth on other devices. Forget "AWEI T56" in your device's Bluetooth settings and re-pair.

Problem	Possible Cause	Solution
No sound or low volume.	Low battery, volume too low on device/earbuds, or earbud placement.	Charge earbuds and case. Increase volume on both your device and via the earbud/case controls. Adjust earbud fit.
Charging case display unresponsive.	Low battery in case, or temporary software glitch.	Charge the case. If issue persists, try a soft reset by holding the reset button (if available, refer to quick start guide) or letting the battery fully drain and recharge.
ANC not working effectively.	Improper fit, or ANC mode not activated.	Ensure earbuds are properly seated in your ears for a good seal. Toggle ANC mode via the touch screen or earbud controls.

SPECIFICATIONS

Feature	Detail
Model Name	T56
Bluetooth Version	5.4
Noise Control	Active Noise Cancellation
Water Resistance Level	IPX6 Waterproof
Charging Case Battery Capacity	500mAh
Earbud Battery Life (Music Time)	5 Hours
Charging Time	1.5 Hours (earbuds), 2.5 Hours (case)
Control Type	Touch (Earbuds & Case Screen)
Compatible Devices	Cellphones, Tablets, Telephones, Laptops
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm
Item Weight	6.3 ounces

WARRANTY AND SUPPORT

AWEI products are manufactured with high standards of quality and craftsmanship. For any questions or concerns regarding your AWEI T56 Wireless Earbuds, please contact our customer support team. We are committed to providing solutions within 24 hours.

For further assistance, please refer to the contact information provided on the official AWEI website or the warranty card included with your product.

