

[manuals.plus](#) /

› [ARTTI](#) /

› [ARTTI T10 Earphone Instruction Manual](#)

ARTTI T10

ARTTI T10 In-Ear Earphone User Manual

Model: T10 | Brand: ARTTI

1. INTRODUCTION

The ARTTI T10 in-ear earphones are engineered for high-fidelity audio reproduction, featuring a 14.2mm dual magnetic circuit planar driver. Designed for audiophiles, musicians, and gamers, these IEMs deliver a pristine and accurate sound experience with significantly reduced distortion. This manual provides essential information for setting up, operating, and maintaining your ARTTI T10 earphones to ensure optimal performance and longevity.



Image: ARTTI T10 In-Ear Earphones with detachable cable.

2. WHAT'S IN THE BOX

Upon unboxing your ARTTI T10 earphones, please verify that all the following components are included:

- ARTTI T10 Earphone Units
- Detachable 4-Core Silver-Plated Cable (with 2-pin connectors and 3.5mm termination plug)
- Ear Cushions (various sizes)
- Protective Case
- User Manual (this document)

3. SETUP GUIDE

3.1 Connecting the Cable

The ARTTI T10 features a detachable 2-pin cable for enhanced durability and versatility. Follow these steps to connect the cable:

1. Identify the left (L) and right (R) earphone units and the corresponding connectors on the cable. The cable connectors are typically marked.
2. Align the 2-pin connector on the cable with the receptacle on the earphone unit. Ensure the pins are correctly oriented.
3. Gently push the connector firmly into the earphone unit until it clicks into place. Do not force the connection.
4. Repeat for the other earphone unit.



Image: Detailed view of the detachable 2-pin cable and 3.5mm termination plug.

3.2 Choosing and Installing Ear Tips

Selecting the correct ear tip size is crucial for optimal sound quality, bass response, and comfort. Experiment with the included ear tips to find the best fit for your ears.

- Gently remove the pre-installed ear tips by pulling them off the nozzle.
- Select a new pair of ear tips. Start with a medium size and adjust as needed.
- Push the new ear tip onto the earphone nozzle until it is securely seated.

3.3 Proper Ear Placement

For the best listening experience and secure fit, follow these steps for proper ear placement:

1. Insert the earphone unit into your ear canal.
2. Gently rotate the earphone until it feels snug and comfortable, creating a good seal. The cable is designed to loop over the top of your ear.
3. Ensure the ear tip forms a complete seal within your ear canal to maximize bass response and noise isolation.



Image: Illustration of the ARTTI T10 earphone worn correctly for an ergonomic and comfortable fit.

4. OPERATING INSTRUCTIONS

4.1 Connecting to an Audio Source

Once the cable is securely attached to the earphone units, connect the 3.5mm termination plug to your audio device. The ARTTI T10 is compatible with a wide range of devices including:

- Smartphones and Tablets
- Laptops and Desktops
- Digital Audio Players (DAPs)
- Gaming Consoles (with 3.5mm jack)
- Car Audio Systems

4.2 Audio Playback and Control

After connecting, select your desired audio content on your device. Adjust the volume using your device's controls. The ARTTI T10 may feature inline media control or remote control functionality depending on the specific cable version. Refer to your cable's design for specific button functions (e.g., play/pause, track skip, volume).

ARTTI T10 HiFi IEM Earphones

Extraodinary HiFi Audio Experience



Image: ARTTI T10 earphones connected to a portable audio device.

5. MAINTENANCE AND CARE

Proper care will extend the lifespan and maintain the performance of your ARTTI T10 earphones.

5.1 Cleaning

- Earphone Units:** Use a soft, dry, lint-free cloth to wipe the exterior of the earphone units. Avoid using harsh chemicals or abrasive materials.
- Ear Tips:** Remove the ear tips from the earphones. They can be gently washed with mild soap and water. Ensure they are completely dry before reattaching them to the earphones.
- Nozzles:** Periodically check the earphone nozzles for earwax buildup. Use a small, soft brush or a cleaning tool specifically designed for earphones to carefully remove any debris. Do not push debris further into the nozzle.

5.2 Storage

When not in use, store your ARTTI T10 earphones in the provided protective case. This will prevent tangling, physical damage, and exposure to dust or moisture.

5.3 Cable Care

Handle the detachable cable with care. Avoid sharp bends, excessive pulling, or twisting, as this can damage the internal wires. Disconnect the cable by gripping the connector housing, not the cable itself.

6. TROUBLESHOOTING

If you encounter issues with your ARTTI T10 earphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound or very low volume	Loose cable connection, incorrect ear tip seal, device volume too low, incorrect audio output selected on device.	Ensure cable is fully inserted into both earphone units and audio source. Check ear tip fit for a proper seal. Increase volume on your audio device. Verify correct audio output settings on your device.
Distorted or poor sound quality	Loose cable connection, damaged cable, earwax buildup in nozzle, low-quality audio source.	Check all cable connections. Inspect cable for visible damage. Clean earphone nozzles. Try a different audio source or higher quality audio files.
Uncomfortable fit or earphones falling out	Incorrect ear tip size, improper ear placement.	Experiment with different ear tip sizes to find the most comfortable and secure fit. Adjust earphone placement in your ear canal, ensuring the cable loops over your ear.
Only one side has sound	Loose connection on one earphone unit, damaged earphone unit or cable, device audio balance settings.	Ensure both 2-pin connectors are fully inserted. Try swapping the earphone units (left to right, right to left) to determine if the issue is with the earphone or the cable. Check your device's audio balance settings.

7. SPECIFICATIONS

Detailed technical specifications for the ARTTI T10 In-Ear Earphones:




Image: Visual representation of ARTTI T10 HiFi Earphones specifications.

Feature	Detail
Model Name	T10

Feature	Detail
Driver Configuration	14.2mm Dual Magnetic Circuit Planar Driver
Frequency Range	20Hz-20kHz
Impedance	16.5 Ohm
Sensitivity	96dB/mW (@1kHz)
Distortion	<1.5% (@1kHz)
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack (standard)
Cable Feature	Detachable, 4-Core 216 Strands High-Purity Oxygen-Free Copper Silver-Plated Wire
Cable Length	1.2m
Cable Connector	Standard 0.78mm 2-Pin
Cavity Material	PC Engineering Plastic with UV handling technique
Faceplate	6063 Aviation Aluminum Alloy CNC Carved Decorative Plate
Earpiece Shape	Rounded Tips
Item Weight	8.4 ounces (0.24 Kilograms)
Included Components	Cable, Ear Cushions, Protective Case, User Manual

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, terms, and conditions for your ARTTI T10 earphones, please refer to the warranty card included with your product or contact ARTTI customer support directly. Warranty details may vary based on region and retailer.

For technical support, product inquiries, or service requests, please visit the official ARTTI website or contact their customer service department through the contact information provided at the point of purchase or on the manufacturer's website.