

KAFF CTC634B

KAFF CTC 63 4B Gas Stove/Cooktop User Manual

Model: CTC634B | Brand: KAFF

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure proper ventilation in the kitchen area when operating the gas stove.
- Do not store flammable materials near the appliance.
- Keep children and pets away from the gas stove during operation.
- Always use appropriate cookware sizes for the burners.
- Do not leave cooking unattended.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.
- Ensure the gas connection is secure and free from leaks.
- Allow the appliance to cool down completely before cleaning or maintenance.

2. PRODUCT OVERVIEW

The KAFF CTC 63 4B is a 63 CM gas stove/cooktop designed for efficient cooking. It features four high-efficiency brass burners, a durable black tempered glass surface, and enamelled pan supports.

Key Features:

- **Type:** Glasstop Gas Stove/Cooktop
- **Size:** 63 CM
- **Ignition Type:** Manual Ignition
- **Glass Type:** 8mm Thick Black Tempered Glass
- **Color:** Black
- **Pan Support:** Enamelled
- **Burners:** 4 Brass Burners (1 Jumbo, 2 Big, 1 Small)
- **Design:** Slim Line design

- **Drip Tray:** Stainless Steel Drip Tray
- **Knobs:** Metal Knobs



Image: The KAFF CTC 63 4B Gas Stove, showcasing its four brass burners and sleek black tempered glass surface.

KAFF
Pride Built-In

High Efficiency Brass Burners

For Even Heat Distribution

4 Burners : 1 Jumbo, 2 Big, 1 Small



Image: High Efficiency Brass Burners for even heat distribution, featuring one jumbo, two big, and one small burner.

Matt Enameled Pan Support

Suitable for all types of Indian utilized



Image: Matt enamelled pan supports, suitable for various types of cookware, providing stable support.

Black Toughened Glass

With Matt Black Finish

Enhance Safety and Durability



Image: Black Toughened Glass with a matte black finish, designed to enhance safety and durability.

3. SETUP AND INSTALLATION

This section provides guidelines for the proper setup of your KAFF gas stove. It is recommended that installation be performed by a qualified technician.

3.1 Unpacking and Inspection

- Carefully remove the appliance from its packaging.
- Inspect for any damage during transit. Do not install if damaged.
- Ensure all included components are present: 1x Cooktop, 1x Warranty Card, 1x User Manual.

3.2 Placement

The KAFF CTC 63 4B is designed for free-standing installation. Place the cooktop on a stable, level, and heat-resistant surface, away from flammable materials.

KAFF
Pride Built-In

Installation Type : Free Standing

User-friendly controls for effortless operation



Image: The gas stove illustrating its free-standing installation type, with user-friendly controls for effortless operation.

3.3 Gas Connection

- Connect the gas stove to a suitable gas supply using an approved gas hose and regulator.
- Check all connections for leaks using a soapy water solution. Bubbles indicate a leak.
- Ensure the gas pressure is appropriate for the appliance.

4. OPERATING INSTRUCTIONS

This section details how to safely operate your gas stove.

4.1 Burner Ignition (Manual)

1. Place your cookware on the pan support over the desired burner.
2. Push and turn the corresponding knob counter-clockwise to the "Ignite" position.
3. While holding the knob in, bring a lit match or gas lighter close to the burner.
4. Once the flame ignites, continue to hold the knob for a few seconds to allow the thermocouple to heat up and keep the gas flowing.
5. Release the knob and adjust the flame to your desired intensity by rotating the knob.

KAFF
Pride Built-In

Easy Grip Knobs

For Precision Flame Control



Image: Easy Grip Knobs designed for precise flame control, allowing for accurate heat adjustment.

4.2 Adjusting Flame

Rotate the knob to increase or decrease the flame size. For simmering, turn the knob to the lowest setting. Ensure the flame does not extend beyond the base of your cookware.

4.3 Turning Off

To turn off a burner, rotate the knob clockwise until it clicks into the "Off" position. Ensure the flame is completely extinguished.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and efficient operation of your gas stove.

5.1 Daily Cleaning

- Allow the cooktop to cool completely before cleaning.
- Wipe the tempered glass surface with a soft cloth and mild detergent. Avoid abrasive cleaners.
- Clean the enamelled pan supports and brass burners with warm soapy water. Dry thoroughly before reassembling.



Image: The gas stove highlighting its low maintenance and easy-to-clean design, simplifying upkeep.

5.2 Stainless Steel Drip Tray

The stainless steel drip tray collects spills and overflow. Remove and clean it regularly to prevent residue buildup.

KAFF
Pride Built-In

Stainless Steel Drip Tray

collects spills, drips, & overflow during cooking



Image: The stainless steel drip tray, designed to collect spills, drips, and overflow during cooking, ensuring a cleaner cooking surface.

5.3 Burner Maintenance

- Periodically check the burner ports for blockages. Use a fine wire or needle to clear any debris.
- Ensure the burner caps are correctly seated after cleaning.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your gas stove.

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, clogged burner ports, faulty lighter.	Check gas cylinder/supply. Clean burner ports. Use an external lighter.
Flame is weak or uneven.	Clogged burner ports, low gas pressure, incorrect burner cap placement.	Clean burner ports. Check gas regulator. Ensure burner cap is seated correctly.
Gas smell detected.	Gas leak.	Immediately turn off gas supply, ventilate area, do not use electrical switches. Contact a qualified technician.
Knob is stiff.	Food residue or debris under the knob.	Clean around the knob base. Do not force the knob.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

Detailed technical specifications for the KAFF CTC 63 4B Gas Stove.

Feature	Detail
Model Number	CTC634B
Colour	Black
Material	Stainless Steel (body), 8mm Black Tempered Glass (top)
Special Features	High Efficiency Brass Burners, Matte Black Finish, Slim Line Design
Number of Heating Elements	4 (1 Jumbo, 2 Big, 1 Small)
Controls Type	Knob
Power Source Type	Gas
Item Dimensions (D x W x H)	73.7D x 61W x 17.8H Centimeters
Item Weight	17.7 Kilograms
Country of Origin	India



Image: Dimensional diagram of the KAFF CTC 63 4B Gas Stove, showing length, width, and height measurements.

8. WARRANTY INFORMATION

Your KAFF CTC 63 4B Gas Stove comes with the following manufacturer's warranty:

- **1 Year Warranty:** Covers Pan Supports, Bypass, Ignition, Generator.
- **2 Years Warranty:** Covers Glass.
- **5 Years Warranty:** Covers Burners.

Please refer to the included Warranty Card for complete terms and conditions.

9. CUSTOMER SUPPORT

For any queries, service requests, or technical assistance, please contact KAFF customer support:

- **Manufacturer:** Kaff Appliances (I) Pvt. Ltd.
- **Address:** SS Plaza 4th floor, Opp. Hilton Garden Inn Sec-47, Gurgaon – 122018
- **Toll-Free Number:** 18001802221

Please have your model number (CTC634B) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question