**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Cofiyard VM-YC01**

# Cofiyard Propane 2 Burner Camping Stove User Manual

Model: VM-YC01 | Brand: Cofiyard

## 1. Important Safety Information

Please read and understand all safety warnings and instructions before operating this appliance. Failure to follow these instructions could result in fire, explosion, serious injury, or death.

- **FOR OUTDOOR USE ONLY:** Never operate this appliance indoors, in an enclosed space, or in a vehicle. Carbon monoxide poisoning can occur.
- **VENTILATION:** Ensure adequate ventilation when operating.
- **LEAK CHECK:** Always perform a leak test before initial use, after replacing the propane cylinder, or if the appliance has been stored for an extended period. Use a soapy water solution; never use a flame.
- **FLAMMABLE MATERIALS:** Keep the stove area clear and free from combustible materials, gasoline, and other flammable vapors and liquids. Maintain a safe distance from walls, ceilings, and other structures.
- **CHILDREN AND PETS:** Keep children and pets away from the stove during operation and while it is cooling down.
- **STABLE SURFACE:** Always operate the stove on a firm, level, non-combustible surface.
- **HOT SURFACES:** The stove and its components will become extremely hot during use. Allow ample time for cooling before handling or storing.
- **PROPANE CYLINDER:** Use only propane gas. Connect the propane cylinder outdoors and away from ignition sources. Store propane cylinders outdoors in a well-ventilated area, out of reach of children.
- **MODIFICATIONS:** Do not modify this appliance. Any modification may be dangerous and will void the warranty.

## 2. Package Contents

Verify that all items are present in your package:

- 1 x Cofiyard Camping Gas Stove with 2 Burners (Folding)
- 1 x Cofiyard Gas Stove Connector
- 1 x Cofiyard Woven Carry Bag
- 1 x User Manual (this document)

## 3. Setup Instructions

Follow these steps to set up your Cofiyard camping stove:

1. **Unpack:** Carefully remove all components from the packaging.

2. **Unfold the Stove:** Place the folded stove on a stable, level surface. Unclasp the securing strap and gently unfold the two burner units until they are fully extended and locked into place.
3. **Connect Gas Connector:** Attach the included gas stove connector to the stove's gas inlet. Ensure it is securely tightened.
4. **Connect Propane Cylinder:** Connect the other end of the gas connector to a standard 1 lb propane cylinder. Hand-tighten only. Do not overtighten.
5. **Perform Leak Test:** Before lighting, apply a soapy water solution to all gas connections. If bubbles appear, there is a leak. Tighten connections and retest. If leaks persist, do not use the stove.
6. **Positioning:** Place the stove on a flat, stable, non-combustible surface, away from any flammable materials or structures.




The Cofiyard 2-burner camping stove unfolded, showing the gas connector ready for propane tank attachment.

## 4. Operating Instructions

Operating your Cofiyard camping stove is straightforward:

1. **Prepare Cookware:** Place your pots or pans on the stove grates. The stove is designed to comfortably fit two 10-inch frying pans simultaneously.

2. **Ignite Burner:** Turn the control knob for the desired burner slowly counter-clockwise to the "ON" position. Immediately press the built-in ignitor button located next to the control knob. You should hear a click and see the flame ignite. If it doesn't light on the first try, turn the knob to "OFF", wait a few seconds, and repeat. If the ignitor fails, use a long-stem lighter or match.
3. **Adjust Flame:** Once lit, adjust the flame intensity by rotating the control knob. Turn clockwise for a lower flame and counter-clockwise for a higher flame. Each burner has an independent control knob for precise heat management.
4. **Cooking:** Begin cooking. The stove provides a total output of 17,000 BTU, offering powerful heat for various culinary needs.
5. **Turn Off:** When finished cooking, turn the control knob for each burner clockwise to the "OFF" position until the flame extinguishes completely.
6. **Disconnect Propane:** Once the stove has cooled, disconnect the propane cylinder from the gas connector.




The dual burner design allows for simultaneous cooking with two large pans.




The stove provides a total output of 17,000 BTU for efficient cooking.

## 5. Maintenance

Proper maintenance ensures the longevity and safe operation of your stove:

- **Cleaning:** After each use, ensure the stove is completely cool. The stove rack (grates) can be easily removed for convenient cleaning. Wipe down the surfaces with a damp cloth. Do not use abrasive cleaners.
- **Burner Oxidation:** It is normal for the stainless steel burners to oxidize and turn black after high-temperature cooking. This does not affect performance.
- **Storage:** Once clean and completely cool, fold the stove back into its compact form. Secure it with the rubber strap. Store the stove in the included woven carry bag in a dry, well-ventilated area.




The removable grates allow for easy cleaning after use.




The included woven carry bag makes storage and transport convenient.

## 6. Troubleshooting

If you encounter issues with your stove, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Burner does not light with ignitor. | No gas flow; faulty ignitor; ignitor not positioned correctly. | Ensure propane cylinder is connected and valve is open. Check for gas leaks. If ignitor is faulty, use a long-stem lighter or match to light the burner. |
| Low flame or inconsistent flame. | Low propane level; regulator issue; partially clogged burner. | Replace propane cylinder. Ensure gas connector is fully tightened. Clean burner ports if visibly clogged (ensure stove is cool and disconnected from gas). |

| Problem | Possible Cause | Solution |
|---|---|---|
| Gas smell detected. | Gas leak. | Immediately turn off gas at the cylinder. Perform a leak test with soapy water. Do not operate if a leak is present. Contact customer support if unable to resolve. |
| Stove does not unfold or fold smoothly. | Mechanism obstruction or misalignment. | Check for any debris or foreign objects obstructing the folding mechanism. Ensure components are aligned correctly. Do not force. |

## 7. Specifications

Key specifications for the Cofiyard Propane 2 Burner Camping Stove:

- **Brand:** Cofiyard
- **Model Number:** VM-YC01
- **Fuel Type:** Propane
- **Material:** Iron, Metal, Stainless Steel
- **Product Dimensions (Folded):** 9.5"L x 9"W x 4.6"H
- **Unfolded Dimensions:** Approximately 19.3"L x 9"W x 2.3"H
- **Power Source:** Gas Powered
- **Maximum Energy Output:** 17,000 BTU (Total from both burners)
- **Item Weight:** 4.2 Pounds




Detailed dimensions and material specifications of the stove.

## 8. Warranty and Customer Support

Cofiyard provides a 1-year warranty for this product. For any questions, concerns, or support needs, please contact Cofiyard customer service. We offer 24/7 customer support to assist you.

**Contact Information:**

Please refer to the contact details provided on the product packaging or the official Cofiyard website for the most current support information.

You may also visit the Cofiyard Store on Amazon for more information and support resources.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0D81PZWBS**

More documents and user manuals: **https://manuals.plus/**