

Mabe 234D1031P001, WW03F00042, 234D1031P002

Mabe/GE/Easy/IEAM Dryer and Washer-Dryer Combo Lint Filter Instruction Manual

Models: 234D1031P001, WW03F00042, 234D1031P002

Brand: Mabe, General Electric, Easy, IEAM

1. INTRODUCTION

This instruction manual provides essential information for the proper installation, operation, and maintenance of your original Mabe, General Electric (GE), Easy, or IEAM lint filter. This filter is a crucial component for the efficient and safe operation of your dryer or washer-dryer combo, designed to capture lint and debris from your laundry.

Please read this manual thoroughly before installing or using the filter to ensure optimal performance and longevity of your appliance.

2. SAFETY INFORMATION

Always prioritize safety when handling appliance parts. Follow these guidelines:

- Ensure the appliance is unplugged or its power supply is disconnected before attempting any installation or maintenance.
- Handle the filter carefully to avoid bending or damaging the metallic mesh.
- Keep small children and pets away from the appliance during maintenance.
- If you are unsure about any step, consult a qualified technician.

3. PRODUCT OVERVIEW

The lint filter is designed to fit specific Mabe, GE, Easy, and IEAM dryer and washer-dryer combo models. It features a durable metallic mesh construction to effectively trap lint and prevent it from accumulating in the dryer vent system, which can cause fire hazards and reduce drying efficiency.

Key Features:

- **Material:** Steel mesh

- **Color:** Gray
- **Length:** Approximately 33.50 cm (13.19 inches)
- **Reference Codes:** 234D1031P001, WW03F00042, 234D1031P002



Figure 1: Front view of the lint filter, showing its approximate length of 33.50 cm and the reminder to clean before each cycle.



Figure 2: Top view of the lint filter, highlighting its curved design and mesh surface.



Figure 3: Bottom view of the lint filter, showing the structural support and mesh.

4. COMPATIBILITY

This lint filter is compatible with a wide range of Mabe, General Electric (GE), Easy, and IEAM dryer and washer-dryer combo models. Please verify your appliance's model number against the list below to ensure compatibility. If your model is not listed, please contact the seller with your appliance's full model number for assistance.

Compatible Models:

- MCL1740GSBB0, C978-97322, MCL6840PSBB1, GUAP270EMWW, MCL1740ESBB0, MCL1640PWBB0, GTUP270GMWW, MKTG15DNAWB0, MCL1740PSBB0, MCL1740ESGG0, MCL1740PSGG0, GUAN275EDWW, MCL1740ESDG0, GUD27ESMJWW, MCL6840GSBB0, GTUP270EMWW, GTUP270GMWM0, MKTG15DNAWB1, MCL6840ESBB1, MCL1540EEBBX0, C978-97222, MCL6840PSBB0, MCL1540EEBBY0, GTUN275EMWW,

MCL1740PSDG0, MCL6840ESBB0, GUD37ESMJDG, GUD27GSSJWW, MKTG15GNAWB0, MKTG15GNAVB0, ICL1740PSDG1, CLME77014BFU3, XUD27ESSM0WW, CLMPG70204DBB0, GCL2340PSDG0, CLMG70204DBB0, MKTG15DNAVB0, CLMG77104DBB0, MCL2040EPDG0, MCL2440PSBB0, GUD27ESMM0WW, CLME77014DFU4, GUD27GSSMW, MCL1740ESDG1, ECL1540EEBBY0, ECL1540EEDGY0, ICL1740PSDG0, GUD27GSPMDG, MCL1540EEDGY0, MCL2440ESDG0, GUD37ESMM0DG, I24CLG4CBISD0, GUD27ESMMWW, GUD27ESSJWW, MCL1540EEDGX0, MKTG15GNAWB2, MCL1640PWBB1, MCLC2340GPDG0, GTUP270PSDG0, CLME77014DFU3, CLMG77104BBB0, MCLC2240GSBB0, MCLI2440EEBB0, MCL2040ESDG0, MCLC1740GSBB, MCL1540EEDGY1, MCLC2040GSBB0, CLME77014BFU0, MCL2040EEBBY0, CLME77014DFU0, MKTG15GNAWB1, MCLC2040PSDG0, MCLP2440PPDG0, MCL1740GSBB1, C23CLG4CBASB0, GCL2340ESDG0, GUV27ESMWW, GUD27ESSM0WW, MCL1740ESBB1, MCL2040PPDG1, MCLC1740GSBB1, CLME71214BAT0, MCLP2440PSBB0, CLPG70204DBB0, GUD37ESMMDG, MCL2040PPDG0, MCL1540EEBBX01, MCL2040EPDG0, MKTG15DNAWB10, MCL2040GSBB0, KLC076WM, RCL2040PPDG0, CLTG70214BAB0, CLGG70214BAB0, CLME70204BBB0, MCL1540EEDGX, GUV27ESSM0WW, FLC105WM2, MCLC2040PPDG0, GUD37EEMNDG, XUD27GSSM0WW, MCL1740PSDG1, MCLI2440EEDG0, MCL2440PPDG0, WLC105WM2, GLC076WM, LCMP77104BAB0, MCLP2440PSDG0, GUD27ESSMW, GCL2340PSBB0, MCL2340ESDG0, GUD57EEMTDG, MCLI2440EPDG0, MCL2440PSDG0, MCLC1740PSDG, MCL1540EEBBY1, ICL2040PSDG0, MKTG15GNAWB, CLMG70204BBB0, MCL2040PSDG0, MCL1540EEBBY, MCLC1740PSDG1, MCLC2340GSDG0, MCL2040PSBB0, MCL1540EEBBX, MCL2040ESBB0, MCL2440ESBB0, CLME77104BBB0, MCL1740GSBB00, GUD27ESPM0DG, MCL2440EPDG0, CLGG70214DAB0, CLME77014BFU4, MCL1740PSBB1, GUD27ESPMDG, MCLC1740PSDG0, MCL2040EEDGY0, GUD27EEMNWW, MCL2340PSDG0, MCLP2440ESBB0

5. INSTALLATION (REPLACEMENT)

This section outlines the general steps for replacing an existing lint filter. Always refer to your appliance's specific user manual for detailed instructions, as procedures may vary by model.

- 1. Disconnect Power:** Unplug your dryer or washer-dryer combo from the electrical outlet to prevent electric shock.
- 2. Locate Filter:** The lint filter is typically located inside the dryer door opening, at the front of the drum.
- 3. Remove Old Filter:** Grasp the handle or edge of the old lint filter and pull it straight out.
- 4. Clean Filter Housing:** Use a vacuum cleaner with a narrow attachment to remove any lint or debris from the filter housing and duct opening.
- 5. Insert New Filter:** Align the new lint filter with the opening and slide it firmly into place until it is fully seated. Ensure there are no gaps.
- 6. Restore Power:** Plug the appliance back into the electrical outlet.

6. OPERATION

Once the lint filter is correctly installed, ensure it is always in place before operating your dryer or washer-dryer combo. Operating the appliance without the lint filter can lead to reduced efficiency, damage to internal components, and pose a fire risk due to lint accumulation in the exhaust system.

7. MAINTENANCE AND CLEANING

Regular cleaning of the lint filter is essential for optimal appliance performance, energy efficiency, and safety. The filter should be cleaned before or after **every** drying cycle.

- Remove Filter:** Pull the lint filter straight out from its housing.
- Remove Lint:** Roll the lint off the screen with your fingers. Do not rinse the filter under water unless necessary, as wet lint is harder to remove.
- Deep Cleaning (as needed):** If the filter screen becomes clogged with fabric softener residue or other buildup, wash it with warm, soapy water and a soft brush. Rinse thoroughly and allow it to air dry completely before reinserting.
- Reinsert Filter:** Slide the clean, dry filter back into its housing until it is fully seated.

Note: A clogged lint filter restricts airflow, increasing drying time and energy consumption, and can lead to overheating.

8. TROUBLESHOOTING

If you encounter issues related to the lint filter, consider the following:

- Excessive Lint Buildup:** Ensure the filter is cleaned before or after every cycle. If lint still accumulates rapidly, check for proper installation or consult your appliance's manual for other potential causes.
- Damaged Filter:** If the metallic mesh is torn, bent, or has holes, the filter needs to be replaced. A damaged filter cannot effectively trap lint.
- Filter Not Seating Properly:** Check for any obstructions in the filter housing or ensure the filter is correctly aligned. Do not force the filter into place.

For persistent issues or problems unrelated to the lint filter, refer to your appliance's main user manual or contact a certified service technician.

9. SPECIFICATIONS

Feature	Detail
Product Type	Lint Filter for Dryer / Washer-Dryer Combo
Brand Compatibility	Mabe, General Electric (GE), Easy, IEAM
Reference Codes	234D1031P001, WW03F00042, 234D1031P002
Material	Steel Mesh
Color	Gray
Length	33.50 cm (approximately 13.19 inches)
Package Dimensions	35.56 x 12.7 x 10.16 cm (approximately 14 x 5 x 4 inches)

10. WARRANTY AND SUPPORT

This product is an original replacement part. For specific warranty information, please refer to the terms provided at the time of purchase or contact your seller directly. For technical support or inquiries regarding compatibility not covered in this manual, please reach out to the authorized

distributor or seller.

Always retain your proof of purchase for any warranty claims or support requests.

© 2024 Mabe/GE/Easy/IEAM. All rights reserved.